

User Manual

MiVue[™] 730 Series

Revision: R00 (10/2017)

Disclaimer

The screenshots in this manual may differ between different operating systems and software versions. You can download the latest User Manual of your product from Mio™ website (www.mio.com).

Specifications and documents are subject to change without notice. MiTAC does not warrant this document is error-free. MiTAC assumes no liability for damage incurred directly or indirectly from errors, omissions or discrepancies between the device and the documents.

Note

Not all models are available in all regions.

Depending on the specific model purchased, the colour and look of your device and accessories may not exactly match the graphics shown in this document.

MiTAC Europe Ltd.
Spectrum House, Beehive Ring Road,
London Gatwick Airport, RH6 0LG,
UNITED KINGDOM


Table of Contents

Getting to know your dash cam	4
Using your dash cam in a vehicle	5
Precautions and notices	5
Inserting a memory card	7
Formatting a card	7
Connecting to your computer	7
Turning the dash cam on	8
Power button	8
Restarting the dash cam	8
System icons	9
Function keys	9
Setting the date and time	. 10
Recording in driving mode	. 10
Continuous recording	. 10
Event recording	11
Recording in Parking mode	11
Camera mode	. 12
Playback mode	. 12
Getting connected	. 13
MiVue app	. 13
Setting up a WIFI connection	. 13
System settings	. 15

MiVue Manager	17
Installing MiVue Manager	
Playing the recording files	
For more information	20
Caring for your device	20
Safety precautions	21
About charging	
About the charger	21
About the battery	21
About GPS	22
Regulatory information	22
Declaration of conformity	23
WEEE	24

Getting to know your dash cam

Note: The screenshots and other presentations shown in this manual may differ from the ones generated by the actual product.



- Mini-USB connector
- 2 Device mount socket
- 3 LCD screen
- System indicator
- 6 Microphone
- 6 Memory card slot
- Shutdown button

- 3 Camera lens
- Speaker
- Power button / Function key
- Function keys

Using your dash cam in a vehicle

Precautions and notices

- Do not operate the device while driving. Using this product does not change the requirement for a driver to take full responsibility for his or her behavior. This responsibility includes observing all traffic rules and regulations in order to avoid accidents, personal injury or property damage.
- A window mount is needed when using the dash cam in a car. Make sure that
 you place the dash cam in an appropriate place, so as not to obstruct the driver's
 view or deployment of airbags.
- Make sure that no object is blocking the camera lens and no reflective material is placed near the lens. Please keep the lens clean.
- If the car's windscreen is tinted with a coating, it may impact the recording quality.
- To ensure the highest quality recordings, you are advised to place the dash cam near the rear view mirror.
- Select an appropriate location for mounting the device in a vehicle. Never place the device where the driver's field of vision is blocked.
- If the car's windscreen is tinted with a reflective coating, it may be athermic and impact the GPS reception. In this instance, please mount your device where there is a "clear area."
- The system will automatically calibrate the G sensor of the device during startup. To avoid G sensor malfunction, always turn the device on AFTER you mount it in the vehicle properly.

Make sure that your car is parked on level ground. Follow the instructions to mount your dash cam in a vehicle securely.

1. Mount the dash cam.




2. Adjust the lens angle.

When adjusting the angle of mounting, make sure that the camera's view is parallel with the level ground and the ground/sky ratio is close to 6/4.

3. Connect the cables.

Route the cables through the top ceiling and the A-pillar so that it does not interfere with driving. Make sure that the cable installation does not interfere with the vehicle's airbags or other safety features.



Inserting a memory card

Note:

- DO NOT apply pressure to the centre of the memory card.
- MiTAC does not guarantee the product's compatibility with memory cards from all manufacturers.
- Before you start recording, please format the memory card to avoid malfunction caused by files not created by the dash cam.
- Turn the device off before removing the memory card.

You must insert a memory card (not supplied) before you can start recording. The dash cam supports the Class 10 memory cards with 8 GB – 128 GB capacity.

Hold the card (MicroSD) by the edges and gently insert it into the slot as shown in the illustration. To remove a card, gently push the top edge of the card inwards to release it and pull it out of the slot.




Formatting a card

To format a memory card (all data will be erased), press = and select Format.

Connecting to your computer

You can connect the dash cam to your computer to access data on the memory card. Connect the dash cam to the computer via a USB cable (not supplied).



Turning the dash cam on

Complete the installation according to the instructions in the "Using your dash cam in a vehicle" section. Once the vehicle engine is started, the dash cam automatically turns on. The System indicator glows in green when the dash cam is powered.


Power button

Press and hold the Power button for 2 seconds to manually turn the dash cam on and off

Restarting the dash cam

Occasionally, you may need to perform a hardware reset when the dash cam stops responding or if it appears to be "frozen" or unresponsive. To restart the dash cam, press and hold the Power button until the system powers off; press the Power button again to turn the dash cam on.

If the system does not shut down by keeping the Power button pressed, you can force it to shut down by inserting a small rod (such as a straightened paperclip) into the Shutdown button on the device.




System icons

Various system icons on the status bar at the top of the screen provide the status information of your device. The icons displayed will vary depending on your device model and state



Function keys

The device provides four function keys to control the corresponding icons displayed on the LCD screen. The keys' functions may vary on different screens.



Setting the date and time

To make sure that the date and time of your recordings are correct, check the settings before you begin recording.

- 1. Press to access the Settings Menu.
- 2. Select System > Date/Time.
- 3. Select Use GPS time or Manual:
 - When you select Use GPS time, press ↑ / ↓ to select the time zone
 of your location. The system will set date and time according to the GPS
 location.

Note: This feature is not available on all models.

- When you select Manual, the system will display the date and time setting screen. Use + / to adjust the value of the selected field; press and repeat the step until all fields have been changed.
- 4. When done, press 🗸 .

Recording in driving mode

Continuous recording

By default, the system will automatically begin with continuous recording in a few seconds after start-up. The System indicator flashes in green and amber alternately while the recording is in progress.

When continuous recording is in progress, you can manually stop recording by pressing . Press to return to the recording screen; the system will start continuous recording automatically.

The recording may be divided into several video clips; recording will not stop between video clips. The continuous recordings can be found in the "Video" category for file playback.

Event recording

By default, if an event happens such as a sudden impact, high speed driving, an aggressive turn or an accidental crash during continuous recording, the G sensor will prompt the dash cam to start recording the event.

Note: You can change the sensitivity level of the G sensor by selecting > Video Recording > G-Sensor Sensitivity.

If you want to manually start an event recording while continuous recording is in progress, press the Event button (1).

The event recordings can be found in the "Event" category for file playback.

Recording in Parking mode

Note: This feature is not available on all models.

Your dash cam supports the parking recording function. You must use an additional power source to record the video during Parking mode, such as Mio Smart Box uninterruptible power cable which is sold separately. For more information on using Mio Smart Box, see the provided documentation in its package.

The Parking mode function is disabled by default. You can enable the function by selecting > Parking Mode > Detection > On.

Before enabling Parking mode, please check the memory storage allocation of your device. Select > System > Storage Allocation to set a proper allocation for parking recording. Changing the allocation will erase the memory card, so save any videos or photos to your computer first.

When the Parking mode detection is enabled, the system will enter Parking mode when you:

 Disconnect the device's power (for example, when the vehicle engine is stopped or the power cable is disconnected) or when the car stops moving for about 5 minutes.

Note: The feature is triggered by the G sensor of the device. You can change the configuration by selecting \implies > **Parking Mode > Auto Entry**.

 Press P to manually start Parking mode while continuous recording is in progress.

The Parking indicator flashes in red when Parking recording is in progress. To stop Parking mode and resume continuous recording, press . If movements are detected and recorded during Parking mode, you will be asked to playback the video when you stop Parking mode.

The parking recordings can be found in the "Parking" category for file playback.

Camera mode

The dash cam allows you to take a photo: press > Camera > 0.

The photos can be found in the "Photo" category for file playback.

Playback mode

To select a video or photo for playback:

- 1. Press = > File Playback.
- 2. Select the desired type.
- 3. Press ← / → to select the desired file from the list and then press ✓ to start playback.

- 4. During playback, you can:
 - While playing videos, press While playing videos, press While playing videos, press While playing videos, press <a href="https://www.next.videos.
 - While viewing photos, press () to display the previous/next photo.
 - Press to return to the list.
 - Press ••• to display the pop-up menu to select:
 - Play / Pause: Starts or pauses the playback.
 - Move to Event: Moves the file to the "Event" category.
 - Transfer to phone: Uploads the selected video/photo to your smartphone.
 - Delete: Deletes the file.

Getting connected

MiVue app

The MiVue app is an integrated application that allows you to share and back up the videos recorded on a MiVue dash cam via WIFI. Search for "MiVue" in Apple App Store or in Google Play Store to download the MiVue app for free.

Note:

- The MiVue app is compatible with iOS 9.0 (and above) and Android 5.0 (and above) devices.
 MiTAC does not guarantee the product's compatibility with smartphones from all manufacturers.
- Not all features are available for every model.

Setting up a WIFI connection

Note: This feature is not available on all models.

The WIFI function allows you to connect the dash cam to your smartphone. The


WIFI function is disabled by default. You can enable WIFI by selecting > WIFI > On. Once enabled, the WIFI setting screen displays the SSID and password of the dash cam.

Follow the steps to set up the wireless network connection between the dash cam and your smartphone:

- 1. Enable the wireless network function of the smartphone.
- On your smartphone, open the MiVue app and follow the on-screen instructions to set up the connection.

The next time you use your smartphone to connect to the dash cam, you will not be prompted to enter the password again unless you reset your phone to the factory default settings.

3. You can check the WIFI connection status by the WIFI icon on the dash cam.



4. On your smartphone, open the MiVue app and keep it awake. You can now transfer videos by pressing the Event button.

System settings

Note: Not all setting items and options are available for all models.

To customise the system settings, press = .

File Playback

Plays the recorded videos and photos.

Camera

Press to enter Camera mode.

WIFI

Enables or disables WIFI. See the "Setting up a WIFI connection" section for information on connecting the dash cam to your smartphone.

Sound Recording

Sets if you want to include sounds in the recordings. The default setting is **On**.

Parking Mode

Allows you to change the settings of Parking mode. The available settings include:

- Detection: When enabled, the dash cam will automatically start recording when it detects movements or if an event happens in Parking mode.
- Detection Method: Sets the parking detection method to Only G-sensor,
 Only Motion or Both Motion & G-sensor.
- Auto Entry: Sets the mode (Low, Medium, High or Manual) for the system to enter Parking mode automatically.
- Motion Detection: Sets the sensitivity level of motion detection to Low, Medium or High.
- . G-Sensor Sensitivity: Sets the sensitivity level of the G sensor that allows

automatic triggering of the parking recording when the dash cam is in Parking mode

· Video Recording

Changes the settings of recording, including:

- Video Clip Length: Sets the length of each video clip for a continuous recording (1 min, 3 min or 5 min).
- WDR: Enables the WDR (Wide Dynamic Range) function to improve the dash cam's image quality under high-contrast lighting conditions.
- EV: Sets the exposure level (-1 +1) to adjust the brightness of the image.
 The default setting is 0.
- Frequency: Sets the frequency to match the flicker frequency of the local power supply when recording.
- G-Sensor Sensitivity: Sets the sensitivity level (6 levels, from Low to High)
 of the G sensor that allows automatic triggering of the event recording while
 continuous recording is in progress.
- Stamps: Sets the information (Coordinates or G-Sensor) that will be displayed on the recorded video.
- Speed stamp: Displays the driving speed on the recorded video.
- Text stamp: Displays customisable text information.

System

Allows you to change the system settings of the device.

- Satellites: Displays the status of the GPS/GLONASS signal reception. You
 can press and then select GPS or GLONASS for better signal reception if
 the need arises
- · Date/Time: Sets the system date and time.
- System Sound: Enables or disables system notification sounds.

- Welcome Sound: Enables or disables the notification sounds during start-up.
- · Volume: Adjusts the volume level.
- LCD Standby: Selects Always On to keep the LCD on; or sets the timer for the LCD to turn off automatically (10 sec, 1 min or 3 min) after recording starts. Selecting Standby will turn off the LCD (in specified time) but still display the time and speed information.
- · Language: Sets the language.
- · Distance Unit: Sets the preferred distance unit.
- Storage Allocation: The system provides 3 default memory configurations to store the videos and photos. Select the proper configuration based on your usage.
- Restore to Defaults: Restores the system settings to the factory defaults.
- · Version: Displays the software information.
- Format

Formats a memory card. (All data will be erased.)

MiVue Manager

MiVue Manager™ is a tool for you to view the videos recorded on a MiVue dash cam.

Note: Not all features are available for every model.

Installing MiVue Manager

Download MiVue Manager from the Support page of Mio website (www.mio.com/support) and follow the on-screen prompts to install it. Make sure to download the correct software version (Windows or Mac) according to your computer's operating system.

Playing the recording files

- Remove the memory card from the dash cam and access the card on the computer via a card reader. You are advised to copy the recording files to your computer for backup and playback.
- 2. Start MiVue Manager on the computer.
 - By default, MiVue Manager shows the calendar and the file list on the right.
 - When a recording file exists, you will see the date marked with "•." Click that
 date to display the files that were recorded on that date.
 - You can select the file type to display: Event / Normal / Parking.
 - To display all files in the current folder, click All. To return to the calendar view. click Calendar.
- 3. Double-click the desired file on the file list to start playback.
- 4. The playback controls are described as follows:



- Skips to the previous / next file on the list.
- 2 Starts or pauses the playback.
- 3 Changes the playback speed to 1/4x, 1/2x, 1x (default), 1.5x, or 2x.
- Mutes or unmutes the volume.
- 6 Adjusts the volume level.
- O Plays the video in full screen.
- Displays the playback progress. You can click on a point along the track bar to move directly to a different location for the playback.

- 5. During playback, you can view more driving information from the dashboard panel and the G sensor chart that are displayed below the video playback screen.
 - On the dashboard panel, click to display the map screen.
 - The G sensor chart displays data in 3-axis waveform about the car's shift forward/backward (X), to the right/left (Y) and upward/downward (Z).

Note: The map screen may not display when the computer is not connected to the Internet or when your MiVue model does not support the GPS function.

6. The tool bar allows you to do the following:



- Selects the folder that stores the recording files.
- 2 Previews and prints the current video image.
- 3 Saves the selected files to the specified location on your computer.
- Captures and saves the current video image to the specified location on your computer.
- 6 Opens the Settings Menu. The Settings items are described as follows:
 - Change Language: Sets the display language of MiVue Manager.
 - · Change Skin: Sets the colour scheme of MiVue Manager.
 - Check for Update: Checks if there is any new version of MiVue Manager. (Internet access is required for this feature.)
 - About: Displays the version and copyright information of MiVue Manager.
- Exports the GPS information of the selected file in the KML format to the specified location on your computer.

Uploads the selected file to Facebook / YouTube™.

For more information

Caring for your device

Taking good care of your device will ensure trouble-free operation and reduce the risk of damage.

- Keep your device away from excessive moisture and extreme temperatures.
- Avoid exposing your device to direct sunlight or strong ultraviolet light for extended periods of time.
- · Do not place anything on top of your device or drop objects on your device.
- Do not drop your device or subject it to severe shock.
- Do not subject your device to sudden and severe temperature changes. This
 could cause moisture condensation inside the unit, which could damage your
 device. In the event of moisture condensation, allow the device to dry out
 completely before use.
- The screen surface can easily be scratched. Avoid touching it with sharp objects.
 Non-adhesive generic screen protectors designed specifically for use on portable devices with LCD panels may be used to help protect the screen from minor scratches.
- Never clean your device with it powered on. Use a soft, lint-free cloth to wipe the screen and the exterior of your device.
- Do not use paper towels to clean the screen.
- Never attempt to disassemble, repair or make any modifications to your device.
 Disassembling, modifying or any attempt to repair could cause damage to your device, may inflict bodily harm or damage to property and will void any warranty.
- · Do not store or carry flammable liquids, gases or explosive materials in the same

- compartment as your device, its parts or accessories.
- To discourage theft, do not leave the device and accessories in plain view in an unattended vehicle.
- · Overheating may damage the device.

Safety precautions

About charging

- Use only the charger supplied with your device. Use of another type of charger may result in malfunction and/or danger.
- This product is intended to be supplied by a LISTED Power Unit marked with "LPS", "Limited Power Source" and output rated + 5 V dc / 1.0 A.

About the charger

- Do not use the charger in a high moisture environment. Never touch the charger when your hands or feet are wet.
- Allow adequate ventilation around the charger when using it to operate the
 device or charge the battery. Do not cover the charger with paper or other objects
 that will reduce cooling. Do not use the charger while it is inside a carrying case.
- Connect the charger to a proper power source. The voltage requirements are found on the product case and/or packaging.
- · Do not use the charger if the cord becomes damaged.
- Do not attempt to service the unit. There are no serviceable parts inside. Replace the unit if it is damaged or exposed to excess moisture.

About the battery

CAUTION! This unit contains a non-replaceable internal Lithium Ion battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns do not disassemble, crush, puncture or dispose of in fire or water.

· Use a specified battery in the equipment.

- · Important instructions (for service personnel only)
 - Caution! Risk of explosion if battery is replaced by an incorrect type. Dispose
 of used batteries according to the instructions.
 - Replace only with the same or equivalent type recommended by the manufacturer.
 - · The battery must be recycled or disposed of properly.
 - · Use the battery only in the specified equipment.

About GPS

Note: This feature is not available on all models.

- GPS is operated by the United States government, which is solely responsible for the performance of GPS. Any change to the GPS system can affect the accuracy of all GPS equipment.
- GPS satellite signals cannot pass through solid materials (except glass). When
 you are inside a tunnel or building, GPS positioning is not available. Signal
 reception can be affected by situations such as bad weather or dense overhead
 obstacles (such as trees, tunnels, viaducts and tall buildings).
- · The GPS positioning data is for reference only.

Regulatory information

For regulatory identification purposes, MiVue 730 Series is assigned a model number of N583.



Products with the CE marking comply with the Radio Equipment Directive (RED) (2014/53/EU) - issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European Standards:

EN301489-1 V2.1.1 (2017-02)

Draft ETSI EN 301 489-19 V2.1.0 (2017-03)

EN301489-17 V3.1.1 (2017-02)

IEC 60950-1:2005 (Second Edition) + Am 1:2009 + Am 2:2013

ETSI EN 303413 V1.1.1 (2017-06)

EN300328 V2.1.1 (2016-11)

EN62311 (2008)

EN55032:2012+AC 2013 (Class B);

EN55024:2010

EN61000-3-2:2014

EN61000-3-3:2013

IEC 61000-4-2:2008

IEC 61000-4-3:2006+A1:2007+A2:2010:

IEC 61000-4-4:2012:

IEC 61000-4-5:2014

IEC 61000-4-6:2013

IEC 61000-4-8:2009

IEC 61000-4-11:2004

EN50498:2010(ISO7637-2)

The manufacturer cannot be held responsible for modifications made by the User and the consequences thereof, which may alter the conformity of the product with the CE Marking.

Declaration of conformity

Hereby, MiTAC declares that this N583 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

WEFE



This product must not be disposed of as normal household waste, in accordance with the EU directive for waste electrical and electronic equipment (WEEE – 2012/19/EU). Instead, it should be disposed of by returning it to the point of sale, or to a municipal recycling collection point.