

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

1. Install the device according to the instructions.
2. Switch ON the bulb.
3. LED Bulbs LED will blink 2x times to indicate that it is looking for a Z-Wave network to connect to.

Exclusion

1. Turn on the Bulb.
2. Switch the Bulb off and on 3 times in a row (between 0.5 - 2 seconds per re-power).

Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association - one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

Association Groups:

Group Number	Maximum Nodes	Description
1	1	Lifeline - Set configuration parameter 80.

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

Parameter 1: User custom mode for LED animations.

User custom mode for LED animations.

Size: 1 Byte, Default Value: 0

Setting	Description
0	Disable custom mode
1	Blink Colors in order mode.
2	Randomized blink color mode

Parameter 2: Enable/Disable Strobe over Custom Color.

Enable/Disable Strobe over Custom Color.

Size: 1 Byte, Default Value: 0

Setting	Description
0	Disable Strobe over Custom Color.
1	Enable Strobe over Custom Color.

Parameter 3: Set the rate of change to next color in Custom Mode.

Set the rate of change to next color in Custom Mode.

Size: 1 Byte, Default Value: 50

Setting	Description
5 - 8640000	Set the specified rate of change to next color in Custom Mode.

Parameter 4: Set color that LED Bulb blinks in (Blink Mode)

Set color that LED Bulb blinks in (Blink Mode). If you set a value of 6 (2+4), LED Bulb blink between (Red -> Orange) in a cycle. If you set a value 255, LED Bulb will blink all colors in a cycle.

Size: 1 Byte, Default Value: 1

Setting	Description
1	White
2	Red
4	Orange
8	Yellow
16	Green
32	Blue
64	Indigo
128	Purple

Parameter 16: Ramp rate when dimming using Multilevel Switch V1 CC in 100ms

Ramp rate when dimming using Multilevel Switch V1 CC in 100ms

Size: 1 Byte, Default Value: 20

Setting	Description
0 - 100	Specifying the ramp rate when dimming using Multilevel Switch V1 CC in 100ms

Parameter 80: Enable to send notifications to associated devices (Group 1) when the state of LED Bulb is changed.

Enable to send notifications to associated devices(Group 1) when the state of LED Bulb is changed.

Size: 1 Byte, Default Value: 1

Setting	Description
0	Nothing
1	Send basic report to associated devices when the state of the LED Bulb is changed

Parameter 81: The user can configure the parameter to adjust the color component Warm White.

The user can configure the parameter to adjust the color component Warm White.

Size: 2 Byte, Default Value: 2700

Setting	Description
2700 - 4999	Value range =Warm White in Kelvin (K)

Parameter 82: The user can configure the parameter to adjust the color component Cold White.

The user can configure the parameter to adjust the color component Cold White.

Size: 2 Byte, Default Value: 6500

Setting	Description
5000 - 6500	Value rang = Cold White in Kelvin (K)

Technical Data

Dimensions	0.0600000x0.1200000x0.0600000 mm
Weight	132.87 gr
Hardware Platform	ZM5101
EAN	1220000016095
IP Class	IP 20
Voltage	230 V
Device Type	Light Dimmer Switch
Network Operation	Always On Slave
Z-Wave Version	6.51.09
Certification ID	ZC10-18046097
Z-Wave Product Id	0x0371.0x0003.0x0002
Color	White
Firmware Updatable	Updatable by Consumer by RF
Frequency	Europe - 868,4 Mhz
Maximum transmission power	5 mW

Supported Command Classes

- Association Grp Info
- Association V2
- Basic
- Switch Color
- Configuration
- Device Reset Locally
- Firmware Update Md V2
- Manufacturer Specific V2
- Switch Multilevel V2
- Powerlevel
- Security
- Switch All
- Version V2
- Zwaveplus Info V2

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network. Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network. Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **WakeUp Notification** — is a special wireless message issued by a Z-Wave device to announces that is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.

(c) 2020 Z-Wave Europe GmbH, Antonstr. 3, 09337 Hohenstein-Ernstthal, Germany, All rights reserved, www.zwave.eu. The template is maintained by [Z-Wave Europe GmbH](http://www.zwave.eu). The product content is maintained by Z-Wave Europe GmbH, Supportteam, support@zwave.eu. Last update of the product data: 2020-01-23 09:27:10