

Footrest kit "Factory"
Honda CBR 1000RR, from year 2004 -2007
with revers shifting (cod.610.0F) photo Nr.1 - 5
and original shifting (cod.610F) photo Nr.6



Thank you for purchasing the PP rear set .
Please pay attention to several assembling
advices, those will prolong the product life
and will quarantee the correct working of it.

By assembling the footrest kit – dismount
the stock shift lever and see photos 1-5
as following.
Photo 6 is for original shifting only

The right side with brake is mounted the same way as original rear sets. The principal change is in montage of the left
side with shifting lever.
Please, see following steps:



1

Dismount the original rear sets
and screw and take out the
nut (see photo 1).
Bolt down a spacer (included
in delivery) instead of the nut.
(see photo 2 + 3)

2



3

Tighten carefully a spacer
(see photo 4)

4



5

Mount a shifting lever
according to photo 5.

6

By installation of the
set with standard shifting
will be the new
shift lever installed in
the same place where
the original one from
Honda is.
(see photo 6)

