



Manual mounting AXA ring lock on the WATT California.

Due to the sleek design of our California e-bikes, the AXA ring lock does not immediately fit on the bicycles and a number of actions will have to be performed to mount the AXA ring lock on the California. It's not complicated and assembly only takes a few minutes more than usual. This manual explains the assembly with photos in a simple way.

- First you loosen the (rear) fender at the top by unscrewing the M6 bolt.
- Because you have loosened the mudguard, you can press the mudguard down (on the tire) with one hand, which creates more space between the mudguard and the frame.
- Then place the lock between the fender and the frame. Note: this is only possible via the left side of the bicycle, otherwise the key of the lock will get in the way.
- If the lock is between the frame and the mudguard, first reattach the mudguard, because if you first mount the AXA ring lock you can no longer reach the M6 bolt to tighten the mudguard.
- Once you have tightened the mudguard, you can mount the lock to the bicycle using 2 M5x12 bolts (not included).

Simple and easy!



Manual mounting AXA ring lock on the WATT California.

Step 1.



Step 2.



Step 3.





Manual mounting AXA ring lock on the WATT California.

Step 4.



Step 5.

