

INSTALLATION MANUAL DAF NGD SUNVISOR



Sunvisor DAF XF/XG/XG+



REMOVE THE SILVER DECOR STRIP AT THE TOP OF THE SUNVISOR, BY UNDOING THE CLIPS ON THE INSIDE OF THE SUNVISOR.

INSTALLATION MANUAL DAF NGD SUNVISOR



REMOVE THE DECOR STRIP. UNDO THE 10 MOUNTING SCREWS WITH A TORX 30 SCREWDRIVER
6 CENTRE BOLTS AND 4 OUTER BOLTS (2 LEFT, 2 RIGHT)



INSTALLATION MANUAL DAF NGD SUNVISOR

REMOVE THE ORIGINAL SUNVISOR COMPLETELY. ONLY THE ORIGINAL BRACKETS REMAIN
ON THE CABIN




3 CENTRE BRACKETS



2 OUTER BRACKETS

INSTALLATION MANUAL DAF NGD SUNVISOR



INSTALL THE BYPASS BRACKETS ON THE 3 CENTER BRACKETS AS SHOWN. THERE ARE NO BYPASS BRACKETS NEEDED ON THE ORIGINAL SIDE BRACKETS.



REMOVE THE RUBBER BUSHINGS FROM THE ORIGINAL SUNVISOR. SEPARATE THE RUBBER AND METAL PART, TO REMOVE THEM EASILY. THESE NEED TO BE PUT BACK IN THE NEW SUNVISOR.

INSTALLATION MANUAL DAF NGD SUNVISOR



PUT THE BUSHINGS IN THE NEW SUNVISOR, METAL PART ON THE INSIDE OF THE SUNVISOR



INSTALLATION MANUAL DAF NGD SUNVISOR



INSTALLATION MANUAL DAF NGD SUNVISOR



MOUNT THE SUNVISOR BACK ON THE ORIGINAL BRACKETS, USING THE ORIGINAL BOLTS THAT
CAME OUT OF THE ORIGINAL SUNVISOR.

6 CENTRE BOLTS, 4 OUTER BOLTS (2 LEFT AND 2 RIGHT)



INSTALLATION MANUAL DAF NGD SUNVISOR

TOOLS NEEDED :

SCREWDRIVER TORX 30

WRENCH 10 MM

MATERIAL NEEDED :

3 X BYPASS BRACKET (MIDDLE BRACKETS)

3 X BOLT M6 (25)

3 X NUT M6

3 X WASHER 3 CM

PLEASE NOTE, THE BYPASS BRACKETS ARE SPECIFIC PER CABIN TYPE.

XF/XG USE THE SAME BYPASS BRACKETS

XG+ HAS SPECIFIC BYPASS BRACKETS

ALWAYS TEST FIT BEFORE PAINTING.

Solar
SOLARGUARD.NL **Guard**

EXCLUSIVE TRUCK PARTS