

INSTRUCTION

CARBON FIBER ABARTH SABELT SEAT COVER SHELL

FT500-38



1. The product is a cover part so is mounted on the original part.

2. Before adding any adhesive first take out the lather part of seat and the sponge than you will put out the seat handle from inside. After that place back the sponge and lather.





3. Add adhesive behind the CF part as is shown in photo.

(We recommended Black Bodywork Silicon Glue such as 3M or Wurth.)

4. Fix it to original part and wait until glue get hard.