

INSTRUCTION CARBON FIBER ALFA ROMEO BRERA CENTRAL CONSOLE TRIM ARB-09



1. This product is a cover so you don't need to remove the original part.

2. Before you add some adhesive clean a little bit the behind of carbon fiber part with an emery.

3. After that add adhesive at the points as is shown in the photo (We recommended Black Bodywork Silicon Glue as adhesive such as 3M or Wurth.)

4. Mount the product in the right position and keep the position by applying tape on top of product and wait till it get hard.

