

INSTRUCTION

CARBON FIBER ALFA ROMEO 159 STEERING WHEEL

AR159-03



1. This product is a cover so you don't need to remove the original part.

2. Before you add some adhesive clean a little bit the behind of a carbon fiber part with an emery.

3. After that add adhesive at some points as is shown in the photo.

(We recommended Black Bodywork Silicon Glue as adhesive such as 3M or Wurth.)

4. Fix it and wait until glue get hard.

