

# INSTRUCTION

*Jaguar F-Type  
Extended Flap Bumper  
Intercooler Frame  
JGR-23*

## 1

This product is a cover so you don't need to remove the original part

## 2

Before you add some adhesive, clean the back side of the carbon fiber part lightly with sandpaper. After cleaning with sandpaper,



## 3

After that add adhesive at the lines as is shown in the photo (We recommended Black Bodywork Silicon Glue as adhesive such as 3M or Wurth),



## 4

Mount the product in the right position and keep the position until adhesive is dry.