

INSTRUCTION

JGR-32 Jaguar F-Type Headrest Inserts



1

The **rear part** is mounted the same as the original part of the car.

- Remove the original **rear** part by releasing the clips.
- Unscrew and remove the original **front** part using the factory bolts.
- Install the **front** Carbon Fiber part using the original bolts.

2

Attach the **rear** Carbon Fiber part (without clips) to the front Carbon Fiber part using automotive adhesive/glue.