

INSTRUCTION

PORSCHE GT3 RS
REAR INTAKE FENDERS
GT3RS-09



1

This product is a cover, therefore there is no need to remove the original part.

2

Before installation, thoroughly clean the mounting surface. For improved adhesion, lightly sand the back side of the carbon fiber part and the contact area on the vehicle.

3

Apply adhesive to the designated areas as shown in the installation diagram, on both sides of the part. We recommend using a high-quality black automotive adhesive/sealant, such as 3M or Würth.

4

Carefully position the product, ensure proper alignment, and hold it securely in place until the adhesive has fully cured.