

INSTRUCTION

ALFA ROMEO MITO
HEADLIGHT TRIM -
CARBON FIBRE

ARM-001



1. Remove the OEM Part

Carefully remove the original OEM part from the vehicle by removing all factory screws. Keep the OEM screws, as they will be reused to install the carbon fiber replacement part.

2. Test Fit the Carbon Fiber Part

Position the carbon fiber replacement part over the original mounting location. Check that all mounting points align correctly and verify the fit before proceeding with the installation.

3. Secure the Carbon Fiber Part

Using the original OEM screws removed in Step 1, fasten the carbon fiber replacement part to the vehicle. Tighten all screws evenly, ensuring the part is securely mounted and properly aligned.

4. Final Inspection

After all screws have been tightened, inspect the installation carefully. Make sure the carbon fiber part is securely attached, correctly aligned, and that all gaps are even before completing the installation.

Important

- Always test fit the part before final installation.
- Reuse all original OEM screws unless otherwise specified.
- Tighten all screws evenly to prevent stress on the carbon fiber.
- Do not overtighten the mounting screws.
- Verify that the part is securely installed before driving the vehicle.