

INSTRUCTION

ALFA ROMEO MITO TAIL LIGHT - CARBON FIBRE

ARM-005



1. Remove the OEM Part

Carefully remove the original OEM part from the vehicle following the manufacturer's recommended procedure. Clean the mounting surface thoroughly and remove any dirt, grease, or adhesive residue before installation.

2. Test Fit the Carbon Fiber Part

Position the carbon fiber replacement part over the original mounting location. Check that the part fits correctly and aligns properly before applying adhesive.

3. Apply Automotive Adhesive

Apply a continuous bead of high-quality automotive-grade adhesive to the contact surface of the carbon fiber part. We recommend using a professional bodywork adhesive such as 3M or Würth for the best results.

4. Install the Carbon Fiber Part

Carefully position the carbon fiber part onto the vehicle. Align it correctly and press firmly over the entire surface to ensure proper contact. Use masking tape to hold the part securely in place while the adhesive cures.

5. Final Inspection

Once the adhesive has fully cured, remove the masking tape and inspect the installation. Make sure the carbon fiber part is securely bonded, correctly aligned, and evenly seated on all sides.

Important

- Always test fit the part before applying adhesive.
- Clean and degrease all bonding surfaces before installation.
- Use only a high-quality automotive-grade adhesive.
- Use masking tape to keep the part in position while the adhesive cures.
- Follow the adhesive manufacturer's recommended curing time before driving the vehicle.