INSTRUCTION

ALFA ROMEO BRERA MIRROR CAPS - CARBON FIBRE

ARB-01



1. Remove the Lower Cover
Carefully open/remove the lower cover underneath the side mirror.

2. Remove the Screws
Unscrew the mounting screws located underneath the cover.

3. Disconnect the Mirror Assembly
Open the interior triangular cover, remove the screws inside, and carefully disconnect the electrical connector.

4. Remove the Mirror Glass
Carefully release the mirror glass from the retaining clips. Take extra care to avoid damaging or breaking the glass.

5. Transfer the Original Mechanism
Remove the internal mechanism from the original mirror housing and install it onto the new carbon fiber part.

6. Reassemble
Follow the previous steps in reverse order to reinstall the mirror, reconnect the electrical connection, tighten all screws, and refit the covers.

Important: *Handle the mirror glass and retaining clips carefully during removal and installation.*