

Tips before you start wallpapering

- Make sure you are wallpapering with 2 people; this makes it a lot easier
- Make sure the wall that you are wallpapering is even or white. This will prevent the appearance of stains/ other colors with light colored patterns.
- Make sure that during the wallpapering you will not get glue on the front of the wallpaper to prevent stains. If this happens anyway, then blot it away. Never rub it in!
- Are you wallpapering a plastered wall? First knock softly on the wall: with a dull sound the plaster is probably locally loose. Carefully remove the bad spots and repair the holes with a filler before you start wallpapering.
- First treat highly absorbent substrates with a primer to break the greatest suction force. See instructions on the packaging of the wallpaper glue.
- Always keep the printed side facing up when cutting the webs. Any errors and / or stains are then immediately detected.
- Always use a sharp knife to cut the wallpaper. A blunt blade can cause slits or rips.
- Wallpaper always needs time to dry. If it gets dried to quickly it can cause it to shrink or tear. Therefore, it is important when you start wallpapering to do this with the doors and windows closed and the heating at a moderate temperature.
- When cleaning the wallpaper, always do this with a blot, never rub, because that may cause the print to stain. Depending on the wallpaper, a slightly damp cloth may or may not be used; first check the product description.

Tools & materials:

1. We recommend for wallpaper with a Non-woven backing; the 'Ready & Roll' wallpaper glue for non-woven wallpaper from Perfax (ready-made) or Wallpaper glue for non-woven wallpaper from Perfax (needs to be prepared with water). Please check the m2 before you are in the shop so you are sure that you buy the correct amount of glue.
2. Wallpaper smoother, snap-off knife, pasting brush and/or pasting roller, ruler, ladder
3. Perpendicular (in case you apply wallpaper partially and not the complete wall)

Processing advice of non-woven wallpaper:

1. Make the glue according to the instructions or use ready-made wallpaper glue.
2. Work from left to right (with customized wallpaper) with number 1 being the first roll to apply on the wall, number 2 next, number 3 next etc.
3. Are you looking for one wallpaper lane on a wall? Then pull a perpendicular line from top to bottom on the wall so that the wallpaper hangs straight. Use a spirit level or plumb bob for this. This is also a useful tip if you are looking at the entire wall.
4. Then apply the glue to the wall with a roller. Glue only a part of the wall and keep the width of the wallpaper web (+ 10cm).

5. Make sure that the second lane matches the pattern on the first lane and then cut off the lane.
6. Apply the wallpaper directly to the wall on the still damp glue. Non-woven wallpaper can also be applied directly from the roll. Press the wallpaper and smooth it with a wallpaper board, brush or cloth. Note: make sure that the spatula, brush or cloth is dry and does not contain glue residues!
7. Cut the wallpaper along the ceiling and the skirting board using a ruler knife