



# **Product Assembly Guide**

## **Plastic Base Roll Containers**

**Step 1:**  
Start with the base in front of you.



**Step 2:**  
Next, add on the first side of the roll container. This is fixed in place to the base with the metal clamp.



**Step 3:**  
Add on the second side of the roll container and fix in place with the metal clamp to secure it to the base.



**Step 4:**  
If you have a 3 sided unit, put the back in place and secure with the plastic clips. These can then be secured with the bolts provided.



When the sides are in place, use the metal clamp to attach them to the base.



The clamps are quite stiff to clamp down, so you may need a hammer to knock them in to place. Secure underneath with the bolts provided.



To attach the back to the sides, these plastic clips are provided. You will see the position of the holes for the bolts to go through on the gates. This is the same for the front and back gates.

