

Mounting instructions



AIRCELL®7

N-male (crimp) / item. no.: 7371



1
Cut off the cable end at right angles.



2
Push the crimp sleeve onto the cable and strip it to approx. 15 mm up to the copper braid.



3
Push the copper braid backwards and unscrew the core of the cable, maintaining 9 mm of the dielectric. The core itself has to be shortened to 5 mm.



4
The inner lift is pushed over the core and crimped with 0.1 inch at the back.



5
The plug is plugged in with the dielectric in the socket. Subsequently, the copper braid is suitably shortened with a side cutter and the crimp sleeve is overstretched.



6
Finally, the crimp sleeve is crimped at 0.355 inches.