









# Bike Trailer & Trolley

for

## Kayaks & Large Boards

### PART LIST

1 x Hitch (unassembled)	 A set of metal hitch components including a ball, a shank, a pin, and a lock.
1 x Detachable Tow Bar (unassembled in three sections)	 Three sections of a black metal tow bar: a long straight section, a shorter straight section, and a curved section.
2 x Solid Wheels	 Two black, solid, multi-spoke wheels.
1 x Cart Frame (including 2 x sets of straps)	 A metal cart frame with two sets of black straps attached to the sides.
1 x Trailer Storage Bag	 A grey, textured storage bag with a handle and a strap, designed to fit over the cart frame.
2 x 'U' Bolts	 Two metal U-bolts with nuts and washers.
2 x Pins (for tow bar)	 Two metal pins with curved ends, used to connect the tow bar sections.
1 x Extra Strap (to secure kayak to trailer)	 A black, heavy-duty strap with a hook and a loop end.

## TOOLS REQUIRED(INCLUDED)

Set of Wrenches/ Spanners

Set of Allen/ Hex keys

### Warning

**DO NOT** exceed 85lbs/ 38.5Kgs in total weight. The weight must be evenly distributed on the trolley and **NOT ON THE TOW BAR!**



### Bicycle Hitch



- 1) The hitch will require assembly. All parts can be found in the same box.
- 2) DO NOT remove the plastic cap from the hitch.
- 3) Assemble Part number 2 & 4 by removing the nut, bolt and spacer tube from Part 4. Slide Part 2 over Part 4 and then reinsert/ connect the nut, bolt and spacer tube as shown below. Part 2 and 4 will now be fixed together.



- 4) Remove the seat post from the bike and mount Part 4 and 2 of the hitch as high as possible (as shown in the image below). You will need to loosen the nuts on Part 4 to allow the seat post to slide through the opening easily. Tighten the nuts again so that the hitch is now secured in place.



- 5) Part 1 will be fixed to the end of the tow bar (see Tow Bar section below).
- 6) Part 3 is a pin used to secure the tow bar in place once Part 1 has been placed/ fitted on to the ball of the hitch (as shown in the image below).



**CAUTION –**

**DO NOT** remove the plastic cap from the hitch.

**ALWAYS** use the pin to secure the tow bar to the hitch.

## Tow Bar

- 1) Connect the three sections of the tow bar using the tow bar connection pins provided.
- 2) Connect the ball hitch section (Hitch Part 1) to the end of the tow bar and tighten the nuts accordingly.

## Trolley/ Cart

- 1) Unfold the cart section.
- 2) Remove the pins. Push the wheels over the pin positions and into place. Replace pins to secure wheels in position.
- 3) Attach the Trailer Storage Bag using the Velcro straps.
- 4) Connect the tow bar to the top of the cart using the two 'U' bolts provided (the 'U' is fitted upside down as shown), tightening the nuts so that the tow bar is fitted securely.



**CAUTION** – Always use all three straps provided to tie down the kayak/ board securely to the trailer so that it doesn't fall off.

**NOTE** – The trailer can also be used as a trolley when not using the bike by removing the tow bar. All bases are covered so that you can find your flow and enjoy!