

Make	Model	Sub-Model	Engine	Valves	BHP	Year	Fitment Details
AMERICAN SUSPENSION AFTERMARKET CALIPERS	B17 Mach 8		Petrol				To Fit Front Left
AMERICAN SUSPENSION AFTERMARKET CALIPERS	P26		Petrol				To Fit Front Left
BENELLI	354		350.0 Petrol			1982	To Fit Rear Right
BENELLI	750 Sei		750.0 Petrol			1975	To Fit Front Right
BENELLI	900 Sei		900.0 Petrol			1983	To Fit Front Left
BIMOTA	All early models		750.0 Petrol			1988	To Fit Front Right
BMW	K1		1000.0 Petrol			1982	To Fit Front Left
BMW	K1		1000.0 Petrol			1983	To Fit Front Left
BMW	K1		1000.0 Petrol			1984	To Fit Front Left
BMW	K1		1000.0 Petrol			1985	To Fit Rear Right
BMW	K1		1000.0 Petrol			1986	To Fit Front Left
BMW	K1		1000.0 Petrol			1987	To Fit Front Left
BMW	K1		1000.0 Petrol			1988	To Fit Front Left
BMW	K1		1000.0 Petrol			1989	To Fit Rear Right
BMW	K1		1000.0 Petrol			1990	To Fit Rear Right
BMW	K1		1000.0 Petrol			1991	To Fit Rear Right
BMW	K1		1000.0 Petrol			1992	To Fit Rear Right
BMW	K1		1000.0 Petrol			1993	To Fit Rear Right
BMW	K100	LT	100.0 Petrol			1986	To Fit Rear Right
BMW	K100	LT	100.0 Petrol			1987	To Fit Front Right
BMW	K100	LT	100.0 Petrol			1988	To Fit Front Left
BMW	K100	LT	100.0 Petrol			1989	To Fit Rear Right
BMW	K100	LT	100.0 Petrol			1990	To Fit Rear Right
BMW	K100	LT	100.0 Petrol			1991	To Fit Rear Right
BMW	K100	RS	100.0 Petrol			1983	To Fit Front Left
BMW	K100	RS	100.0 Petrol			1984	To Fit Front Left
BMW	K100	RS	100.0 Petrol			1985	To Fit Front Left
BMW	K100	RS	100.0 Petrol			1986	To Fit Front Left
BMW	K100	RS	100.0 Petrol			1987	To Fit Rear Right
BMW	K100	RS	100.0 Petrol			1988	To Fit Rear Right
BMW	K100	RS	100.0 Petrol			1989	To Fit Rear Right
BMW	K100	RS	100.0 Petrol			1990	To Fit Rear Right
BMW	K100	RS	100.0 Petrol			1991	To Fit Rear Right
BMW	K100	RS	100.0 Petrol			1992	To Fit Rear Right
BMW	K100	RT	100.0 Petrol			1983	To Fit Rear Right
BMW	K100	RT	100.0 Petrol			1984	To Fit Front Left
BMW	K100	RT	100.0 Petrol			1985	To Fit Rear Right
BMW	K100	RT	100.0 Petrol			1986	To Fit Front Left
BMW	K100	RT	100.0 Petrol			1987	To Fit Rear Right
BMW	K100	RT	100.0 Petrol			1988	To Fit Front Right
BMW	K100	RT	100.0 Petrol			1989	To Fit Rear Right
BMW	K100 2		1002.0 Petrol			1987	To Fit Front Left
BMW	K100 2		1002.0 Petrol			1988	To Fit Rear Right
BMW	K100 2	1987-Aug. 1988	1002.0 Petrol			1988	To Fit Rear Right
BMW	K100 2	Sept. 1988-1990	1002.0 Petrol			1989	To Fit Rear Right
BMW	K100 2	Sept. 1988-1990	1002.0 Petrol			1990	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1989	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1990	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1991	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1992	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1993	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1994	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1995	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1996	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1997	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1998	To Fit Rear Right
BMW	K1100	LT	1100.0 Petrol			1999	To Fit Rear Right
BMW	K1100	RS	1100.0 Petrol			1992	To Fit Rear Right
BMW	K1100	RS	1100.0 Petrol			1993	To Fit Rear Right
BMW	K1100	RS	1100.0 Petrol			1994	To Fit Rear Right
BMW	K1100	RS	1100.0 Petrol			1995	To Fit Rear Right
BMW	K1100	RS	1100.0 Petrol			1996	To Fit Rear Right
BMW	K1200	GT 2 pin rear pad K41	1200.0 Petrol			2003	To Fit Rear Right
BMW	K1200	GT 2 pin rear pad K41	1200.0 Petrol			2004	To Fit Rear Right
BMW	K1200	GT 2 pin rear pad K41	1200.0 Petrol			2005	To Fit Rear Right
BMW	K1200	GT 2 pin rear pad K41	1200.0 Petrol			2006	To Fit Rear Right
BMW	K1200	RS K589	1200.0 Petrol			2001	To Fit Rear Right
BMW	K1200	RS K589	1200.0 Petrol			2002	To Fit Rear Right
BMW	K1200	RS K589	1200.0 Petrol			2003	To Fit Rear Right
BMW	K1200	RS K589	1200.0 Petrol			2004	To Fit Rear Right
BMW	K75	75-2 1984-July 1990	75.0 Petrol			1984	To Fit Front Right
BMW	K75	75-2 1984-July 1990	75.0 Petrol			1985	To Fit Front Left
BMW	K75	75-2 1984-July 1990	75.0 Petrol			1986	To Fit Front Left
BMW	K75	75-2 1984-July 1990	75.0 Petrol			1987	To Fit Front Left
BMW	K75	75-2 1984-July 1990	75.0 Petrol			1988	To Fit Front Left
BMW	K75	75-2 1984-July 1990	75.0 Petrol			1989	To Fit Front Right

BMW	K75	75-2 1984-July 1990	75.0 Petrol	1990 To Fit Front Left
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1990 To Fit Rear Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1991 To Fit Rear Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1992 To Fit Rear Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1993 To Fit Rear Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1994 To Fit Rear Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1995 To Fit Rear Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1996 To Fit Rear Right
BMW	K75	75-S 1984-Aug. 1988	75.0 Petrol	1984 To Fit Front Left
BMW	K75	75-S 1984-Aug. 1988	75.0 Petrol	1985 To Fit Front Right
BMW	K75	75-S 1984-Aug. 1988	75.0 Petrol	1986 To Fit Front Left
BMW	K75	75-S 1984-Aug. 1988	75.0 Petrol	1987 To Fit Front Left
BMW	K75	75-S 1984-Aug. 1988	75.0 Petrol	1988 To Fit Front Right
BMW	K75	C 1985-August	75.0 Petrol	1985 To Fit Front Right
BMW	K75	C 1985-August	75.0 Petrol	1986 To Fit Front Right
BMW	K75	C 1985-August	75.0 Petrol	1987 To Fit Front Right
BMW	K75	C 1985-August	75.0 Petrol	1988 To Fit Front Left
BMW	K75	RT	75.0 Petrol	1989 To Fit Rear Right
BMW	K75	RT	75.0 Petrol	1990 To Fit Rear Right
BMW	K75	RT	75.0 Petrol	1991 To Fit Rear Right
BMW	K75	RT	75.0 Petrol	1992 To Fit Rear Right
BMW	K75	RT	75.0 Petrol	1993 To Fit Rear Right
BMW	K75	RT	75.0 Petrol	1994 To Fit Rear Right
BMW	K75	RT	75.0 Petrol	1995 To Fit Rear Right
BMW	K75	RT	75.0 Petrol	1996 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1985 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1986 To Fit Front Right
BMW	K75	S	75.0 Petrol	1987 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1988 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1989 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1990 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1991 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1992 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1993 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1994 To Fit Rear Right
BMW	K75	S	75.0 Petrol	1995 To Fit Rear Right
BMW	R100	7 T	100.0 Petrol	1980 To Fit Front Left
BMW	R100	7 T	100.0 Petrol	1981 To Fit Front Right
BMW	R100	7 T	100.0 Petrol	1982 To Fit Front Left
BMW	R100	7 T	100.0 Petrol	1983 To Fit Front Left
BMW	R100	7 T	100.0 Petrol	1984 To Fit Front Right
BMW	R100	RS 9E	100.0 Petrol	1980 To Fit Rear Left
BMW	R100	RS 9E	100.0 Petrol	1981 To Fit Front Right
BMW	R100	RS 9E	100.0 Petrol	1982 To Fit Rear Left
BMW	R100	RS 9E	100.0 Petrol	1983 To Fit Rear Left
BMW	R100	RS 9E	100.0 Petrol	1984 To Fit Front Right
BMW	R100	RS	100.0 Petrol	1986 To Fit Front Right
BMW	R100	RS	100.0 Petrol	1987 To Fit Front Right
BMW	R100	RS	100.0 Petrol	1988 To Fit Front Right
BMW	R100	RT 1987-Aug. 1988	100.0 Petrol	1987 To Fit Front Right
BMW	R100	RT 1987-Aug. 1988	100.0 Petrol	1988 To Fit Front Right
BMW	R100	RT Oct. 1980-1984	100.0 Petrol	1980 To Fit Front Left
BMW	R100	RT Oct. 1980-1984	100.0 Petrol	1981 To Fit Rear Left
BMW	R100	RT Oct. 1980-1984	100.0 Petrol	1982 To Fit Rear Left
BMW	R100	RT Oct. 1980-1984	100.0 Petrol	1983 To Fit Rear Left
BMW	R100	RT Oct. 1980-1984	100.0 Petrol	1984 To Fit Front Right
BMW	R1100	RS	1100.0 Petrol	1992 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	1993 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	1994 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	1995 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	1996 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	1997 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	1998 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	1999 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	2000 To Fit Rear Right
BMW	R1100	RS	1100.0 Petrol	2001 To Fit Rear Right
BMW	R45	45 N	473.0 Petrol	1978 To Fit Front Right
BMW	R45	45 N	473.0 Petrol	1979 To Fit Front Left
BMW	R45	45 N	473.0 Petrol	1980 To Fit Front Right
BMW	R45	45 N	473.0 Petrol	1981 To Fit Front Right
BMW	R45	45 N	473.0 Petrol	1982 To Fit Front Right
BMW	R45	45 N	473.0 Petrol	1983 To Fit Front Left
BMW	R45	45 N	473.0 Petrol	1984 To Fit Front Left
BMW	R45	45 N	473.0 Petrol	1985 To Fit Front Left
BMW	R65	GS	650.0 Petrol	1987 To Fit Front Left
BMW	R65	GS	650.0 Petrol	1988 To Fit Front Left
BMW	R65	GS	650.0 Petrol	1989 To Fit Front Left

BMW	R65	GS	650.0 Petrol	1990 To Fit Front Left
BMW	R65	GS	650.0 Petrol	1991 To Fit Front Left
BMW	R65	GS	650.0 Petrol	1992 To Fit Front Left
BMW	R65	July 1988-Aug. 1989	650.0 Petrol	1989 To Fit Front Right
BMW	R65	LS	650.0 Petrol	1981 To Fit Front Right
BMW	R65	LS	650.0 Petrol	1982 To Fit Front Left
BMW	R65	LS	650.0 Petrol	1983 To Fit Front Left
BMW	R65	LS	650.0 Petrol	1984 To Fit Front Left
BMW	R65	LS	650.0 Petrol	1985 To Fit Front Right
BMW	R65	R	650.0 Petrol	1988 To Fit Front Left
BMW	R65	RT	650.0 Petrol	1985 To Fit Front Left
BMW	R65	RT	650.0 Petrol	1986 To Fit Front Left
BMW	R65	RT	650.0 Petrol	1987 To Fit Front Left
BMW	R65	RT	650.0 Petrol	1988 To Fit Front Right
BMW	R65	T	650.0 Petrol	1980 To Fit Front Left
BMW	R65	T	650.0 Petrol	1981 To Fit Front Left
BMW	R65	T	650.0 Petrol	1982 To Fit Front Left
BMW	R65	T	650.0 Petrol	1983 To Fit Front Left
BMW	R65	T	650.0 Petrol	1984 To Fit Front Left
BMW	R65	T	650.0 Petrol	1985 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1980 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1981 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1982 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1983 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1984 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1985 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1986 To Fit Front Left
BMW	R80	GS	80.0 Petrol	1987 To Fit Front Left
BMW	R80	R 80 RT	80.0 Petrol	1984 To Fit Front Right
BMW	R80	R 80 RT	80.0 Petrol	1985 To Fit Front Left
BMW	R80	R 80 RT	80.0 Petrol	1986 To Fit Front Left
BMW	R80	R 80 RT	80.0 Petrol	1987 To Fit Front Left
BMW	R80	R 80 RT	80.0 Petrol	1988 To Fit Front Left
BMW	R80	RT	80.0 Petrol	1982 To Fit Front Right
BMW	R80	RT	80.0 Petrol	1983 To Fit Front Right
BMW	R80	RT	80.0 Petrol	1984 To Fit Front Right
BMW	R80	ST	80.0 Petrol	1982 To Fit Front Left
BMW	R80	ST	80.0 Petrol	1983 To Fit Front Left
BMW	R80	ST	80.0 Petrol	1984 To Fit Front Left
BMW	R80	TIC - Sept. 1980-1985	80.0 Petrol	1981 To Fit Front Right
BMW	R80	TIC - Sept. 1980-1985	80.0 Petrol	1982 To Fit Front Left
BMW	R80	TIC - Sept. 1980-1985	80.0 Petrol	1983 To Fit Front Left
BMW	R80	TIC - Sept. 1980-1985	80.0 Petrol	1984 To Fit Front Right
BMW	R80	TIC - Sept. 1980-1985	80.0 Petrol	1985 To Fit Front Right
BMW	R80	TIC	80.0 Petrol	1980 To Fit Front Right
DUCATI	1000 R1 Hailwood Replica		1000.0 Petrol	1984 To Fit Front Right
DUCATI	250 350 450	Desmo Single	250.0 Petrol	1974 To Fit Front Left
DUCATI	250 350 450	Desmo Single	250.0 Petrol	1975 To Fit Front Left
DUCATI	250 350 450	Desmo Single	250.0 Petrol	1976 To Fit Front Left
DUCATI	250 350 450	Desmo Single	250.0 Petrol	1977 To Fit Front Left
DUCATI	750 F1		750.0 Petrol	1998 To Fit Rear Left
DUCATI	750 Paso		750.0 Petrol	1987 To Fit Front Left
DUCATI	750 Paso		750.0 Petrol	1988 To Fit Front Left
DUCATI	750 Paso		750.0 Petrol	1989 To Fit Front Left
DUCATI	750 Paso		750.0 Petrol	1990 To Fit Front Left
DUCATI	750 Sport		750.0 Petrol	1988 To Fit Front Left
DUCATI	750 Sport		750.0 Petrol	1989 To Fit Front Left
DUCATI	750 Sport		750.0 Petrol	1990 To Fit Front Right
DUCATI	860 GT GTS		860.0 Petrol	1975 To Fit Front Right
DUCATI	860 GT GTS		860.0 Petrol	1976 To Fit Rear Left
DUCATI	900 SD	Darmah	900.0 Petrol	1977 To Fit Front Right
DUCATI	900 SD	Darmah	900.0 Petrol	1978 To Fit Rear Left
DUCATI	900 SD	Darman	900.0 Petrol	1978 To Fit Front Left
DUCATI	900 GTS		900.0 Petrol	1975 To Fit Front Right
DUCATI	900 GTS		900.0 Petrol	1976 To Fit Rear Left
DUCATI	900 Hailwood Replica		900.0 Petrol	1979 To Fit Front Left
DUCATI	906 Paso		906.0 Petrol	1988 To Fit Front Left
DUCATI	906 Paso		906.0 Petrol	1989 To Fit Front Left
DUCATI	Pantah 600		600.0 Petrol	1981 To Fit Front Left
DUCATI	Pantah 650		650.0 Petrol	1984 To Fit Rear Left
HOREX	500 600 Columbus		600.0 Petrol	1988 To Fit Front Left
HOREX	HRD 600		600.0 Petrol	1985 To Fit Rear Left
LAVERDA	1000 3C	C	1000.0 Petrol	1974 To Fit Front Left
LAVERDA	1000 3C	C	1000.0 Petrol	1975 To Fit Rear Left
LAVERDA	1000 3CL	CL	1000.0 Petrol	1976 To Fit Rear Left
LAVERDA	1000 3CL	CL	1000.0 Petrol	1977 To Fit Front Right
LAVERDA	1000 3CL	CL	1000.0 Petrol	1978 To Fit Rear Left

LAVERDA	1000 3CL	Jarama Jota	1000.0 Petrol	1979 To Fit Front Left
LAVERDA	1000 3CL	Jarama Jota	1000.0 Petrol	1980 To Fit Front Right
LAVERDA	1000 3CL	Jarama Jota	1000.0 Petrol	1981 To Fit Front Left
LAVERDA		1000 RGA RGS Exec	1000.0 Petrol	1983 To Fit Front Left
LAVERDA		1000 RGS Corsa	1000.0 Petrol	1984 To Fit Rear Left
LAVERDA		1000 RGS	1000.0 Petrol	1982 To Fit Rear Left
LAVERDA		1000 SFC	1000.0 Petrol	1985 To Fit Front Right
LAVERDA		1000 SFC	1000.0 Petrol	1986 To Fit Front Left
LAVERDA	1200 TS Mirage	Mirage	1200.0 Petrol	1981 To Fit Front Left
LAVERDA		1200	1200.0 Petrol	1978 To Fit Rear Left
LAVERDA		1200	1200.0 Petrol	1979 To Fit Rear Left
LAVERDA		750 SF2	750.0 Petrol	1974 To Fit Front Right
LAVERDA		750 SF3	750.0 Petrol	1976 To Fit Rear Left
LAVERDA		750 SF3	750.0 Petrol	1977 To Fit Rear Left
LAVERDA		750 SFC	750.0 Petrol	1974 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1984 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1985 To Fit Front Right
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1986 To Fit Front Right
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1987 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1988 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1989 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1990 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1991 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1992 To Fit Front Left
MOTO-GUZZI	1000 Le-Mans	IV V DE	1000.0 Petrol	1993 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1984 To Fit Front Left
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1985 To Fit Rear Left
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1986 To Fit Front Right
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1987 To Fit Front Right
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1988 To Fit Front Right
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1989 To Fit Front Right
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1990 To Fit Front Left
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1991 To Fit Front Right
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1992 To Fit Front Left
MOTO-GUZZI	1000 Le-Mans	IV V KE	1000.0 Petrol	1993 To Fit Rear Left
MOTO-GUZZI		1000 GT RE	1000.0 Petrol	1987 To Fit Front Left
MOTO-GUZZI		1000 GT RE	1000.0 Petrol	1988 To Fit Front Left
MOTO-GUZZI		1000 GT RE	1000.0 Petrol	1989 To Fit Front Left
MOTO-GUZZI		1000 GT RE	1000.0 Petrol	1990 To Fit Front Left
MOTO-GUZZI		1000 GT RE	1000.0 Petrol	1991 To Fit Rear Left
MOTO-GUZZI		1000 II	1000.0 Petrol	1983 To Fit Front Left
MOTO-GUZZI		1000 II	1000.0 Petrol	1984 To Fit Front Left
MOTO-GUZZI		1000 II	1000.0 Petrol	1985 To Fit Front Left
MOTO-GUZZI		1000 II	1000.0 Petrol	1986 To Fit Front Right
MOTO-GUZZI		1000 II	1000.0 Petrol	1987 To Fit Front Right
MOTO-GUZZI		1000 II	1000.0 Petrol	1988 To Fit Front Left
MOTO-GUZZI		1000 II	1000.0 Petrol	1989 To Fit Front Left
MOTO-GUZZI		1000 II	1000.0 Petrol	1990 To Fit Front Right
MOTO-GUZZI		1000 II	1000.0 Petrol	1991 To Fit Front Right
MOTO-GUZZI		1000 II	1000.0 Petrol	1992 To Fit Front Right
MOTO-GUZZI		1000 II	1000.0 Petrol	1993 To Fit Front Left
MOTO-GUZZI		1000 II	1000.0 Petrol	1994 To Fit Front Left
MOTO-GUZZI		1000 III	1000.0 Petrol	1984 To Fit Front Right
MOTO-GUZZI		1000 III	1000.0 Petrol	1985 To Fit Front Right
MOTO-GUZZI		1000 III	1000.0 Petrol	1986 To Fit Front Right
MOTO-GUZZI		1000 III	1000.0 Petrol	1987 To Fit Front Left
MOTO-GUZZI		1000 III	1000.0 Petrol	1988 To Fit Front Left
MOTO-GUZZI		1000 S E	1000.0 Petrol	1984 To Fit Rear Left
MOTO-GUZZI		1000 S E	1000.0 Petrol	1985 To Fit Front Right
MOTO-GUZZI		1000 S E	1000.0 Petrol	1986 To Fit Rear Left
MOTO-GUZZI		1000 S E	1000.0 Petrol	1987 To Fit Rear Left
MOTO-GUZZI		1000 S E	1000.0 Petrol	1988 To Fit Front Left
MOTO-GUZZI		1000 S E	1000.0 Petrol	1989 To Fit Rear Left
MOTO-GUZZI		1000 S E	1000.0 Petrol	1990 To Fit Front Right
MOTO-GUZZI		1000 S E	1000.0 Petrol	1991 To Fit Front Right
MOTO-GUZZI		1000 S E	1000.0 Petrol	1992 To Fit Front Right
MOTO-GUZZI		1000 S E	1000.0 Petrol	1993 To Fit Rear Left
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1983 To Fit Front Left
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1984 To Fit Front Left
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1985 To Fit Front Right
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1986 To Fit Front Right
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1987 To Fit Front Left
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1988 To Fit Front Right
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1989 To Fit Front Right
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1990 To Fit Front Right
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1991 To Fit Front Left
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1992 To Fit Front Right

MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1993 To Fit Front Left
MOTO-GUZZI		1000 SP KE	1000.0 Petrol	1994 To Fit Front Right
MOTO-GUZZI	850 Le Mans	I	850.0 Petrol	1976 To Fit Front Right
MOTO-GUZZI	850 Le Mans	I	850.0 Petrol	1977 To Fit Rear Left
MOTO-GUZZI	850 Le Mans	II	850.0 Petrol	1978 To Fit Front Right
MOTO-GUZZI	850 Le Mans	II	850.0 Petrol	1979 To Fit Rear Left
MOTO-GUZZI	850 Le Mans	II	850.0 Petrol	1980 To Fit Rear Left
MOTO-GUZZI	850 Le Mans	III	850.0 Petrol	1981 To Fit Front Right
MOTO-GUZZI	850 Le Mans	III	850.0 Petrol	1982 To Fit Front Right
MOTO-GUZZI	850 Le Mans	III	850.0 Petrol	1983 To Fit Front Right
MOTO-GUZZI	850 Le Mans	III	850.0 Petrol	1984 To Fit Front Left
MOTO-GUZZI	850 T		850.0 Petrol	1974 To Fit Front Left
MOTO-GUZZI	850 T3		850.0 Petrol	1975 To Fit Front Left
MOTO-GUZZI	850 T3		850.0 Petrol	1976 To Fit Rear Left
MOTO-GUZZI	850 T3		850.0 Petrol	1977 To Fit Rear Left
MOTO-GUZZI	850 T3		850.0 Petrol	1978 To Fit Front Left
MOTO-GUZZI	850 T3		850.0 Petrol	1979 To Fit Rear Left
MOTO-GUZZI	850 T4	T4	850.0 Petrol	1980 To Fit Rear Left
MOTO-GUZZI	850 T4	T4	850.0 Petrol	1981 To Fit Rear Left
MOTO-GUZZI	850 T4	T4	850.0 Petrol	1982 To Fit Rear Left
MOTO-GUZZI	850 T5	T5	850.0 Petrol	1983 To Fit Rear Left
MOTO-GUZZI	850 T5	T5	850.0 Petrol	1984 To Fit Rear Left
MOTO-GUZZI	850 T5	T5	850.0 Petrol	1985 To Fit Rear Left
MOTO-GUZZI	California	1000 II	1000.0 Petrol	1981 To Fit Rear Left
MOTO-GUZZI	California	1000 II	1000.0 Petrol	1982 To Fit Front Right
MOTO-GUZZI	California	1000 II	1000.0 Petrol	1983 To Fit Rear Left
MOTO-GUZZI	California	1000 II	1000.0 Petrol	1984 To Fit Front Left
MOTO-GUZZI	California	1000 II	1000.0 Petrol	1985 To Fit Front Left
MOTO-GUZZI	California	1000 II	1000.0 Petrol	1986 To Fit Front Left
MOTO-GUZZI	California	1000 II	1000.0 Petrol	1987 To Fit Front Right
MOTO-GUZZI	California	1000 III - EFI	1000.0 Petrol	1990 To Fit Rear Left
MOTO-GUZZI	California	1000 III - EFI	1000.0 Petrol	1991 To Fit Rear Left
MOTO-GUZZI	California	1000 III - EFI	1000.0 Petrol	1992 To Fit Front Right
MOTO-GUZZI	California	1000 III - EFI	1000.0 Petrol	1993 To Fit Front Right
MOTO-GUZZI	California	1000 III	1000.0 Petrol	1987 To Fit Front Right
MOTO-GUZZI	California	1000 III	1000.0 Petrol	1988 To Fit Front Right
MOTO-GUZZI	California	1000 III	1000.0 Petrol	1989 To Fit Rear Left
MOTO-GUZZI	California	1000 III	1000.0 Petrol	1990 To Fit Rear Left
MOTO-GUZZI	California	1000 III	1000.0 Petrol	1991 To Fit Rear Left
MOTO-GUZZI	California	1000 III	1000.0 Petrol	1992 To Fit Rear Left
MOTO-GUZZI	California	1000 III	1000.0 Petrol	1993 To Fit Front Right
MOTO-GUZZI	California	1100 Carb	1100.0 Petrol	1994 To Fit Rear Left
MOTO-GUZZI	California	1100 Carb	1100.0 Petrol	1995 To Fit Rear Left
MOTO-GUZZI	California	1100 Carb	1100.0 Petrol	1996 To Fit Front Left
MOTO-GUZZI	California	1100 Carb	1100.0 Petrol	1997 To Fit Front Right
MOTO-GUZZI	California	850 T5	850.0 Petrol	1983 To Fit Rear Left
MOTO-GUZZI	California	850 T5	850.0 Petrol	1984 To Fit Rear Left
MOTO-GUZZI	California	850 T5	850.0 Petrol	1985 To Fit Front Left
MOTO-GUZZI	California		850 850.0 Petrol	1975 To Fit Rear Left
MOTO-GUZZI	California		850 850.0 Petrol	1976 To Fit Rear Left
MOTO-GUZZI	California		850 850.0 Petrol	1977 To Fit Front Right
MOTO-GUZZI	California		850 850.0 Petrol	1978 To Fit Front Left
MOTO-GUZZI	California		850 850.0 Petrol	1979 To Fit Rear Left
MOTO-GUZZI	G5	V1000	1000.0 Petrol	1978 To Fit Front Left
MOTO-GUZZI	G5	V1000	1000.0 Petrol	1979 To Fit Rear Left
MOTO-GUZZI	G5	V1000	1000.0 Petrol	1980 To Fit Rear Left
MOTO-GUZZI	G5	V1000	1000.0 Petrol	1981 To Fit Front Left
MOTO-GUZZI	G5	V1000	1000.0 Petrol	1982 To Fit Front Left
MOTO-GUZZI	G5	V1000	1000.0 Petrol	1983 To Fit Front Left
MOTO-GUZZI	Strada		1000 1000.0 Petrol	1993 To Fit Rear Left
MOTO-GUZZI	Strada		1000 1000.0 Petrol	1994 To Fit Rear Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1985 To Fit Front Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1986 To Fit Front Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1987 To Fit Front Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1988 To Fit Front Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1989 To Fit Front Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1990 To Fit Front Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1991 To Fit Front Left
MZ MUZ	ETZ	125 150	125.0 Petrol	1992 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1985 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1986 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1987 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1988 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1989 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1990 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1991 To Fit Front Left
MZ MUZ	ETZ	250 300	250.0 Petrol	1992 To Fit Front Left

MZ MUZ	Fun		251 250.0 Petrol	1995 To Fit Front Left
MZ MUZ	Fun		251 250.0 Petrol	1996 To Fit Front Left
MZ MUZ	Saxon Tour	251 301	251.0 Petrol	1993 To Fit Front Left
MZ MUZ	Saxon Tour	251 301	251.0 Petrol	1994 To Fit Front Left
MZ MUZ	Saxon Tour	251 301	251.0 Petrol	1995 To Fit Front Left
MZ MUZ	Saxon Tour	251 301	251.0 Petrol	1996 To Fit Front Left
MZ MUZ	Saxon Tour	251 301	251.0 Petrol	1997 To Fit Front Left
MZ MUZ	Saxon Tour	251 301	251.0 Petrol	1998 To Fit Front Left
MZ MUZ	Saxon		125 125.0 Petrol	1993 To Fit Front Left
MZ MUZ	Saxon		125 125.0 Petrol	1994 To Fit Front Left
MZ MUZ	Saxon		125 125.0 Petrol	1995 To Fit Front Left
MZ MUZ	Saxon		125 125.0 Petrol	1996 To Fit Front Left
MZ MUZ	Saxon		125 125.0 Petrol	1997 To Fit Front Left
MZ MUZ	Saxon		150 150.0 Petrol	1995 To Fit Front Left
MZ MUZ	Saxon	500 All Models	500.0 Petrol	1993 To Fit Front Left
MZ MUZ	Saxon	500 All Models	500.0 Petrol	1994 To Fit Front Left
MZ MUZ	Saxon	500 All Models	500.0 Petrol	1995 To Fit Front Left
MZ MUZ	Saxon	500 All Models	500.0 Petrol	1996 To Fit Front Left
MZ MUZ	Saxon	500 All Models	500.0 Petrol	1997 To Fit Front Left
MZ MUZ	Saxon	500 All Models	500.0 Petrol	1998 To Fit Front Left
NORTON	Classic	Rotary	588.0 Petrol	1989 To Fit Front Right
NORTON	Interpol 2	Rotary	588.0 Petrol	1989 To Fit Rear Left
SVM SWM	350 XP Sahara		350.0 Petrol	1983 To Fit Front Left
TRIUMPH MERIDEN PRODUCED MACHINES	T140	Bonneville L.F. Harris Production Bike	140.0 Petrol	1985 To Fit Rear Right
TRIUMPH MERIDEN PRODUCED MACHINES	T140	Bonneville L.F. Harris Production Bike	140.0 Petrol	1986 To Fit Front Left
TRIUMPH MERIDEN PRODUCED MACHINES	T140	Bonneville L.F. Harris Production Bike	140.0 Petrol	1987 To Fit Rear Right
TRIUMPH MERIDEN PRODUCED MACHINES	T140	Bonneville L.F. Harris Production Bike	140.0 Petrol	1988 To Fit Rear Right
ZUNDAPP	KS 175		175.0 Petrol	1982 To Fit Front Left