

Make	Model	Sub-Model	Engine	Valves	BHP	Year	Fitment Details
BMW	R100	7 T	100.0 Petrol			1977 To Fit Front Right	
BMW	R100	7 T	100.0 Petrol			1978 To Fit Front Right	
BMW	R100	7 T	100.0 Petrol			1979 To Fit Front Left	
BMW	R100	7 T	100.0 Petrol			1980 To Fit Front Left	
BMW	R100	R	100.0 Petrol			1976 To Fit Front Right	
BMW	R100	R	100.0 Petrol			1977 To Fit Front Left	
BMW	R100	RS	100.0 Petrol			1976 To Fit Front Left	
BMW	R100	RS	100.0 Petrol			1977 To Fit Front Right	
BMW	R100	RS	100.0 Petrol			1978 To Fit Front Right	
BMW	R100	RS	100.0 Petrol			1979 To Fit Front Left	
BMW	R100	RS	100.0 Petrol			1980 To Fit Front Right	
BMW	R100	RT 1978-Sept 1980	100.0 Petrol			1978 To Fit Front Left	
BMW	R100	RT 1978-Sept 1980	100.0 Petrol			1979 To Fit Front Left	
BMW	R100	RT 1978-Sept 1980	100.0 Petrol			1980 To Fit Front Left	
BMW	R100	S R	100.0 Petrol			1976 To Fit Front Right	
BMW	R100	S R	100.0 Petrol			1977 To Fit Front Right	
BMW	R100	S R	100.0 Petrol			1978 To Fit Front Left	
BMW	R100	S R	100.0 Petrol			1979 To Fit Front Right	
BMW	R100	S R	100.0 Petrol			1980 To Fit Front Right	
BMW	R60	TIC R	600.0 Petrol			1978 To Fit Front Right	
BMW	R60	TIC R	600.0 Petrol			1979 To Fit Front Right	
BMW	R60	TIC R	600.0 Petrol			1980 To Fit Front Left	
BMW	R60	TIC R	600.0 Petrol			1981 To Fit Front Left	
BMW	R60	TIC R	600.0 Petrol			1982 To Fit Front Left	
BMW	R60 7	R	607.0 Petrol			1976 To Fit Front Right	
BMW	R60 7	R	607.0 Petrol			1977 To Fit Front Right	
BMW	R60 7	R	607.0 Petrol			1978 To Fit Front Left	
BMW	R60 7	R	607.0 Petrol			1979 To Fit Front Left	
BMW	R60 7	R	607.0 Petrol			1980 To Fit Front Left	
BMW	R75 6 75 7	R	75.0 Petrol			1973 To Fit Front Right	
BMW	R75 6 75 7	R	75.0 Petrol			1974 To Fit Front Left	
BMW	R75 6 75 7	R	75.0 Petrol			1975 To Fit Front Right	
BMW	R75 6 75 7	R	75.0 Petrol			1976 To Fit Front Left	
BMW	R75 6 75 7	R	75.0 Petrol			1977 To Fit Front Left	
BMW	R75 6 75 7	R	75.0 Petrol			1978 To Fit Front Left	
BMW	R75 6 75 7	R	75.0 Petrol			1979 To Fit Front Left	
BMW	R80	1977-Sept 1980	80.0 Petrol			1978 To Fit Front Left	
BMW	R80	1977-Sept 1980	80.0 Petrol			1979 To Fit Front Right	
BMW	R80	1977-Sept 1980	80.0 Petrol			1980 To Fit Front Right	
BMW	R80	Oct. 1980-1984	80.0 Petrol			1981 To Fit Front Left	
BMW	R80	Oct. 1980-1984	80.0 Petrol			1982 To Fit Front Right	
BMW	R80	Oct. 1980-1984	80.0 Petrol			1983 To Fit Front Left	
BMW	R80	Oct. 1980-1984	80.0 Petrol			1984 To Fit Front Left	
BMW	R80	R	80.0 Petrol			1977 To Fit Front Left	
BMW	R80	R	80.0 Petrol			1980 To Fit Front Right	
BMW	R80	TIC - 1978-Aug 1980	80.0 Petrol			1979 To Fit Front Right	
BMW	R80	TIC - 1978-Aug 1980	80.0 Petrol			1980 To Fit Front Right	
BMW	R80	TIC	80.0 Petrol			1978 To Fit Front Right	
BMW	R90 S	S	90.0 Petrol			1973 To Fit Front Right	

BMW	R90 S	S	90.0 Petrol	1974 To Fit Front Left
BMW	R90 S	S	90.0 Petrol	1975 To Fit Front Left
BMW	R90 S	S	90.0 Petrol	1976 To Fit Front Right
BMW	R90 6	R	906.0 Petrol	1973 To Fit Front Right
BMW	R90 6	R	906.0 Petrol	1974 To Fit Front Left
BMW	R90 6	R	906.0 Petrol	1975 To Fit Front Left
BMW	R90 6	R	906.0 Petrol	1976 To Fit Front Left