

Make	Model	Sub-Model	Engine	Valves	BHP	Year	Fitment Details
BMW	K 100	LT	1000.0 Petrol			1988	To Fit Front Right
BMW	K 100	LT	1000.0 Petrol			1989	To Fit Front Left
BMW	K 100	LT	1000.0 Petrol			1990	To Fit Front Left
BMW	K 100	LT	1000.0 Petrol			1991	To Fit Front Left
BMW	K 100	RS	1000.0 Petrol			1988	To Fit Front Right
BMW	K 100	RS	1000.0 Petrol			1989	To Fit Front Right
BMW	K 100	RT	1000.0 Petrol			1988	To Fit Front Left
BMW	K 100	RT	1000.0 Petrol			1989	To Fit Front Left
BMW	K 100 2		1002.0 Petrol			1988	To Fit Front Right
BMW	K 100 2		1002.0 Petrol			1989	To Fit Front Left
BMW	K 100 2		1002.0 Petrol			1990	To Fit Front Right
BMW	K 75	75-2	740.0 Petrol			1988	To Fit Front Left
BMW	K 75	75-2	740.0 Petrol			1989	To Fit Front Right
BMW	K 75	75-2	740.0 Petrol			1990	To Fit Front Right
BMW	K 75	75-2	740.0 Petrol			1991	To Fit Front Right
BMW	K 75	75-2	740.0 Petrol			1992	To Fit Front Right
BMW	K 75	75-2	740.0 Petrol			1993	To Fit Front Left
BMW	K 75	75-2	740.0 Petrol			1994	To Fit Front Right
BMW	K 75	75-2	740.0 Petrol			1995	To Fit Front Right
BMW	K 75	75-2	740.0 Petrol			1996	To Fit Front Right
BMW	K 75	75-S	740.0 Petrol			1990	To Fit Front Left
BMW	K 75	75-S	740.0 Petrol			1991	To Fit Front Right
BMW	K 75	75-S	740.0 Petrol			1992	To Fit Front Left
BMW	K 75	75-S	740.0 Petrol			1993	To Fit Front Right
BMW	K 75	75-S	740.0 Petrol			1994	To Fit Front Left
BMW	K 75	75-S	740.0 Petrol			1995	To Fit Front Right
BMW	K 75	75-S	740.0 Petrol			1996	To Fit Front Left
BMW	K 75	C	740.0 Petrol			1988	To Fit Front Right
BMW	K 75	C	740.0 Petrol			1989	To Fit Front Right
BMW	K 75	C	740.0 Petrol			1990	To Fit Front Left
BMW	K 75	RT	740.0 Petrol			1989	To Fit Front Left
BMW	K 75	RT	740.0 Petrol			1990	To Fit Front Right
BMW	K 75	RT	740.0 Petrol			1991	To Fit Front Right
BMW	K 75	RT	740.0 Petrol			1992	To Fit Front Left
BMW	K 75	RT	740.0 Petrol			1993	To Fit Front Left
BMW	K 75	RT	740.0 Petrol			1994	To Fit Front Right
BMW	K 75	RT	740.0 Petrol			1995	To Fit Front Right
BMW	K 75	RT	740.0 Petrol			1996	To Fit Front Left
BMW	K 75	S	740.0 Petrol			1988	To Fit Front Right
BMW	K 75	S	740.0 Petrol			1989	To Fit Front Left
BMW	K 75	S	740.0 Petrol			1990	To Fit Front Left
BMW	K 75	S	740.0 Petrol			1991	To Fit Front Right
BMW	K 75	S	740.0 Petrol			1992	To Fit Front Left
BMW	K 75	S	740.0 Petrol			1993	To Fit Front Right
BMW	K 75	S	740.0 Petrol			1994	To Fit Front Right
BMW	K 75	S	740.0 Petrol			1995	To Fit Front Left
BMW	K100	LT	100.0 Petrol			1988	To Fit Front Left
BMW	K100	LT	100.0 Petrol			1989	To Fit Front Left
BMW	K100	LT	100.0 Petrol			1990	To Fit Front Right
BMW	K100	LT	100.0 Petrol			1991	To Fit Front Left
BMW	K100	RS	100.0 Petrol			1988	To Fit Front Left
BMW	K100	RS	100.0 Petrol			1989	To Fit Front Right
BMW	K100	RT	100.0 Petrol			1988	To Fit Front Left
BMW	K100	RT	100.0 Petrol			1989	To Fit Front Right
BMW	K100 2		1002.0 Petrol			1988	To Fit Front Left
BMW	K100 2	Sept. 1988-1990	1002.0 Petrol			1989	To Fit Front Left
BMW	K100 2	Sept. 1988-1990	1002.0 Petrol			1990	To Fit Front Left

BMW	K75	75-2 Aug. 1990	75.0 Petrol	1990 To Fit Front Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1991 To Fit Front Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1992 To Fit Front Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1993 To Fit Front Left
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1994 To Fit Front Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1995 To Fit Front Right
BMW	K75	75-2 Aug. 1990	75.0 Petrol	1996 To Fit Front Left
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1988 To Fit Front Left
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1989 To Fit Front Right
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1990 To Fit Front Left
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1991 To Fit Front Right
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1992 To Fit Front Right
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1993 To Fit Front Left
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1994 To Fit Front Right
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1995 To Fit Front Left
BMW	K75	75-2 Sept. 1988-1996	75.0 Petrol	1996 To Fit Front Right
BMW	K75	C Sept. 1988	75.0 Petrol	1988 To Fit Front Left
BMW	K75	C Sept. 1988	75.0 Petrol	1989 To Fit Front Right
BMW	K75	C Sept. 1988	75.0 Petrol	1990 To Fit Front Left
BMW	K75	RT	75.0 Petrol	1989 To Fit Front Left
BMW	K75	RT	75.0 Petrol	1990 To Fit Front Right
BMW	K75	RT	75.0 Petrol	1991 To Fit Front Right
BMW	K75	RT	75.0 Petrol	1992 To Fit Front Right
BMW	K75	RT	75.0 Petrol	1993 To Fit Front Left
BMW	K75	RT	75.0 Petrol	1994 To Fit Front Right
BMW	K75	RT	75.0 Petrol	1995 To Fit Front Right
BMW	K75	RT	75.0 Petrol	1996 To Fit Front Left
BMW	K75	S	75.0 Petrol	1988 To Fit Front Right
BMW	K75	S	75.0 Petrol	1989 To Fit Front Left
BMW	K75	S	75.0 Petrol	1990 To Fit Front Right
BMW	K75	S	75.0 Petrol	1991 To Fit Front Right
BMW	K75	S	75.0 Petrol	1992 To Fit Front Left
BMW	K75	S	75.0 Petrol	1993 To Fit Front Right
BMW	K75	S	75.0 Petrol	1994 To Fit Front Left
BMW	K75	S	75.0 Petrol	1995 To Fit Front Left
BMW	R 100	RS	1000.0 Petrol	1988 To Fit Front Right
BMW	R 100	RS	1000.0 Petrol	1989 To Fit Front Right
BMW	R 100	RS	1000.0 Petrol	1990 To Fit Front Left
BMW	R 100	RS	1000.0 Petrol	1991 To Fit Front Right
BMW	R 100	RS	1000.0 Petrol	1992 To Fit Front Left
BMW	R 100	RT	1000.0 Petrol	1988 To Fit Front Right
BMW	R 100	RT	1000.0 Petrol	1989 To Fit Front Left
BMW	R 100	RT	1000.0 Petrol	1990 To Fit Front Right
BMW	R 100	RT	1000.0 Petrol	1991 To Fit Front Right
BMW	R 100	RT	1000.0 Petrol	1992 To Fit Front Right
BMW	R 100	RT	1000.0 Petrol	1993 To Fit Front Right
BMW	R 100	RT	1000.0 Petrol	1994 To Fit Front Left
BMW	R 100	RT	1000.0 Petrol	1995 To Fit Front Right
BMW	R 80	R 80 RT	800.0 Petrol	1988 To Fit Front Left
BMW	R 80	R 80 RT	800.0 Petrol	1989 To Fit Front Left
BMW	R 80	R 80 RT	800.0 Petrol	1990 To Fit Front Right
BMW	R 80	R 80 RT	800.0 Petrol	1991 To Fit Front Right
BMW	R 80	R 80 RT	800.0 Petrol	1992 To Fit Front Left
BMW	R 80	R 80 RT	800.0 Petrol	1993 To Fit Front Left
BMW	R 80	R 80 RT	800.0 Petrol	1994 To Fit Front Left
BMW	R 80	R 80 RT	800.0 Petrol	1995 To Fit Front Right
BMW	R100	RS	100.0 Petrol	1988 To Fit Front Right
BMW	R100	RS	100.0 Petrol	1989 To Fit Front Right

BMW	R100	RS	100.0 Petrol	1990 To Fit Front Left
BMW	R100	RS	100.0 Petrol	1991 To Fit Front Left
BMW	R100	RS	100.0 Petrol	1992 To Fit Front Left
BMW	R100	RT Sept. 1988-Aug. 1989	100.0 Petrol	1988 To Fit Front Left
BMW	R100	RT Sept. 1988-Aug. 1989	100.0 Petrol	1989 To Fit Front Left
BMW	R100	RT Sept. 1989-1995	100.0 Petrol	1989 To Fit Front Right
BMW	R100	RT Sept. 1989-1995	100.0 Petrol	1990 To Fit Front Right
BMW	R100	RT Sept. 1989-1995	100.0 Petrol	1991 To Fit Front Left
BMW	R100	RT Sept. 1989-1995	100.0 Petrol	1992 To Fit Front Right
BMW	R100	RT Sept. 1989-1995	100.0 Petrol	1993 To Fit Front Left
BMW	R100	RT Sept. 1989-1995	100.0 Petrol	1994 To Fit Front Left
BMW	R100	RT Sept. 1989-1995	100.0 Petrol	1995 To Fit Front Right
BMW	R80	R 80 RT	80.0 Petrol	1988 To Fit Front Right
BMW	R80	R 80 RT	80.0 Petrol	1989 To Fit Front Left
BMW	R80	R 80 RT	80.0 Petrol	1990 To Fit Front Left
BMW	R80	R 80 RT	80.0 Petrol	1991 To Fit Front Right
BMW	R80	R 80 RT	80.0 Petrol	1992 To Fit Front Right
BMW	R80	R 80 RT	80.0 Petrol	1993 To Fit Front Right
BMW	R80	R 80 RT	80.0 Petrol	1994 To Fit Front Left
BMW	R80	R 80 RT	80.0 Petrol	1995 To Fit Front Right
QUADZILLA	Buzz 50		50.0 Petrol	2004 To Fit Rear Right
QUADZILLA	Buzz 50		50.0 Petrol	2005 To Fit Rear Left
QUADZILLA	RL 500 Buggie		500.0 Petrol	2008 To Fit Front Right
QUADZILLA	RL 500 Buggie		500.0 Petrol	2009 To Fit Rear Left