



# INSTRUCTIONS

- DELETE THE BOLTS (IN THE MIDDLE) AND THE RUBBER! (RIGHT CORNER)
- AND DRILL THE HOLES TO 8,5 MM



- SO YOU GET THIS: (PICTURE BELOW!)
- AND DRILL 2 NEW HOLES ON THE SIDES OF THE LAMP FOR THE WIRING, SO THE WIRES CAN GO LEFT AND RIGHT TO THE OTHER LAMPS





# INSTRUCTIONS

- PLACE THE CHROME RING IN PLACE



- NOW YOU CAN PLACE THE LIGHT-UNIT OVER THE BOLTS AND TIGHTEN IT!



# INSTRUCTIONS



- NOW PLACE THE FITTING WITH THE WIRES AND PLACE TO GLASS!





# INSTRUCTIONS



- AND DONE! ✓