







Disclaimer

Rebelmoto accepts no liability for damage, injury or any legal responsibility incurred directly or indirectly from the use or installation of this product. The use and installation of this product is at user's own risk.

If you are installing a rebelmoto triple tree, the extra 8mm hole can be used to run wiring through the risers.

When installing the upper part of the risers, make sure to tighten the M8 stainless bolts evenly. The cap between the upper and lower part has to be the same at the front and the back.

Torque bolts to: 22Nm