




Headrest Adjustment



Headrest Adjustment



Lumbar Adjustment



Armpad Adjustment



LA VELLA

user guide



Armpad Sliding




Tension Adjustment



Sliding Adjustment

Gaslift Adjustment



Locking Adjustment