

SIZE SPECS.


MEN

HOW TO MEASURE

HOODED ZIP:

Width: measure from the left to the right under the arms (A)

Length: measure from the highest shoulder point to the bottom of the hooded zip (B)



SIZE	S	M	L	XL	XXL	XXXL
LENGTH (A)	53	56	59	62	65	68
LENGTH (B)	68	70	72	74	76	78