

**ROFUN RACING**

[www.rofunracing.com](http://www.rofunracing.com)




# **Instructions**

**1/5 GAS OFF ROAD CAR**



**RTR** **2-STROKE** **2.4GHZ**





欢迎使用本公司 BAHA 系列产品。此产品采用高品质材料生产，设计新颖，操作有趣。仔细阅读说明将有助于您更加容易的操控此产品。我们愿与您分享操控的乐趣与刺激。

Welcome to use our company's BAHA series products. It's produced with high-quality materials, with novel design and interesting operation. Reading the instructions carefully will help you control this product more easily. We would like to share the joy and excitement with you.



**Caution**

不按照此说明操作有可能会损害整车或零配件，甚至导致人身伤害。  
If you don't follow the manual to run the vehicle, which may cause the probability of truck damage, collateral spare parts damage and even serious bodily injury.



**Attention**

不按照此说明操作有可能伤害到自己或他人。  
Failure to follow this instruction may cause the hurt to yourself and others.



**Caution**

- 为了防止造成人身伤害或财产损失，操控此车时请特别注意。此车采用可燃性混合汽油燃料，最高速度可达70km/h。  
To prevent any serious personal injury and/or damage to property, please be responsible when operating this vehicle. This vehicle uses inflammable mixed gasoline. Max running speed of this vehicle would reach 70km/h.
- 14岁以下儿童、禁止玩耍。  
Children are forbidden to play under 14 years old.

#### 发动机安全操作指南 Engine Guidelines for safe handling




- 请加入汽油与两冲程机油混合燃料。  
Please use a mixture of gasoline and 2stroke oil for fuel.
- 请勿在有火苗和烟区操控此车或加油。  
Never operate your vehicle near open flames. Never smoke while operating your vehicle or while handling fuel.
- 加油时保持水平位置，远离火苗、火源、高温等地方。  
When fueling the vehicle, please be sure to make this vehicle be in a well horizontal site, and away from flame and high temperature area.
- 此发动机仅用汽油与两冲程机油混合作为燃料，其它燃料均不可使用。  
Only use a mixture of gasoline and twocycle oil for fuel in this vehicle engine. Do not use other fuel.
- 汽油易然有毒，请注意安全。  
Please be safe because gasoline is inflammable and poisonous.
- 操控过程中有些部件温度很高，在未冷却之前请勿触摸。  
Do not touch the engine and muffler as they can become extremely hot during use.
- 使用完毕后将油箱的剩余燃料清理掉。  
Please clean the fuel tank after running this vehicle.
- 操控时远离儿童。  
Please be away from children when running this vehicle.

## 装箱清单 *Packing List*

- RC整车 RC assembled car
- 遥控/接收机 Transmitter/Receiver
- 接收机电池 Receiver battery
- 工具/说明书 Tool/Instruction
- 充电器 Charger


公司可能会对箱内配件做其它的调整，不再另行通知，一切以收到的实物为准。  
ROFUN might do some changes on accessories, which would not be informed. Please just subject to all what you get.



遥控设备或其它配件会出现更新与图片不符，恕不另行通知，解释权归公司所有。  
Transmitter equipment or other spare parts might be updated in future, which maybe not same as current picture. We won't make extra informing. ROFUN own the reserved explanation right for all instructions and terms.


## 配备工具 *Fitted Tools*

- |                      |                      |                            |                             |                               |                               |                      |
|----------------------|----------------------|----------------------------|-----------------------------|-------------------------------|-------------------------------|----------------------|
| 六角扳手<br>Allen wrench | 十字套筒<br>Cross Wrench | 火花塞套筒<br>Spark plug wrench | 金属六角扳手<br>Metal Hexagon key | 塑料六角扳手<br>Plastic Hexagon key | 燃油配比壶<br>Mixed fuel ratio can | 轮毂扳手<br>Wheel Wrench |
|----------------------|----------------------|----------------------------|-----------------------------|-------------------------------|-------------------------------|----------------------|




## 自备工具 *Self-prepared Tools*



- 一字螺丝刀  
Screwdriver




- AA电池  
AA Battery



- 燃油壶  
Gasoline





电池完全性充放电，  
可延长电池的寿命。


Battery useful life can be extended longer  
if charging or releasing power of battery  
is enough .



**Caution**

车子运转过程中，发动机和排气管温  
度很高，在未冷却之前请勿触摸。  
Please don't touch engine or exhaust  
pipe before they are cold, because  
they will be extremely hot during  
running of this vehicle .

充电器插入电源插座  
Plug the charger in the  
power socket





**Caution**

- 请勿使用其它充电器
- 充电时间约为6小时
- 此充电器勿给其它电池充电
- 电池远离儿童及水源

- Don't use other charger
- Charging time need about 6 hours
- Don't allow to use this charger to charge other battery
- Battery should be far away from Children and water














## 车辆启动 Vehicle Starting And Running

启动顺序      发射机      ⇨ 接收机      ⇨ 发动机  
 Startup sequence    Transmitter power    ⇨ Receiver power    ⇨ Engine

### 启动发动机 Priming The Engine

发动机必须吸入燃油才可以成功启动。按压吸油气囊，直到你可以看到燃料从回油管返回到油箱内。  
 The engine must be primed before it can be successfully started. Push the primer bulb until you can see fuel in the yellow return tube.

### 启动程序：冷启动 Starting Procedure: Cold Engine



1. 设置阻风阀手柄，如步骤A所示。  
Set choke lever as shown in Step A
2. 连续拉动启动器拉线（约3次），直到你听到发动机几乎启动，然后停止。  
Pull start cord in a quick continuous motion (about 3 times) until you hear the engine almost start, then stop.
3. 小心不要让燃料涌入发动机。不拉超过50cm/20英寸，否则会破坏拉动启动装配。  
Be careful not to flood the engine with fuel. Do not pull more than 50 cm/20 inch. or you can damage the pull start assembly.
4. 设置阻风阀手柄，如步骤B所示。  
Set the choke lever as shown in Step B.
5. 拉动手拉启动器，启动发动机。  
Pull the starter cord start the engine.
6. 发动机应该在6次拉动内启动。  
The engine should start within 6 pulls.

### 启动程序：热启动 Starting Procedure: Hot Engine

1. 设置阻风阀手柄，如步骤B所示。  
Set the choke lever as shown in Step B.
2. 连续快速拉动发动机启动手拉线。发动机应该在6次拉动内启动。  
Pull the starter cord in a quick continuous motion to start the engine. The engine should start within 6 pulls.

