





STEP 1





# 70125 装配分解图 Assembly Exploded Views


**STEP 2**





# 70125 装配分解图 Assembly Exploded Views


## STEP 3





# 70125 装配分解图 Assembly Exploded Views


## STEP 4





# 70125 装配分解图 Assembly Exploded Views


## STEP 5





# 70125 装配分解图 Assembly Exploded Views

## STEP 6



序号	零件号	名称	数量
1	8719501	LT 电调固定板	1
2	8719502	LT 电调固定座 1	1
3	8719503	LT 电调固定座 2	1
4	8719504	LT 70125 电机固定座	1
5	8719505	LT 70125 电机尾座	1
6	8719506	LT 电机风扇板	1
7	8719507	LT 电池左托板	1
8	8719508	LT 电池左固定杆	1
9	8719509	LT 电池右固定杆	1
10	8719510	LT 电池右托板	1
11	8719511	LT 电池板支撑杆	4
12	8719305	LT 电车舵机架	1
13	8719306	LT 电车舵机架盖	1
14	8714703	电机齿 斜齿 (19T)	1
15	151039	发动机固定件	4
16	68012	内六角沉头螺钉 M5×16	4
17	68022	内六角沉头自攻螺钉 ST4×16	4
18	68025	顶丝 M3×3	1
19	68053	内六角沉头自攻螺钉 ST4×18	4
20	68056	R形插销 (小)	1
21	68159	内六角沉头螺钉 M4×12	18
22	68103	内六角圆柱头螺钉 M4×12	20
23	68137	顶丝 M6×6	1