# ULTRAMAR



## PVC PARTYTENT CLEANER

PVC Party Tent Cleaner is biodegradable. This strong cleanser cleans every party tent and stretch tent. It's particularly well suited to PVC and PE. It removes dirt, such as black deposits, grease, oil, grass, and nicotine. Highly concentrated. Can be diluted as desired.



Size	1 litre
EAN:	8716462000060
SKU:	CL-PT-01000-0060

### "We use this cleaner for all of our party tents." - (REVIEW) Jeroen Brouwer

- Is your party tent dirty and in need of a thorough cleaning?
- That's no problem for this strong cleaner.
- It removes dirt, like black deposits, rain streaking, grease, oil, grass, and nicotine.
- It's biodegradable, so it's safe to use anywhere.
- This party tent cleaner has been specially developed by Ultramar.



### PVC PARTYTENT CLEANER

#### Suitable for:

- PVC Party Tent
- Pagoda tent
- Folding tent
- Star tent
- Deck screens

- Stretch tent
- Festival marquee
- Frame tent
- Storage tent


### Instructions for PVC Party Tent Cleaner:

PVC Party Tent Cleaner is highly concentrated. It can be diluted as desired. Dilution depends on the nature and degree of staining. Heavy staining = use undiluted. Mild staining = dilute with water up to 1:30.

- 1. Apply with a sponge, mop, brush, or spray.
- 2. Brush away dirt.
- 3. Let it sit for about 10 minutes.
- 4. Do not let it dry.
- 5. Then rinse with plenty of water.
- 6. If necessary, repeat the treatment

#### Tips:

Is there still visible dirt after cleaning? Then use Ultramar Power Cleaner for stubborn stains.



"The fabric is completely clean and waterproof again. Great explanation. Also about further maintenance. Ultramar is Top! Raymond"

**ULTRAMARXL.COM**