
6S10 6S20 6S30 6S11 6S21

MIYOTA



Battery consumption could be minimum by pulling out the stem


Balance Weight

Minute 1.00 Chrono Second 0.40 Small 0.04

Clearance

<µN.m>

Clearance changes subject to the glass, case structure, and the length of the hand.



Original **Package**


200pcs

Time measurement


Accuracy

The unit (gate) time of measurement must be set at "10 sec." and the measurement must be performed in the form of complete watch.

10 sec 10 sec



Reset the chronograph












7 Date

High Hand Standard



Setting the Time

DO NOT set Date between

9:00pm - 1:00am

Set CHRONOGRAPH hands to reset

Push A or B to set the hands to the zero position. The chronograph hands can be advanced rapidly by continuously pressing button.

A for the Center Chronograph Second hand, B for 1/20 hands