

# Mounting instructions Nuki Keypad



The Nuki Keypad is mounted on the outside of your front door by gluing it to the door frame or screwing it to the front of the house. The Keypad can be assembled and used by anyone in just a few minutes. Two button cells power the Keypad, eliminating the need to connect wires or cables. The Keypad must be within Bluetooth range of the Smart Lock.

The Keypad can be used with any Nuki Smart Lock. Keypad management is done using the Nuki app.

---

## Stick Keypad to the door frame


- 1) Clean the door frame so that it is free of dirt and grease.
- 2) Remove the adhesive backing from the back of the Keypad.
- 3) Fix the keypad to the desired position on the door frame.
- 4) Open the Nuki App on your smartphone and set up your Nuki Keypad with it. Open the Nuki App menu and choose “Manage Keypad”.



**1.**



**2.**



**3.**



**4.**

## Screw Keypad to the wall

- 1) Open the case of the Nuki Keypad by applying pressure to the bottom of the Keypad and pulling it from the back plate.
- 2) Mount the back plate of the Nuki Keypad to the wall. Use the enclosed mounting material. Simply screw through the silicone covers at the inside of the two holes. The silicone covers

serve as waterproof seals to prevent water from getting into the Keypad case.

3) Then close the case of the Keypad so that the outer silicone cover seals tightly at all edges.

4) Open the Nuki App on your smartphone and set up your Nuki Keypad with it. Open the Nuki App menu and choose “Manage Keypad”.

## Setup Nuki Keypad

The setup and administration of the Nuki Keypad is done via the **Nuki app**. Open the Nuki app and select “Manage Keypad” from the menu. Follow the instructions in the Nuki app to set up the Keypad, configure the Keypad settings or pair a Smart Lock with the Keypad.



the Nuki Keypad has been designed to be **compatible with the entire Nuki product range**. You can use your Keypad with the Smart Lock. The two devices communicate with each other via Bluetooth, which is why the Keypad can also be used offline (without an internet connection and Nuki Bridge). Your Keypad can only be paired with one Smart Lock. Multiple Smart Locks require the use of multiple Keypads.

During the initial setup of the Nuki Keypad, a **6-digit security code** must be set up to protect your Keypad from unauthorized access. The security code must then be entered every time you want to configure the settings of the Keypad or if you want to pair another Smart Lock.

After setting up your Keypad, you can create up to **99 individual entry codes** with the Nuki app (in the Smart Lock user management). With the Nuki Bridge this even works from afar. You decide which permissions each user receives. Thanks to the Nuki app’s activity log, you can always keep track of who’s entering your home.

In User management tap Access Codes, Add an Access Code, Choose your Code, and give it a name. You can now limit the access and or share the access code with the user via your smartphone message options like; e-mail, text message, whatsapp, etc.

You can always deactivate, change or delete codes you made.

Remark; You do not see the Keypad in the Connection Status