

SIEMENS



SAX.., SAY..



SAV..



SAL..

Acvatix™ Actuators SAX.., SAY.., SAV.., SAL.. for valves Basic Documentation

Siemens Switzerland Ltd
Building Technologies Division
International Headquarters
Gubelstrasse 22
6301 Zug
Switzerland
Tel. +41 41-724 24 24
www.siemens.com/sbt

© Siemens Switzerland Ltd, 2010
Subject to change

Contents


1	About this documentation.....	5
1.1	Navigation / Quick access	5
1.2	Revision history	6
1.3	Reference documents.....	6
1.4	Before you start	6
1.4.1	Trademarks	6
1.4.2	Copyright.....	7
1.4.3	Quality assurance	7
1.4.4	Document use / request to the reader	7
1.5	Scope of this documentation.....	7
2	Engineering.....	8
2.1	Product description	8
2.2	Use.....	9
2.3	Type summary	9
2.3.1	Stroke actuators.....	9
2.3.2	Stroke actuators – combi valves.....	10
2.3.3	Rotary actuators	10
2.4	Ordering	11
2.5	Equipment combinations.....	12
2.5.1	Stroke actuators – 3-port valves.....	12
2.5.2	Stroke actuators – 2-port valves.....	14
2.5.3	Stroke Acutuators – combi valves	16
2.5.4	Rotary actuators – slipper and butterfly valves	16
2.6	Accessories	17
2.6.1	Electrical accessories	17
2.6.2	Mechanical accessories.....	17
2.7	Product replacements	18
2.7.1	Stroke actuators SQX.. to SAX.....	18
2.7.2	Rotary actuators SQL.. to SAL.....	18
2.7.3	Electrical accessories	19
2.8	Spare parts.....	20
2.9	Sizing	20
2.9.1	Parallel operation of actuators.....	20
2.9.2	Permissible cable lengths and wire cross-sectional areas.....	21
2.10	Warranty	22
3	Handling.....	23
3.1	Mounting and installation	23
3.1.1	Mounting positions.....	23
3.1.2	Fitting stroke actuators to seat valves VVF.. / VXF.. or VVG.. / VXG.....	23
3.1.3	Avoid missaligment on V_G41 valves with fittings.....	24
3.1.4	Fitting rotary actuators to butterfly valves VKF41.....	25
3.1.5	Fitting rotary actuators to slipper valves VBF21.....	27
3.1.6	Fitting rotary actuators to butterfly valves VKF46.....	30
3.1.7	Fitting rotary actuators to butterfly valves VKF45.....	31
3.1.8	Fitting accessories	33
3.1.9	Wiring (installation)	40
3.2	Commissioning and operation.....	42
3.2.1	Function check and Calibration	42
3.2.2	Maintenance.....	44
3.2.3	Disposal	44

4	Functions and control	45
4.1	3-position control	45
4.1.1	Combination with RVD.. controller for direct domestic hot water distribution by heat exchanger	47
4.2	Modulating control	48
4.3	Function module AZX61.1.....	49
4.3.1	Sequence control (signal adaptation)	49
4.3.2	Changeover of acting direction.....	51
4.4	Positioning signal and flow characteristic selection.....	52
4.5	Acting direction and flow characteristic.....	53
4.6	Position Feedback U.....	53
4.7	Position control with ClosedPosition-Synchronisation.....	54
4.7.1	ClosedPosition-Synchronisation.....	54
4.8	Calibration	56
4.9	Signal priorities.....	56
4.10	Detection of valve seat.....	57
4.11	Detection of foreign bodies	57
4.12	Forced control Z	58
4.13	Technical and mechanical design.....	59
4.13.1	Transmission of power	59
4.13.2	Coupling	60
4.13.3	Manual adjuster	60
4.13.4	Indicators.....	61
4.13.5	Electrical accessories	62
4.13.6	Mechanical accessories.....	63
5	Technical data.....	64
6	Connection diagrams and dimensions.....	67
6.1	Internal diagrams.....	67
6.2	Connection terminals	68
6.2.1	Actuators	68
6.2.2	Electrical accessories	68
6.3	Connection diagrams.....	69
6.4	Dimensions.....	70
6.4.1	Stroke actuators	70
¹⁾	SAX..U: 1.850 kg	70
6.4.2	Rotary actuators	71
7	Revision numbers.....	72
8	Glossary.....	73
8.1	Symbols	73
8.2	Terms	73

1 About this documentation

1.1 Navigation / Quick access

Information about a specific actuator is provided throughout the document. The structure of chapters 2 to 4 is as follows:



4040Z228en

Quick access to important information including reference to pages:

Product no.	2 Engineering		3 Handling		4 Function and control		
	Equipment combinations	Accessories	Calibration	Accessories (mounting)	Control	Calibration	Accessories
SAX31.00	Page 12	Page 17	-	Page 33-39	Page 45-46	-	Page 62
SAX31.03			Page 42		Page 48	Page 53	
SAX61.03 ¹⁾			-		Page 45-46	-	
SAV61.00U ¹⁾			-		Page 45-46	-	
SAX81.00 ¹⁾			-	Page 33-39	Page 45-46	-	
SAX81.03 ¹⁾			-		Page 48	Page 53	
SAX81.03U ¹⁾			-		Page 45-46	-	
SAV31.00	Page 12	Page 17	-	Page 33-39	Page 45-46	-	Page 62
SAV61.00			Seite 42		Page 48	Page 53	
SAV61.00U			-		Page 45-46	-	
SAV81.00			-	Page 33-39	Page 45-46	-	
SAV81.00U			-		Page 48	Page 53	
SAL31.00T10	Page 12	Page 17	-	Page 33-39	Page 45-46	-	Page 62
SAL31.00T20			-		Page 48	Page 53	
SAL31.00T40			-		Page 45-46	-	
SAL31.03T10			-		Page 45-46	-	
SAL61.00T10 ¹⁾			-		Page 45-46	-	
SAL61.00T20 ¹⁾			Page 42	Page 33-39	Page 48	Page 53	
SAL61.00T40 ¹⁾			-		Page 45-46	-	
SAL61.03T10 ¹⁾			-		Page 45-46	-	
SAL81.00T10 ¹⁾			-	Page 33-39	Page 45-46	-	
SAL81.00T20 ¹⁾			-		Page 48	Page 53	
SAL81.00T40 ¹⁾			-		Page 45-46	-	
SAL81.03T10 ¹⁾			-	Page 33-39	Page 45-46	-	
SAY31P03			-		Page 48	Page 53	
SAY61P03			-		Page 45-46	-	
SAY61.03U			-		Page 45-46	-	
SAY81P03			-		Page 45-46	-	
SAY81.03U			-	Page 33-39	Page 45-46	Page 53	Page 62

¹⁾ These types of actuator are UL-listed versions

Note

Glossary and Index are arranged at the end of the document.

1.2 Revision history

Revision	Date	Changes	Chapter
First edition	16.07.2010	-	-
2.0	2010-12-12	Rotary actuator SAL..T10 integrated	
		Mounting and installation of butterfly valves and slipper valves corrected and expanded	3.1
		New chapter „Position feedback U“	4.6
		Technical data corrected	5
2.1	2011-09-14	V..F53.. valves added	2.5
		SAL.T20 rotary actuators added	1.1, 1.2, 2.3, 2.4, 2.5, 2.6, 3, 3.1, 4.12, 5, 7
3	2012-09-12	Corrections regarding SAX..Series „G“ VVF53.50-40K valve added	2.4, 4.1, 4.7, 4.13, 5, 6.4
3.1	2013-12-17	SAL..T40 is added	...
3.2	2014-11-20	Supplemented with new valves V..F22, V..F32.., V..F42..	1.1, 1.3, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 3.1, 4.1, 4.3, 4.4 4.13, 5, 6.1, 6.4, 7
		Supplemented with actuators SAV..	1.1, 1.3, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 2.8, 4.1, 4.4, 4.7, 4.13, 5, 6.4, 7
3.3	2015-10-26	Supplemented with actuators SAY..P..	Various
3.4	2016-10-04	Actualization of headings with SAY.., added SAY.. to information on content and accessories	Various

1.3 Reference documents

Type of document	SAX..	SAV..	SAY..	SAL..
Data Sheet	N4501, N4509, Q4501	N4503, N4510	A6V10628469	N4502
	-	-	-	ASK31N: M4502.1 ASK33N: M4502.2 ASK35N: M4502.3
Mounting Instructions	ASC..: M4040.1 ASZ7.5/..: M4040.2 AZX61..: M4040.3	ASK39..: M4040.3 ASZ6.6: M4501.1	-	-
CE Declaration of Conformity	AC 230 V AC/DC 24 V	T4501X1 T4501X2	T4503X1 T4503X2	A5W00000333 A5W00000333
Environmental Declaration	E4501	E4503	7173310559B	E4502

1.4 Before you start

1.4.1 Trademarks

The table below lists the third-party trademarks used in this document and their legal owners. The use of trademarks is subject to international and domestic provisions of the law.

Trademarks	Legal owner
Acvatix™	Siemens Switzerland Ltd

All product names listed in the table are registered (®) or not registered (™) trademarks of the owner listed in the table. We forgo the labeling (e.g. using the symbols ® and ™) of trademarks for the purposes of legibility based on the reference in this section.

1.4.2 Copyright

This document may be duplicated and distributed only with the express permission of Siemens, and may be passed on only to authorized persons or companies with the required technical knowledge.

1.4.3 Quality assurance

These documents were prepared with great care.

- The contents of all documents are checked at regular intervals
- All necessary corrections are included in subsequent versions
- Anpassungen bzw. Documents are automatically amended as a consequence of modifications and corrections to the products described

Please make sure that you are aware of the latest document revision date.

If you find lack of clarity while using this document, or if you have any criticisms or suggestions, please contact the product manager in your nearest branch office.

The addresses of the Siemens regional companies are available at
www.siemens.com/acvatix.

1.4.4 Document use / request to the reader

Before using our products, it is important that you read the documents supplied with or ordered at the same time as the products (equipment, applications, tools etc.) carefully and in full.

We assume that persons using our products and documents are authorized and trained appropriately and have the technical knowledge required to use our products as intended.

More information on the products and applications is available:

- On the intranet (Siemens employees only) at
<https://workspace.sbt.siemens.com/content/00001123/default.aspx>.
- From the Siemens branch office near you www.siemens.com/acvatix or from your system supplier.
- From the support team at headquarters fieldsupport-zug.ch.sbt@siemens.com if there is no local point of contact.

Siemens assumes no liability to the extent allowed under the law for any losses resulting from a failure to comply with the aforementioned points or for the improper compliance of the same.

1.5 Scope of this documentation


This document shall serve as a source of knowledge. In addition to basic information, it provides general technical information about the actuators used in HVAC plants. It is also targeted at engineering staff, HVAC electrical planners, system integrators and service engineers and provides all information required for planning work, correct installation, commissioning and service.

2 Engineering


2.1 Product description

The line of large actuators is comprised of stroke actuators SAX.., SAY.., SAV.. and rotary actuators SAL..

Mechanical design



Components



2.2 Use

SAX.., SAV..

For use in connection with Siemens 2-port or 3-port valves with 20/40 mm stroke, as control or shutoff valves for HVAC plants.

SAY..

For the operation of Siemens combi valves of type VPI46.40F9.5Q and VPI46.50F12Q with 15 mm stroke as control valves in ventilation, air conditioning, and district heating systems.

SAL..

For use in connection with Siemens butterfly or slipper valves, as control or shutoff valves for HVAC plants.

Note

When using the actuators outdoors, weather shield ASK39.1 must be fitted.

2.3 Type summary

2.3.1 Stroke actuators

Product no.	Stock no.	Stroke	Pos. force	Operating voltage	Positioning signal	Spr. ret. time	Pos. time	LED	Manual adjuster	Extra functions	
SAX31.00	S55150-A105	20 mm	800 N	AC 230 V	3-position	-	120 s	-	Press and fix	-	
SAX31.03	S55150-A106				DC 0...10 V DC 4...20 mA 0...1000 Ω		30 s	✓		Position feedback, forced control, change of characteristic	
SAX61.03 SAX61.03U	S55150-A100 S55150-A100-A100			AC 24 V /DC 24 V	3-position		120 s	-		-	
SAX81.00	S55150-A102						30 s	-		-	
SAX81.03 SAX81.03U	S55150-A103 S55150-A103-A100	40 mm	1600 N	AC 230 V	3-position	-	120 s	-	Press and fix	-	
SAV31.00	S55150-A112				DC 0...10 V DC 4...20 mA 0...1000 Ω			✓		Position feedback, forced control, change of characteristic	
SAV61.00 SAV61.00U	S55150-A110 S55150-A110-A100			AC 24 V /DC 24 V	3-position		-	-		-	
SAV81.00 SAV81.00U	S55150-A111 S55150-A111-A100							-			

SAV..: This product line of actuators might not be available in all countries. Please talk to your local contact or consult your local internet pages of www.buildingtechnologies.siemens.com.

2.3.2 Stroke actuators – combi valves

Product no.	Stock no.	Stroke	Pos. force	Operating voltage	Positioning signal	Spr. ret. time	Pos. time	LED	Manual adjuster	Extra functions
SAY31P03	S55150-A132	15 mm	500 N	AC 230 V	3-Point	-	30 s	-	Press and fix	Position feedback, forced control, change of characteristic
SAY61P03 SAY61.03U	S55150-A133 S55150-A135			AC 24 V /DC 24 V	DC 0...10 V DC 4...20 mA 0...1000 Ω			✓		
SAY81P03 SAY81.03U	S55150-A134 S55150-A136	20 mm	500 N	AC 230 V	3-Point	-	30 s	-	Press and fix	Position feedback, forced control, change of characteristic
SAX31P03	S55150-A118			AC 24 V /DC 24 V	DC 0...10 V DC 4...20 mA 0...1000 Ω			✓		
SAX61P03	S55150-A114	40 mm	1100 N	AC 230 V	3-position	-	120 s	-	Press and fix	Position feedback, forced control, change of characteristic
SAX81P03	S55150-A116			AC 24 V /DC 24 V	DC 0...10 V DC 4...20 mA 0...1000 Ω			✓		
SAV31P00	S55150-A121	90°	1100 N	AC 230 V	3-position	-	120 s	-	Press and fix	Position feedback, forced control, change of characteristic
SAV61P00	S55150-A119			AC 24 V /DC 24 V	3-position			-		
SAV81P00	S55150-A120			AC 230 V	3-position	-	30 s	-	Press and fix	Position feedback, forced control, change of characteristic

2.3.3 Rotary actuators

Product no.	Stock no.	Angular rotation	Torque	Operating voltage	Positioning signal	Spr. ret. time	Pos. time	LED	Manual adjuster	Extra functions		
SAL31.00T10	S55162-A108	90°	10 Nm	AC 230 V	3-position	120 s	-	Press and fix	Position feedback, forced control	-		
SAL31.00T20	S55162-A110		20 Nm				30 s					
SAL31.00T40	S55162-A111		40 Nm				120 s	✓				
SAL31.03T10	S55162-A109		10 Nm				30 s					
SAL61.00T10	S55162-A100		20 Nm	AC 24 V DC 24 V	DC 0...10 V DC 4...20 mA 0...1000 Ω	120 s	-					
SAL61.00T20	S55162-A102		40 Nm				30 s					
SAL61.00T40	S55162-A103		10 Nm				120 s	✓				
SAL61.03T10	S55162-A101		20 Nm				30 s					
SAL81.00T10	S55162-A104		40 Nm				120 s	-				
SAL81.00T20	S55162-A106		10 Nm				30 s					
SAL81.00T40	S55162-A107		20 Nm				120 s	✓				
SAL81.03T10	S55162-A105		40 Nm				30 s	-				

2.4 Ordering



Example

Product no.	Stock no.	Description	Quantity
SAX81.03	S55150-A103	Actuator	1
ASZ7.5/1000	S55845-Z106	Potentiometer	1

Delivery

Actuators, valves and accessories are supplied in individual packs.

Scope of delivery


Type	Device	Screws	Waveinset
SAY.P..		-	-
SAX..		-	-
SAV..		-	-
SAL..T10		-	-
SAL..T20		2 pcs. M5 x 20 mm 4040U20	1 pc. 11 mm 
SAL..T40		2 pcs. M6 x 20 mm 4040U20	1 pc. 14 mm 
ASK31N		4 pcs. M6 x 16 mm 1 pc. M5 x 20 mm incl. nut 4040U16	1 pc. 12 mm  1 pc. 12 mm 
ASK33N		4 pcs. M6 x 16 mm 1 pc. M5 x 20 mm incl. nut 4040U16	1 pc. 12 mm  1 pc. 12 mm 
ASK35N		2 pcs. M8 x 50 mm 1 pc. M5 x 20 mm incl. nut 4040U19	1 pc. 12 mm 1 pc. 16 mm  

2.5 Equipment combinations

2.5.1 Stroke actuators – 3-port valves

Typical applications	Stroke actuators	Data Sheet	Stroke	20 mm	40 mm					
			Positioning force	800 N	1600 N					
• Heating plants • Ventilation and air conditioning plants • Heat generation • Heat distribution • District heating plants	SAX.. SAV..	N4501 N4503								
										
			SAX..	SAX..	SAV..					
Valves	Basic Doc. (P4030)									
Valves	Data Sheet	Valve type	DN	K_{vs} [m³/h]						
PN6	N4410	VXF21.22...25 ^{1) 7)} VXF21.25.. ^{2) 7)} VXF21.39-40 ⁷⁾ VXF21.40.. ^{2) 7)} VXF21.50 ⁷⁾ VXF21.50-40 ⁷⁾ VXF21.65 ⁷⁾ VXF21.65-63 ⁷⁾ VXF21.80-78 ⁷⁾ VXF21.80-100 ⁷⁾	25 25 40 40 50 50 65 65 80 80	1.9 / 3 / 5 / 7.5 2.5 / 4 / 6.3 / 10 12 / 19 16 / 25 31 40 49 63 78 100		$\Delta p_{max}^{5)}$ [kPa] AB → A B	Δp_{max} [kPa] A → AB B	$\Delta p_{max}^{5)}$ [kPa] AB → A B	Δp_{max} [kPa] A → AB B	
-10...130 °C ⁴⁾					100	300				
PN6	N4401	VXF22.25.. ²⁾ VXF22.40.. ²⁾ VXF22.50-40 VXF22.65-63 VXF22.80-100 VXF22.100-160	25 40 50 65 80 100	2.5 / 4 / 6.3 / 10 16 / 25 40 63 100 160		100	300	100	300	
-10...130 °C							50	150	75	50
PN10	N4420	VXF31.15.. ^{2) 7)} VXF31.24...25 ^{1) 7)} VXF31.25.. ^{2) 7)} VXF31.39...40 ^{1) 7)} VXF31.40.. ^{2) 7)} VXF31.50 ⁷⁾ VXF31.50-40 ⁷⁾ VXF31.65 ⁷⁾ VXF31.65-63 ⁷⁾ VXF31.80 ⁷⁾ VXF31.80-100 ⁷⁾	15 25 25 40 40 50 50 65 65 80 80	2.5 / 4 5 / 7.5 6.3 / 10 12 / 19 16 / 25 31 40 49 63 78 100		100	300			
-10...130 °C ⁴⁾										
PN 10	N4402	VXF32.15.. ²⁾ VXF32.25.. ²⁾ VXF32.40.. ²⁾ VXF32.50-40 VXF32.65-63 VXF32.80-100 VXF32.100-160 VXF32.125-250 VXF32.150-400	15 25 40 50 65 80 100 125 150	1.6 / 2.5 6.3 / 10 16 / 25 40 63 100 160 250 400		100	400	100	400	
-10...130 °C ⁴⁾							50	150	75	50
PN16	N4430	VXF40.15.. ^{2) 7)} VXF40.25.. ^{2) 7)} VXF40.40.. ^{2) 7)} VXF40.50.. ^{2) 7)} VXF40.65.. ^{2) 7)} VXF40.80.. ^{2) 7)}	15 20 40 50 65 80	1.9 / 2.5 / 3 / 4 5 / 6.3 / 7.5 / 10 12 / 16 / 19 / 25 31 / 40 49 / 63 78 / 100		100	300			
-10...130 °C ⁴⁾								60	175	
PN16	N4440	VXF41.14...15 ^{1) 7)} VXF41.24...25 ^{1) 7)} VXF41.39...40 ^{1) 7)} VXF41.49...50 ^{1) 7)}	15 25 40 50	1.9 / 3 5 / 7.5 12 / 19 19 / 31		200	800			
-10...130 °C ⁴⁾								150	500	
								100	350	

SAV..: This product line of actuators might not be available in all countries. Please talk to your local contact or consult your local internet pages of www.buildingtechnologies.siemens.com.

Typical applications	Stroke actuators	Data Sheet	Stroke	20 mm	40 mm
			Positioning force	800 N	1600 N
• Heating plants • Ventilation and air conditioning plants • Heat generation • Heat distribution • District heating plants	SAX.. SAV..	N4501 N4503			
			SAX..	SAV..	
Valves	Basic Doc. (P4030)				
Valves	Data Sheet	Valve type	DN	k_{vs} [m³/h]	$\Delta p_{max}^{(5)}$ [kPa] AB → A B
PN16	N4403	VXF42.15-.. ²⁾	15	1.6 / 2.5 / 4	100
		VXF42.20-6.3	20	6.3	
		VXF42.25-.. ²⁾	25	6.3 / 10	
		VXF42.40-.. ²⁾	40	16 / 25	
		VXF42.50-.. ²⁾	50	31.5 / 40	
		VXF42.65-.. ²⁾	65	50 / 63	
		VXF42.80-.. ²⁾	80	80 / 100	
		VXF42.100-.. ²⁾	100	125 / 160	
-10...130 °C ⁴⁾		VXF42.125-.. ²⁾	125	200 / 250	-
		VXF42.150-.. ²⁾	150	315 / 400	50
PN16	N4404	VXF43.65-63	65	63	-
		VXF43.80-100	80	100	
		VXF43.100-160	100	160	
		VXF43.125-250	125	250	
-20...130 °C ⁴⁾		VXF43.150-400	150	400	50
PN25/16 ⁶⁾	N4405	VXF53.15-.. ²⁾	15	1.6 / 2.5 / 4	200
		VXF53.20-6.3	20	6.3	
		VXF53.25-.. ²⁾	25	6.3 / 10	
		VXF53.32-16	32	16	
		VXF53.40-.. ²⁾	40	16 / 25	
		VXF53.50-40	50	40	100
PN25 ⁵⁾		VXF53.65-63	65	63	-
		VXF53.80-100	80	100	
		VXF53.100-160	100	160	
		VXF53.125-250	125	250	
-20...130 °C ⁴⁾		VXF53.150-400	150	400	50
PN16	N4463	- VXG41.1301 ³⁾	15	1.6	-
		- VXG41.1401 ³⁾	15	2.5	
		VXG41.15 VXG41.1501 ³⁾	15	4	
		VXG41.20 VXG41.2001 ³⁾	20	6.3	
		VXG41.25 VXG41.2501 ³⁾	25	10	
		VXG41.32 VXG41.3201 ³⁾	32	16	
		VXG41.40 VXG41.4001 ³⁾	40	25	
-25...130 °C ⁴⁾		VXG41.50 VXG41.5001 ³⁾	50	40	800
					525
					300

1) Insert running number instead of k_{vs} value

2) .. = insert k_{vs} value

3) With tight bypass; VXG41.1301 and VXG41.1401: use only SAX61.., SKD32.50 or SKD82.50.

4) For media temperatures > 130 °C use electrohydraulic actuators SKD.. (N4561), SKB.. (N4564).



5) Δp_{max} = max. permissible differential pressure in diverting mode

6) DN 15...50: Flange dimensions for PN 16 and PN 25


DN 65...150: Flange dimensions only for PN 25

7) Valves no longer in the active sale

2.5.2 Stroke actuators – 2-port valves

Typical applications	Stroke actuators	Data Sheet	Stroke	20 mm	40°mm		
			Positioning force	800 N	1600 N		
• Heating plants • Ventilation and air conditioning plants • Heat generation • Heat distribution • District heating plants	SAX.. SAV..	N4501 N4503					
				SAX..	SAV..		
Valves	Basic Doc. (P4030)						
Valves	Data Sheet	Valve type	DN	k_{vs} [m³/h]	Δp_s [kPa] Δp_{max} [kPa] Δp_s [kPa] Δp_{max} [kPa]		
PN6	N4310	VVF21.22...25 ^{1) 4)}	25	1.9 / 3 / 5 / 7,5	600		
		VVF21.25-.. ^{2) 4)}	25	2.5 / 4 / 6.3 / 10			
		VVF21.39...40 ^{1) 4)}	40	12 / 19	500	300	
		VVF21.40-.. ^{2) 4)}	40	16 / 25			
		VVF21.50 ⁴⁾	50	31	300	-	
		VVF21.50-40 ⁴⁾	50	40			
		VVF21.65 ⁴⁾	65	49	175	175	
		VVF21.65-63 ⁴⁾	65	63			
		VVF21.80-78 ⁴⁾	80	78	100	100	
		VVF21.80-100 ⁴⁾	80	100			
-10...130 °C ³⁾							
PN6	N4401	VVF22.25-.. ²⁾	25	2.5 / 4 / 6.3 / 10	600		
		VVF22.40-.. ²⁾	40	16 / 25	550	300	
		VVF22.50-40	50	40	350	600	300
		VVF22.65-63	65	63	200	150	450
		VVF22.80-100 ¹⁾	80	100	125	75	250
		VVF22.100-160 ¹⁾	100	160	-	-	225
-10...130 °C						160	160
PN10	N4320	VVF31.15-.. ^{2) 4)}	15	2.5 / 4			
		VVF31.24...25 ^{1) 4)}	25	5 / 7,5	1000		
		VVF31.25-.. ^{2) 4)}	25	6.3 / 10			
		VVF31.39...40 ^{1) 4)}	40	12 / 19	525	300	
		VVF31.40-.. ^{2) 4)}	40	16 / 25			
		VVF31.50 ⁴⁾	50	31	325	-	
		VVF31.50-40 ⁴⁾	50	40			
		VVF31.65 ⁴⁾	65	49	175	175	
		VVF31.65-63 ⁴⁾	65	63			
		VVF31.80 ⁴⁾	80	78	100	100	
		VVF31.80-100 ⁴⁾	80	100			
-10...130 °C ³⁾							
PN10	N4402	VVF32.15-.. ²⁾	15	1.6 / 2.5 / 4	1000		
		VVF32.25-.. ²⁾	25	6.3 / 10	400	-	
		VVF32.40-.. ²⁾	40	16 / 25	1000		
		VVF32.50-40	50	40	350	750	400
		VVF32.65-63	65	63	200	150	450
		VVF32.80-100 ²⁾	80	100	125	75	250
		VVF32.100-160 ²⁾	100	160			225
		VVF32.125-250	125	250	-	-	160
		VVF32.150-400 ²⁾	150	400			125
-10...130 °C ⁴⁾						80	90
PN16	N4330	VVF40.15-.. ^{2) 4)}	15	1.9 / 2.5 / 3 / 4	1600		
		VVF40.25-.. ^{2) 4)}	20	5 / 6.3 / 7.5 / 10	1550	300	
		VVF40.40-.. ^{2) 4)}	40	12 / 16 / 19 / 25	525	-	
		VVF40.50-.. ^{2) 4)}	50	31 / 40	325		
		VVF40.65-.. ^{2) 4)}	65	49 / 63	175	175	
		VVF40.80-.. ^{2) 4)}	80	78 / 100	100	100	
-10...130 °C ³⁾							
PN16	N4340	VVF41.49 ⁴⁾	50	19			
		VVF41.50 ⁴⁾	50	31	350	300	
-10...130 °C ³⁾		-	-	-	-	-	-

SAV..: This product line of actuators might not be available in all countries. Please talk to your local contact or consult your local internet pages of www.buildingtechnologies.siemens.com.

Typical applications	Stroke actuators	Data Sheet	Stroke	20 mm		40°mm		
			Positioning force	800 N	1600 N			
• Heating plants • Ventilation and air conditioning plants • Heat generation • Heat distribution • District heating plants	SAX.. SAV..	N4501 N4503						
				SAX..		SAV..		
Valves	Basic Doc. (P4030)							
Valves	Data Sheet	Valve type	DN	k_{vs} [m³/h]	Δp_s [kPa]	Δp_{max} [kPa]	Δp_s [kPa]	
PN16	N4403	VVF42.15... ²⁾	15	1.6 / 2.5 / 4	1600	400	-	-
		VVF42.20-6.3	20	6.3				
		VVF42.25... ²⁾	25	6.3 / 10				
		VVF42.32-16	32	16			1250	400
		VVF42.40... ²⁾	40	16 / 25	550	300	750	
		VVF42.50... ²⁾	50	31.5 / 40	350	150	450	
		VVF42.65... ²⁾	65	50 / 63	200	75	250	
		VVF42.80... ²⁾	80	80 / 100	125	160	225	
-10...130 °C ³⁾		VVF42.100... ²⁾	100	125 / 160	-	-	125	125
		VVF42.125... ²⁾	125	200 / 250			80	80
		VVF42.150... ²⁾	150	315 / 400			160	125
PN16	N4403	VVF42.50-40K	50	40	1600	400	-	-
		VVF42.65-63K	65	63				
		VVF42.80-100K	80	100				
		VVF42.100-160K	100	160		-	1600	400
		VVF42.125-250K	125	250			125	
		VVF42.150-360K	150	360			80	1400
-10...130 °C ³⁾		VVF43.65... ²⁾	65	50 / 63	-	-	450	400
		VVF43.80... ²⁾	80	80 / 100			250	225
		VVF43.100... ²⁾	100	125 / 160			160	125
20...130 °C ³⁾		VVF43.125... ²⁾	125	200 / 250			125	90
		VVF43.150... ²⁾	150	315 / 400			80	60
PN25	N4373	VVF52.15... ^{2) 4)}	15	0.16 / 0.2 / 0.25 / 0.32 / 0.4 / 0.5 / 0.63 / 0.8 / 1 / 1.25 / 1.6 / 2 / 2.5 / 3.2 / 4	2500	1600	-	-
		VVF52.25... ^{2) 4)}	25	5 / 6.3 / 8 / 10				
		VVF52.40... ^{2) 4)}	40	12.5 / 16 / 20 / 25				
-20...130 °C ³⁾		VVF53.15... ²⁾	15	0.16 / 0.2 / 0.25 / 0.32 / 0.4 / 0.5 / 0.63 / 0.8 / 1 / 1.25 / 1.6 / 2 / 2.5 / 3.2 / 4	2500	1200	-	-
		VVF53.20-6.3	20	6.3				
		VVF53.25... ²⁾	25	5 / 6.3 / 8 / 10				
		VVF53.32-16	32	16				
		VVF53.40... ²⁾	40	12.5 / 16 / 20 / 25				
PN25/16		VVF53.50... ²⁾	50	31.5 / 40	500	400	-	-
		VVF53.65-63	65	63				
		VVF53.80-100	80	100				
		VVF53.100-160	100	160				
		VVF53.125-250	125	250				
		VVF53.150-360	150	360				
-20...130 °C ³⁾		VVG41.11...12 ¹⁾	15	0.63 / 1				
		VVG41.13	15	1.6				
		VVG41.14	15	2.5				
PN25		VVG41.15	15	4				
		VVG41.20	20	6.3				
		VVG41.25	25	10	1600	800	-	-
		VVG41.32	32	16				
		VVG41.40	40	25				
		VVG41.50	50	40				
-25...130 °C ³⁾		VVG41.11...12 ¹⁾	15	0.63 / 1				

SAV..: This product line of actuators might not be available in all countries. Please talk to your local contact or consult your local internet pages of www.buildingtechnologies.siemens.com.

¹⁾ insert running number instead of k_{vs} value

²⁾ .. = insert k_{vs} value



³⁾ For media temperatures > 130 °C use electrohydraulic actuators SKD.. (N4561), SKB.. (N4564).

⁴⁾ valves no longer in the active sale

2.5.3 Stroke Actuators – combi valves

	Valves				Actuators											
	Standard flow rate	High flow rate	DN	H_{100} [mm]	SAY..P..		SAX..P..		SAV..P..							
PN25 N4855	VPI46.40F9.5Q	-	40		400	400	-	-	-	-						
	VPI46.50F12Q	-	50		15	-	600	600	-	-						
PN16 N4315	VPF43.50F16	VPF43.50F25	50													
	VPF43.65F24	VPF43.65F35	65	20												
	VPF43.80F35	VPF43.80F45	80													
	VPF43.100F70	VPF43.100F90	100	40												
	VPF43.125F110	VPF43.125F135	125	600					600							
	VPF43.150F160	VPF43.150F200	150		43											
PN25 N4315	VPF53.50F16	VPF53.50F25	50	20					600	600						
	VPF53.65F24	VPF53.65F35	65													
	VPF53.80F35	VPF53.80F45	80	40					600	600						
	VPF53.100F70	VPF53.100F90	100													
	VPF53.125F110	VPF53.125F135	125													
	VPF53.150F160	VPF53.150F200	150	43												

2.5.4 Rotary actuators – slipper and butterfly valves

Typical applications	Rotary actuators	Data Sheet	Angular rotation		90°		
			Torque	10 Nm	20 Nm	40 Nm	
• Heating plants • Ventilation and air conditioning plants • Heat generation • Heat distribution • District heating plants	SAL..	N4502					
Slipper valves	Data Sheet	Valve type	DN	k_{vs} [m³/h]	Mounting set	Δp_{max} [kPa]	SAL..T10 SAL..T20 SAL..T40
PN6  1 °C...120 °C	N4241	VBF21.40	40	25	-	- ¹⁾	
		VBF21.50	50	40	-	- ¹⁾	
		VBF21.65	65	63	ASK31N		
		VBF21.80	80	100	ASK31N		
		VBF21.100	100	160	ASK31N		
		VBF21.125	125	550	ASK31N		
Butterfly valves  -10 °C...120 °C	N4131	VBF21.150	150	820	ASK31N		
		VKF41.40 ²⁾	40	50	ASK33N	500	
		VKF41.50 ²⁾	50	80	ASK33N		
		VKF41.65 ²⁾	65	200	ASK33N		
		VKF41.80 ²⁾	80	400	ASK33N		
		VKF41.100 ²⁾	100	760	ASK33N		
PN16  -10 °C...120 °C	N4136	VKF41.125 ²⁾	125	1000	ASK33N	300	
		VKF41.150 ³⁾	150	2100	ASK33N	250	- 400
		VKF41.200 ³⁾	200	4000	ASK33N	125	- 300
		VKF46.40 ⁴⁾	40	50	-	1600	
		VKF46.50 ⁴⁾	50	85	-		
		VKF46.65 ⁴⁾	65	215	-		
		VKF46.80 ⁴⁾	80	420	-		1600
		VKF46.100 ⁴⁾	100	800	-		1200
		VKF46.125 ⁴⁾	125	1010	-		800

1) SAL..T10 rotary actuators only fit on VBF21.., DN65...150. For VBF21.., DN40/50 use SQK34.., SQK84.. or SQK33.00 rotary actuators.

2) VKF41.. maximum flow speed with SAL.T10 actuator with water DN40.. DN125 = 4 m/s

3) VKF41.. maximum flow speed with SAL.T0 actuator with water DN150/200 = 2.5 m/s, with SAL.T40 actuator with water DN150/200 = 4 m/s

4) VKF46.. maximum flow speed water = 4.5 m/s, air 40 m/s

2.6 Accessories

2.6.1 Electrical accessories

Product no.	Auxiliary switch ASC10.51	Potentiometer ASZ7.5/.. ¹⁾	Function module AZX61.1	Stem heating element ASZ6.6
Stock no.	S55845-Z103	S55845-Z104 (ASZ7.5/135) S55845-Z105 (ASZ7.5/200) S55845-Z106 (ASZ7.5/1000)	S55845-Z107	S55845-Z108
		Max. 2		
SAX31..	Max. 2	Max. 1	-	Max. 1
SAX61..		-	Max. 1	
SAX81..		Max. 1	-	
SAX31P..	Max. 2	Max. 1	-	-
SAX61P..		-	Max. 1	
SAX81P..		Max. 1	-	
SAV31..	Max. 2	Max. 1	-	Max. 1
SAV61..		-	Max. 1	
SAV81..		Max. 1	-	
SAV31P..	Max. 2	Max. 1	-	-
SAV61P..		-	Max. 1	
SAV81P..		Max. 1	-	
SAL31..	Max. 2	Max. 1	-	-
SAL61..		-	Max. 1	
SAL81..		Max. 1	-	
SAY31P..	Max. 2	Max. 1	-	-
SAY61P..		-	Max. 1	
SAY81P..		Max. 1	-	

¹⁾ Available with 135 Ω, 200 Ω or 1000 Ω

2.6.2 Mechanical accessories

Product no.	Weather shield ASK39.1	Mounting set		
		ASK31N for VBF21..	ASK33N for VKF41..	ASK35N für VKF45.. ¹⁾
Stock no.	S55845-Z109	S55845-Z100	S55845-Z101	S55845-Z102
SAY..	Max. 1	-	-	-
SAX..				
SAV..				
SAL..				
SAL..T10	Max. 1	✓	✓	-
SAL..T20		-	-	DN40...DN65
SAL..T40		-	DN150 / 200	DN80...DN200

¹⁾ In 2000 VKF45.. line was replaced by VKF46.. line.

2.7 Product replacements

Replacement of SQX.. / SQL.. actuators by SAX.. / SAL.. actuators.

Note

- When replacing actuators consider positioning force, torque and positioning times.
- Adjust in the controller the parameter "Running time" respectively "Positioning time", to ensure stable control.
- The replacement of accessory items needs to be taken into consideration also. In that case, compatibility is not necessarily ensured.

2.7.1 Stroke actuators SQX.. to SAX..

SQX..		Pos. time [s]	Pos. force [N]	SAX.. ¹⁾	Pos. time [s]	Pos. force [N]	VVF21../VXF21.. VVF31../VXF31.. VVF40../VXF40..	VVF41../VXF41.. VVG41../VXG41..	VVF51.. VVF52..
							DN15...80	DN15...50	DN15...40
SQX31..²⁾	SQX31.00	150	500	SAX31.00	120	800	✓	✓	✓
	SQX31.03	35	500	SAX31.03	30	800	✓	✓	✓
SQX61..	SQX61	35	500	SAX61.03	30	800	✓	✓	✓
	SQX61U	35	500	SAX61.03U	30	800	✓	✓	✓
SQX81..	SQX81.00	150	500	SAX81.00	120	800	✓	✓	✓
	SQX81.00U	150	500	SAX81.00U	120	800	✓	✓	✓
	SQX81.03	35	500	SAX81.03	30	800	✓	✓	✓
	SQX81.03U	35	500	SAX81.03U	30	800	✓	✓	✓
SQX32..	SQX32.00	150	700	SAX31.00	120	800	✓	✓	✓
	SQX32.03	35	700	SAX31.03	30	800	✓	✓	✓
SQX62..	SQX62	35	700	SAX61.03	30	800	✓	✓	✓
	SQX62U	35	700	SAX61.03U	30	800	✓	✓	✓
SQX82..	SQX82.00	150	700	SAX81.00	120	800	✓	✓	✓
	SQX82.00U	150	700	SAX81.00U	120	800	✓	✓	✓
	SQX82.03	35	700	SAX81.03	30	800	✓	✓	✓
	SQX82.03U	35	700	SAX81.03U	30	800	✓	✓	✓

¹⁾ SAX81.., SAX61.. are available as UL-listed versions.

²⁾ SQX31.06: Actuator for gas valves. Either replace complete valve-actuator combination or clarify required positioning time and replace only actuator. Consider if mounting set is required.

2.7.2 Rotary actuators SQL.. to SAL..

SQL..			SAL..	Pos. time [s]	Torque [Nm]
	Pos. time [s]	Torque [Nm]		Pos. time [s]	Torque [Nm]
SQL31..	SQL31.10	120	SAL31.00T10	120	10
SQL32..	SQL32.10	125	SAL31.00T10	120	10
	SQL32.12	70	SAL31.00T10 or SAL31.03T10 ¹⁾	120	10
	SQL32.13	30	SAL31.03T10	30	10
SQL33..	SQL33.00	125	SAL31.00T10	120	10
	SQL33.03	30	SAL31.03T10	30	10
SQL83..	SQL83.00	125	SAL81.00T10	120	10
	SQL83.04	30	SAL81.03T10	30	10
SQL35..	SQL35.00	125	SAL31.00T20 ²⁾	120	20
	SQL35.00	125	SAL31.00T40 ²⁾	120	40
SQL85..	SQL85.00	125	SAL81.00T20 ²⁾	120	20
	SQL85.00	125	SAL81.00T40 ²⁾	120	40

¹⁾ SAL.. positioning time differs from that of SQL32.12 and SQL32.13 rotary actuators. Consider positioning time when replacing.

²⁾ use SAL.T20 on VKF46.40, VKF46.50 and VKF46.65
use SAL.T40 on VKF46.80, VKF46.100 and VKF46.125

Rotary actuators		SQL..				SAL..			
		SQL31..	SQL32..	SQL33.. SQL83..	SQL35.. SQL85..	SAL31.00T10 SAL31.03T10 SAL81.00T10 SAL81.03T10	SAL31.00T20 SAL81.00T20	SAL31.00T40 SAL81.00T40	
VBF21..	DN 40 / DN 50 ¹⁾	-	-	ASK32	-	¹⁾	¹⁾	¹⁾	
	DN 65...150	-	-	ASK31	-	ASK31N	-	-	
VBF31..	DN 40 / DN 50 ²⁾	-	-	ASK32	-	²⁾	²⁾	²⁾	
	DN 65...100	-	-	ASK31	-	ASK31N	-	-	
B3f..	DN 40 / DN 50 ²⁾	Direct	ASK25	ASK31	-	-	-	-	
	DN 65...150	Direct	ASK25	ASK31	-	ASK31N	-	-	
C1f..	DN 40 / DN 50 ²⁾	Direct	-	ASK31	-	-	-	-	
	DN 65...100	Direct	-	ASK31	-	ASK31N	-	-	
K1i..	DN 20...32	Direct	ASK24	ASK33	-	ASK33N	-	-	
K1f..	DN 40...200	Direct	ASK24	ASK33	-	ASK33N	-	-	
VKF41..	DN 40...125	-	-	ASK33	-	ASK33N	-	-	
	DN 150 / DN 200	-	-	ASK33	ASK35	ASK33N	-	ASK33N	
VKF45..	DN40...65	-	-	-	ASK35	-	ASK35N	ASK35N	
	DN80...200					-	-	ASK35N	

¹⁾ Replace with rotary actuators SQK34.., SQK84.. (data sheet N4508) or SQK33.00 (data sheet N4506).

²⁾ Replace with rotary actuators SQK33.00 + ASK32

Note

Rotary actuators SAL.. are not suited for mounting sets ASK24, ASK25, ASK31, ASK32, ASK33, ASK35, ASK36, ASK40 and ASK41.

2.7.3 Electrical accessories

Notes

- If an auxiliary switch is required, its switching point should be indicated on the plant schematic.
- For media below 0 °C the stem heating element ASZ6.6 keeps the valve free from freezing.
- For this case, do not insulate the actuator bracket and the valve stem, as air circulation must be ensured!
- Non-observance of the above may result in accidents and fires!**
- Do not touch the hot parts without prior protective measures to avoid burns.**



Stroke actuators		SQX..				SAX..	
		SQX31..	SQX61..	SQX32..	SQX62..	SAX31..	SAX61..
		SQX81..	-	SQX82..	-	SAX81..	-
ASZ6.5	Stem heater	ASZ6.5	ASZ6.5	ASZ6.5	ASZ6.5	ASZ6.6	ASZ6.6
ASZ7.4	1 auxiliary switch, 1 potentiometer (1000 Ω)	ASZ7.4	-	ASZ7.4	-	ASC10.51 + ASZ7.5/1000	-
ASC9.4	Double auxiliary switch	ASC9.4	-	ASC9.4	-	2x ASC10.51	-
ASC9.5	Auxiliary switch	ASC9.5	-	ASC9.5	-	ASC10.51	-

Rotary actuators		SQL..				SAL..	
		SQL31..	SQL32..	SQL33..	-	SAL31..T10	-
		-	-	SQL83..	-	SAL81..T10	-
		-	-	-	SQL35.00	-	SAL31.00T20 / T40
		-	-	-	SQL85.00	-	SAL81.00T20 / T40
ASZ7.4	1 auxiliary switch, 1 potentiometer (1000 Ω)	-	-	ASZ7.4	ASZ7.4	ASC10.51 + ASZ7.5/1000	ASC10.51 + ASZ7.5/1000
ASC9.4	Double auxiliary switch	-	-	ASC9.4	ASC9.4	2x ASC10.51	2x ASC10.51
ASC9.5	Auxiliary switch	-	-	ASC9.5	ASC9.5	ASC10.51	ASC10.51
ASZ8.4	Potentiometer (220 Ω)	ASZ8.4	ASZ8.4	-	-	¹⁾	-
ASZ9.4	Potentiometer (2800 Ω)	ASZ9.4	ASZ9.4	-	-	¹⁾	-
ASC1.4	Auxiliary switch	ASC1.4	ASC1.4	-	-	ASC10.51	-




¹⁾ Used auxiliary switches or potentiometer (order accessories additionally were applicable):

- Check used functionality
- Check compatibility with controller

2.8 Spare parts



The following spare part sets are available:

SAY.., SAX.., SAV..

Stock number 8000060843	Housing cover  Screw (valve stem coupling)  U-bracket 	
-----------------------------------	--	---

Single components from the spare part sets are not available.

SAL..

Stock number 8000060844	Housing cover  2 adapters  1 pc. 14 mm  1 pc. 11 mm 4 screws  2 pcs. M5 x 20 mm 2 pcs. M6 x 20 mm	
-----------------------------------	---	--

Single components from the spare part sets are not available.

2.9 Sizing

2.9.1 Parallel operation of actuators

SA..31.. and SA..81..

3-position actuators must have one specific controller each, refer to "Connection diagrams" (page 69).

SA..61..

Up to 10 actuators can drive in parallel on a controller output with a rating of 1 mA. Modulating actuators have an input impedance of 100 kΩ.

2.9.2 Permissible cable lengths and wire cross-sectional areas

Cable lengths and wire cross-sectional areas depend on the following criteria of the actuators:

- Current draw
- Permissible voltage drop across the power supply lines

The control accuracy of the modulating actuators can be improved by using 4-wire connections, thus ensuring that voltage drops on G0 will not distort the positioning signal.

Note


When determining the cable length and the wire cross-sectional area, adherence to the permissible operating voltage tolerance at the actuator is of importance, in addition to the permissible voltage drop across the operating voltage and signal lines (see table below).

Product no.	Operating voltage	Terminal	Max. permissible voltage drop
SA..31..	AC 230 V	N, Y1, Y2	2% each (total of 4%)
SA..61..	AC/DC 24 V	G0, G	4% each (total of 8%)
		G0, Y, U	1% each (at DC 0...10 V)
SA..81..		G, Y1, Y2	4% each (total of 8%)

The following criteria must be considered:


- With modulating control, the permissible positioning signal error must not exceed 1%, the reason being the voltage drop on the G0 wire.
- The voltage drop, caused by charging current peaks in the actuator's DC circuit, must not exceed 2 Vpp.
- If the G0 line is not correctly sized, load changes of the actuator due to changes of the DC voltage drop might lead to self-oscillations.
- The operating voltage drop at AC/DC 24 V may be a maximum of 8% (4% above the G0 wire).

Basic diagram – voltage drop across the power supply cables



The following diagram can be used to determine the cable lengths and wire cross-sectional areas.

L/P-diagram for AC/DC 24 V



Permissible cable length L as a function of power P and cross-sectional area of wire as a parameter

Note

P is the decisive power consumption of all actuators connected in parallel. When operating on AC 24 V, power consumption is in VA; when operating on DC 24 V, in W.

Formulas for wire lengths

Operating voltage	Permissible voltage drop / wire	Formula for wire length
AC 230 V	2% of AC 230 V	$L = 46 \cdot \frac{1313 \cdot A}{P}$ [m]
AC/DC 24 V	4% of AC 24 V	$L = \frac{1313 \cdot A}{P}$ [m]
	1% of DC 10 V	$L = \frac{5.47 \cdot A}{I(DC)}$ [m]

A Cross-sectional area of wire in mm^2

L Permissible wire length in m

P Power consumption in VA (AC) or W (DC) (see actuator's rating plate)

I(DC) DC current part (in A) on G0 wire

2.10 Warranty

The engineering data specified in chapter "Equipment combinations" (page 12) are only guaranteed in connection with the Siemens valves listed.


Note

When using the actuators in connection with valves of other manufacture, correct functioning must be ensured by the user, and Siemens will assume no responsibility.

3 Handling

3.1 Mounting and installation

3.1.1 Mounting positions





¹⁾ Only in connection with weather shield ASK39.1

3.1.2 Fitting stroke actuators to seat valves VVF.. / VXF.. or VVG.. / VXG..

First, observe "Mounting positions" (page 23).


	Caution! Risk of burns from hot surfaces! If you touch heated parts, you will get burns as result. • Allow to cool parts. • Wear protective gloves.
--	---





3.1.3 Avoid missaligment on V_G41 valves with fittings

	Caution! Risk of burns from hot surfaces! If you touch heated parts, you will get burns as result. <ul style="list-style-type: none"> Allow to cool parts. Wear protective gloves.
--	---







On threaded valves it's possible that the actuator is missaligned on the valve due to a collision with the fitting. If so, please take care for correct mounting, either by turning the actuator or by adjusting the fitting (e.g. use a second sealing to change fitting position).

3.1.4 Fitting rotary actuators to butterfly valves VKF41..

First, observe "Mounting positions" (page 23).


Mounting set ASK33N


Scope of delivery			
Mounting set (2 parts)	5 screws	1 adapter inc. fixing screw	1 adapter
 4040U15	4 pcs. M6 x 16 mm 1 pc. M5 x 20 incl. nut  .4040U16	 4040U17	 4040U18

Note

Actuators SAL.. are not compatible with mounting sets ASK31, ASK32, ASK33, ASK35, ASK40, and ASK41.

	Caution! Risk of burns from hot surfaces! If you touch heated parts, you will get burns as result. • Allow to cool parts. • Wear protective gloves.
---	---









¹⁾ Angle position errors between actuator shaft and valve stem must be corrected via manual control (refer to "Manual adjuster" page 60).

3.1.5 Fitting rotary actuators to slipper valves VBF21..

First, observe "Mounting positions" (page 23).


Mounting set ASK31N

Scope of delivery			
Mounting set (2 parts)	5 screws	1 adapter inc. fixing screw	1 adapter
 4040U15	4 pcs. M6 x 16 mm 1 pc. M5 x 20 mm incl. nut  4040U16	 4040U17	 4040U18



SAL..T10 rotary actuators only fit on VBF21.., DN65...150. For VBF21.., DN40/50 use SQK34.., SQK84.. or SQK33.00 rotary actuators.

With VBF21.. (e.g. DN 125), the following steps must be performed prior to fitting the mounting set.

	Caution! Risk of burns from hot surfaces! If you touch heated parts, you will get burns as result. • Allow to cool parts. • Wear protective gloves.
---	---



Opening clockwise



4040193

For further mounting positions of VBF 21.. and routing of the connection cables the rotary actuators and adapters must be mounted according to the sketches above.


3.1.6 Fitting rotary actuators to butterfly valves VKF46..

First, observe "Mounting positions" (page 23).

Standard scope of delivery
VKF46..

Product no.	Scope of delivery		
	2 screws	1 dapter	
SAL..T20	2 pcs. M5 x 20 mm	1 pc. 11 mm 4040J20	1 pc. 14 mm 4040J21
SAL..T40	2 pcs. M6 x 20 mm		




	Caution! Risk of burns from hot surfaces! If you touch heated parts, you will get burns as result. <ul style="list-style-type: none"> Allow to cool parts. Wear protective gloves.
---	---



3.1.7 Fitting rotary actuators to butterfly valves VKF45..

First, observe "Mounting positions" (page 23).

Mounting set ASK35N
For VKF45..

Scope of delivery		
Mounting set (2 parts)	5 screws	2 adapters
 4040U15	2 pcs. M8 x 50 mm 1 pc. M5 x 20 mm incl. nut  4040U19	1 pc. 12 mm 1 pc. 16 mm 

Note


Actuators SAL.. are not suited for use with mounting sets ASK31, ASK32, ASK33, ASK35, ASK40, and ASK41.




Caution!

Risk of burns from hot surfaces!

- If you touch heated parts, you will get burns as result.
- Allow to cool parts.
 - Wear protective gloves.






3.1.8 Fitting accessories

Special notes on mounting


SA..31...

	Danger! Danger to life from electrical current! There is an immediate risk of fatal injury in case of contact with live parts of SA..31... • Disconnect actuator from power.
--	---


1. Actuator is mechanically connected to a Siemens valve.
2. Observe compatibility and choice of combinations. Refer to "Accessories" (page 17).
3. Disconnect actuator from power.
4. Only required with actuators without fail safe function: Using the manual adjuster, drive the actuator's stem to the fully retracted position and fix the coupling. See "Manual operation" and "Fixing coupling" (page 45).
5. When mounting two different accessories watch out for correct plug-in space A or B (see below).
6. To fit an auxiliary switch, potentiometer or function module, the housing cover must be removed.





Interior view of setting elements and plug-in spaces



A	Plug-in space for... <ul style="list-style-type: none">• Potentiometer ASZ7.5/.., or• Auxiliary switch ASC10.51
B	Plug-in space for... <ul style="list-style-type: none">• Function module AZX61.1 , or• Auxiliary switch ASC10.51
C	LED
D	DIL switches
E	Calibration slot
F	Connection terminals

Potentiometer**ASZ7.5/..**

4040U08

Scope of delivery		
1 potentiometer ASZ7.5/..	1 screw	2 screw covers
 4040U08	1 pc. 	 4040U29




First, observe "Special notes on mounting" (page 33).


**Danger!****Danger to life from electrical current!**

If a live wire gets in contact with the screws the whole actuator housing is a live.


- Fit the screw covers first.

Plug-in space A






**Function module
AZX61.1**




Plug-in space B



First, observe "Special notes on mounting" (page 33).



**Auxiliary switch
ASC10.51**



4040U07

Scope of delivery		
1 auxiliary switch ASC10.51	1 screw	2 screw covers
 4040U07	1 pc.  4040U28	 4040U29



First, observe "Special notes on mounting" (page 33).




Danger!


Danger to life from electrical current!

If a live wire gets in contact with the screws the whole actuator housing is a live.

- Fit the screw covers first.

Plug-in space A







First, observe "Special notes on mounting" (page 33).

	Danger! Danger to life from electrical current! If a live wire gets in contact with the screws the whole actuator housing is a live. <ul style="list-style-type: none"> • Fit the screw covers first.
---	---

Plug-in space B




5 Adjust switch position (refer also to "Manual operation" page 60)




6 No.: 1

When initial situation: $0\ \Omega$



When initial situation: $\infty\ \Omega$




7 Observe "Wiring" (page 40)

8 Observe "Connection terminals" (page 68)

Stem heating element


ASZ6.6



Scope of delivery	
1 stem heating element ASZ6.6	1 screw
	1 pc. M4 x 30 incl. nut


When fitting the stem heating element, stroke actuator and valve must be assembled. The stem heating element is powered separately.

First, observe "Special notes on mounting" (page 33).



Weather shield

ASK39.1




First, observe "Special notes on mounting" (page 33).

Scope of delivery	
Weather shield ASK39.1	2 UV-proof cable ties

Notes

- To protect the actuator when used outdoors, the weather shield must always be fitted.
- If fitted several times, 2 UV-proof cable ties (800 x 4 mm) must be used.
- The manual adjuster cannot be used when the weather shield is mounted.





3.1.9 Wiring (installation)

Conduct the electrical connections in accordance with local regulations on electrical installations as well as the "Connection diagrams" on page 68.

Preparation of wire endings

The cable endings must be prepared before as follows.




A	EU: M20 US: 1/2"	Standard	Connection actuator
B	EU: M25 US: 1/2"	Ground cable for outdoor installation	
C	EU: M20 US: 1/2"		Connection accessories

Cable glands (not contained in scope of delivery)		
Metric	Metric	Inch thread
M20	M25	1/2"


Prior to installation, the following preconditions must be satisfied:

- Actuator is mechanically connected to a Siemens valve.
- Housing cover is removed (step 6 "Special notes on mounting", page 33).

Actuator




**Auxiliary switch
ASC10.51**




4040U07

and

**Potentiometer
ASZ7.5/..**



4040U08



3.2 Commissioning and operation

3.2.1 Function check and Calibration

Mechanically

Before making the function check, the following preconditions must be satisfied:

- Environmental conditions specified in chapter "Technical data" (page 64)
- Actuator is mechanically connected to a Siemens valve
- **Actuator is in "Manual operation" mode** (page 60).

The actuator can be operated with the help of the "Manual adjuster" (see page 60).

Manual adjuster	Stroke actuator	Rotary actuator	Control path valve A → AB	Bypass valve B → AB
Turning in clockwise direction	Actuator's stem extends	Actuator's spindle turns in clockwise direction	Opening	Closing
Turning in counter-clockwise direction	Actuator's stem retracts	Actuator's spindle turns in counterclockwise direction	Closing	Opening

Notes

- Ensure that the actuator's and valve's stem, or actuator's and valve's spindle are securely connected in all positions.
- If the actuator is forced to travel beyond its end positions, overload protection responds.
- Observe information given in chapter "Acting direction and flow characteristic" on page 53.

Electrically

Before making the function check, the following preconditions must be satisfied:

- Environmental conditions specified in chapter "Technical data" (page 64).
- Actuator is mechanically connected to a Siemens valve.
- **Actuator is in "Automatic" mode** (page 60).
- Actuator and, if required, accessories are correctly fitted and connected. Also refer to "Connection terminals" (page 68).
- Power is applied.


SA..61..

Calibration is required with modulating actuators and SA..61.. before the function check.

General notes on calibration

Before making the calibration, the following preconditions must be satisfied:

- A description of the calibration function is given in chapter "Calibration" (page 53).
- Housing cover is removed (step 6 "Special notes on mounting", page 33).



If required, calibration can be repeated any number of times.

Make the function check for modulating actuators after the calibration with a point test according to the following table:

Connection terminals	Stroke actuator	Rotary actuator	Control path valve A → AB	Bypass valve B → AB	Position feedback U
Y 6 V 13.6 mA	Actuator's stem extends (60%)	Actuator's spindle turns in clockwise direction (60 %)	Opening	Closing	6 V
Y 5 V 12 mA	Actuator's stem retracts (50%)	Actuator's spindle turns in counterclockwise direction (50 %)	Closing	Opening	5 V
"Z" connected to "G"	Actuator's stem extends	Actuator's spindle turns in clockwise direction	Opening	Closing	10 V
"Z" connected to "G0"	Actuator's stem retracts	Actuator's spindle turns in counterclockwise direction	Closing	Opening	0 V

SA..31.. and SA..81..


Make the function check for 3-position actuators according to the following table:

Connection terminals	Stroke actuator	Rotary actuator	Control path valve A → AB	Bypass valve B → AB
Voltage at Y1	Actuator's stem extends	Actuator's spindle turns in clockwise direction	Opening	Closing
Voltage at Y2	Actuator's stem retracts	Actuator's spindle turns in counter-clockwise direction	Closing	Opening
No voltage at Y1 and Y2	Actuator's stem maintains the position	Actuator's spindle maintains the position	Maintains the position	

Notes

- If function module AZX61.1 is used, observe information given in chapter "Changeover of acting direction" (page 51).
- Observe information given in chapter "Acting direction and flow characteristic" on page 53.


Auxiliary switch
ASC10.51



4040U07

Make the function check for mounted auxiliary switches according to the following table – example switching point at 25% position:

Connection terminals	Stroke actuator	Rotary actuator	Terminal S1 – S3	Terminal S1 – S2
Voltage at Y2	Y = 0 V	Actuator's stem retracts (until end position is reached)	Actuator's spindle turns in counter-clockwise direction (until end position is reached)	-
No voltage at Y1 und Y2	Y = 0 V	Actuator's stem maintains the position	Actuator's spindle maintains the position	— ● ● — ● ● —
Voltage at Y1 for desired valve position % + 2% x positioning time Example: SAX31.00 = 27% x 120 sec = 32.5 sec	Valve position % + 2% Y = 2.7 V	Actuator's stem extends to desired position (27%)	Actuator's spindle turns in clockwise direction to desired position (27%)	— ● ● — ● ● —
Check switching point with voltmeter	Actuator's stem maintains the position	Actuator's spindle maintains the position	-	-



Make the function check for mounted potentiometer according to the following table
(Example values for ASZ7.5/1000):

Connection terminals	Stroke actuator	Rotary actuator	Terminal P1 – P2	Terminal P2 – P3
Voltage at Y2	Actuator's stem retracts (until end position is reached)	Actuator's spindle turns in counter-clockwise direction (until end position is reached)	-	-
No voltage at Y1 und Y2	Actuator's stem maintains the position	Actuator's spindle maintains the position	< 1 Ω	> 996 Ω
Voltage at Y1 for desired valve position % positioning time Example: SAX31.00 = 75% x 120 sec = 90 sec	Actuator's stem extends to desired position (75%)	Actuator's spindle turns in clockwise direction to desired position (75%)	-	-
Check position value with ohmmeter	Actuator's stem maintains the position	Actuator's spindle maintains the position	~ 560 Ω	~ 436 Ω
Voltage at Y2 for desired change of valve position % x positioning time Example: SAX31.00 = 10% x 120 sec = 12 sec	Actuator's stem retracts to desired position (65%)	Actuator's spindle turns in counter-clockwise to desired position (65%)	-	-
Check position value with ohmmeter	Actuator's stem maintains the position	Actuator's spindle maintains the position	~ 485 Ω	~ 511 Ω

3.2.2 Maintenance

The actuators are maintenance-free.

3.2.3 Disposal


The device is considered an electronics device for disposal in terms of European Directive 2012/19/EU and may not be disposed of as domestic garbage.

- Dispose of the device through channels provided for this purpose.
- Comply with all local and currently applicable laws and regulations.



4 Functions and control

4.1 3-position control



A 3-position signal drives the actuator via connection terminals Y1 or Y2. The required position is transferred to the valve.

1	A/D conversion	
2	Control functions	Identification of seat
		Control of direction
		Motor control
		Manual adjustment
3	Brushless DC motor	
4	Gear train	
	Manual adjuster	

Positioning signal	Stroke actuator	Rotary actuator	Control path valve A → AB	Bypass valve B → AB
Voltage at Y1	Actuator's stem extends	Actuator's spindle turns in clockwise direction	Opening	Closing
Voltage at Y2	Actuator's stem retracts	Actuator's spindle turns in counter-clockwise direction	Closing	Opening
No voltage at Y1 and Y2	Actuator's stem maintains the position	Actuator's spindle maintains the position	Maintains the position	


Note

Observe information given in chapter "Acting direction and flow characteristic" on page 53.

Internal control ensures very constant positioning times and determination of the actuator's position.

Positioning times stroke model


The specified positioning times refer to the respective nominal stroke / nominal angular rotation. Since the end positions of rotary actuators are inside the actuator, the following remarks refer to stroke actuators.
The resulting effective strokes vary, depending on the type of valve, resulting in shorter or longer actuator positioning times.



Notes

Deviations occur...

- after several positioning signals Y1 and Y2 in the same direction since the stroke movement starts with a delay of 300 ms.
- when positioning signals Y1 and Y2 are active for less than 300 ms since the stroke movement cannot be made in that case.



Accurate position feedback is made possible with the help of a potentiometer (page 62).

4.1.1 Combination with RVD.. controller for direct domestic hot water distribution by heat exchanger

The design based slow reaction on control signals of SAX31.., SAX81.., SAV31.. and SAV81.. actuators doesn't allow the actuator to react on very short control pulses. Only control pulses with a length greater than 400 ms allow a sufficient reaction.


Especially the direct domestic hot water control does not allow such long control pulses. The specific optimized control loops – equipped with an SIGMAGYR RVD.. controller and Acvatix SQS359.05 actuator – work with pulses down to 40 ms.

SAX31.. and SAX81.. are not able to work with these short pulses.

The following table gives alternatives which actuators can be used within these control loops.

Controller	Plant type	Prefered actuator	Valve line	DN	kvs
RVD130	4 und 5	SQS35.03	VVG55..	DN15 ..25	0.25 .. 6.3
RVD135/109		SAS31.03			
RVD135/309		SQS359.05	VVG549..	DN15 ..25	0.25 .. 6.3
RVD140		SAT31.008			
RVD144/109		SQS359.54	VVG549..	DN15 ..25	0.25 .. 6.3
RVD145/109		SAT31.51			
RVD139		SKD32.21	VVG41.. VVF53..	DN15 ..50	0.63 .. 40 0.16 .. 40
RVD230	x- 4	SQS35.03	VVG55..	DN15 ..25	0.25 .. 6.3
RVD235/109		SAS31.03			
RVD250		SQS359.05	VVG549..	DN15 ..25	0.25 .. 6.3
RVD255/109		SAT31.008			
RVD240		SQS359.54	VVG549..	DN15 ..25	0.25 .. 6.3
RVD245/109		SAT31.51			
RVD260		SKD32.21	VVG41.. VVF53..	DN15 ..50	0.63 .. 40 0.16 .. 40
RVD265/109		SKD32.21E	VVG41.. VVF53..	DN15 ..50	0.63 .. 40 0.16 .. 40

4.2 Modulating control



The modulating positioning signal drives the actuator steplessly. The positioning signal range (DC 0...10 V / DC 4...20 mA, 0...1000 Ω) corresponds in a linear manner to the positioning range (fully closed...fully open, or 0...100 % stroke).

The actuator is driven via connection terminal Y or forced control Z (page 58). The required stroke / rotation is transferred to the valve's stem / spindle.

1	Calibration slot	
2	LED (2 colors)	
3	DIL switches	Changeover of characteristic
		Positioning signal
4	Function module	
5	A/D conversion	
6	Power supply	
7	Control functions	Identification of seat
		Position control
		Motor control
		Detection of foreign bodies
		Calibration
		Forced control
		Characteristics function
		Manual adjustment
8	Brushless DC motor	
9	Gear train	
	Manual adjuster	


Positioning signal	Stroke actuator	Rotary actuator	Control path valve A → AB	Bypass valve B → AB
Signal Y, Z increasing	Actuator's stem extends	Actuator's spindle turns in clockwise direction	Opening	Closing
Signal Y, Z decreasing	Actuator's stem retracts	Actuator's spindle turns in counterclockwise direction	Closing	Opening
Signal Y, Z constant	Actuator's stem maintains the position	Actuator's spindle maintains the position	Maintains the position	

Notes

- If function module AZX61.1 is used, observe the information given in chapter "Changeover of acting direction" (page 51).
- Observe the information given in chapter "Acting direction and flow characteristic" on page 53.

4.3 Function module AZX61.1

DIL switches



	Acting direction	Sequence control
OFF ¹⁾	ON 1 2 4040Z10	ON 1 2 4040Z12 Sequence control not active
ON ¹⁾	ON 1 2 4040Z9	ON 1 2 4040Z11 Sequence control (signal adaptation)

¹⁾ Factory setting: All switches set to OFF

4.3.1 Sequence control (signal adaptation)

DIL switches

	Sequence control
ON ¹⁾	ON 1 2 4040Z11 Sequence control (signal adaptation)

¹⁾ Factory setting: All switches set to OFF

HEX switches


Nr.: 1	Setting sequence control			
Rotary switches LO and UP are used to set the starting point or working range of a sequence.				
Position "LO"	Starting point	Position "UP"	Working range	
0	0,3 V	0	9,4 V	
1	1 V	1	3 V	
2	2 V	2	4 V	
3	3 V	3	5 V	
4	4 V	4	6 V	
5	5 V	5	7 V	
6	6 V	6	8 V	
7	7 V	7	9 V	
8	8 V	8	10 V	
9	9 V	9	12 V	
A	10 V	A	14 V	
B	11 V	B	16 V	
C	12 V	C	18 V	
D	13 V	D	20 V	
E	14 V	E	25 V	
F	15 V	F	30 V	
Invalid HEX switches combinations				
LO	0	1	2	3
UP	F	F	F	F
UP			E	E
UP			E	E
UP			F	F
UP			F	F
UP				F

Notes

- Can only be used with voltage input.
- Maximum input voltage is DC 30 V. If the configuration is invalid, the actuator operates on DC 0...10 V.

Examples

4040Z29



Legend diagram	Positioning signal range	Position LO	Position UP	Position feedback U
A	DC 2...10 V	2	6	DC 0...10 V
B	DC 0...5 V	0	3	DC 0...10 V
C	DC 12...17 V	C	3	DC 0...10 V
H	Stroke or rotary angle			
—	Acting direction: Direct (A, B, C)			
- - -	Acting direction: Reverse (A', B', C')			

4.3.2 Changeover of acting direction

DIL switches


Acting direction		
OFF ¹⁾	 Direct acting positioning signal Y or Z	 Reverse acting positioning signal Y or Z

¹⁾ Factory setting: All switches set to OFF


Selecting the acting direction

- With valves whose stem is extended in the fully closed position, "direct acting" means that the valve is fully closed (0 %) when positioning signal $Y = 0 \text{ V}$ resp. $Z = 0 \Omega$. This applies to all Siemens valves according to "Equipment combinations" (page 12).
- With valves whose stem is retracted in the fully closed position, "direct acting" means that the valve is fully open (100 %) when positioning signal $Y = 0 \text{ V}$ resp. $Z = 0 \Omega$.


SAX61.03
SAV61.00



SAY61P03
SAX61P03
SAV61P00




4.4 Positioning signal and flow characteristic selection




	Positioning signal "Y"	Position feedback "U"	Flow characteristic	
OFF ¹⁾	ON 1 2 4040Z10	DC 0...10 V	ON 1 2 4040Z12	log = equal-percentage
	ON 1 2 4040Z09	DC 4...20 mA	ON 1 2 4040Z11	lin = linear

¹⁾ Factory setting: All DIL switches set to OFF Ω

Flow characteristic
SAX61.03 / SAV61.00
with VVF..





Flow characteristic
SAY61P03 / SAX61P03 /
SAV61P00 with VPF..



4.5 Acting direction and flow characteristic


The selection of changeover of acting direction and characteristic with the DIL switches depends on the type of actuator (with or without fail safe function) and the associated type of valve (valve characteristic, push to open, pull to open).


When the positioning signal increases (DC 0...10 V, DC 4...20 mA, 0...1000 Ω), the objective is to have the valve's volumetric flow V rising, but to fully open the valve, $V = 100\%$ (NO = normally open), or to fully close it, $V = 0\%$ (NC = normally closed) in the event of a power failure.

			
 4040235	DIL switches	Acting direction	Direct Reverse
		Flow characteristic	Linear Equal-percentage
	Without fail safe function	No power applied	Maintains the position

4.6 Position Feedback U

The position feedback U (DC 0...10 V) is always proportional to stroke H of the actuator's stem.





4.7 Position control with ClosedPosition-Synchronisation

Within SAX/SAV/SAL61/SAY61.. actuators the position control works based on the HALL-sensor pulses from the brushless DC-motor calculating with an internal stroke model calculating the actual position. This kind of control is more accurate and wearless compared with a physical element for position measurement and grants a precise position control with high resolution.

During manual operation the motor is declutched from the gear train and the internal position control get's not sensor pulses. So real position will deviate from the internally calculated position. As a consequence the position feedback on terminal U is set to "0V" during manual operation.


To grant – after manual operation – that real mechanical position and internal position control are matching all SA..61.. operate after manual operation an automatic ClosedPosition-Synchronisation.

4.7.1 ClosedPosition-Synchronisation

Returned into automatic operation the actuator runs for 0.5.. 2 s into opening direction to grant secure closed-position detection. Then the actuator runs into closed position (seat A-AB in the valve). Reaching the closed position the internal stroke model is synchronized. Positioning signal, position feedback and meachnical position now match perfectly again.

With this function it's granted that the position feedback U – which was zero during manual operation and synchronization - always represents the real mechanical position of the actuator.

After synchronization the actuator follows the control signal again.



4.7.1.1 Active forced position input on Z

If after return to automatic mode a signal on Z is active (GND, AC/DC 24 V or 0...1000 Ohm) the ClosedPosition-Synchronisation is deactivated as long as the signal on Z remains.

After Z is deactivated the ClosedPosition-Synchronisation will be performed.

Note

ClosedPosition-Synchronisation is only automatically activated after manual operation. A power failure does not activate this function automatically, to avoid that all actuators in a section close in parallel.


If the customer likes synchronization also after a power failure he should take care that the plant restarting routine drives the actuator automatically into an end position. This will also synchronizes the internal position control and the real position.

4.8 Calibration

To match the actuator to production-related mechanical tolerances of the individual valves, accurate positioning and position feedback must be ensured, if calibration is performed when the plant is commissioned (page 42). During commissioning, the actuator detects the valve's end positions and files the exact stroke in its internal memory.

Calibration takes place in the following phases:

- Actuator drives to H_0 (1), valve closes. Detection of upper end position.
- Actuator drives to H_{100} (2), valve opens. Detection of lower end position.
- The detected values are stored (3). Then the actuator follows the positioning signal.



Note

- Observe status indication (LED) during and after calibration (page 61).
- If the actuator does not detect the second end position within an appropriate stroke range (max. 25 mm), the first end stop will be adopted and the actuator operates with a working range of 20 mm.

4.9 Signal priorities

The actuators are controlled via different interlinked positioning signal paths (positioning signal "Y", forced control input "Z", manual adjuster). The signal paths are assigned the following priorities:

Priority	Description	
1 (highest)	The manual adjuster always has priority 1, thus overriding all signals active at "Z" or "Y", independent of whether or not power is applied.	
2	Only SA..61... As soon as a valid positioning signal is active at input "Z", the position is determined via positioning signal "Z" (forced control). Prerequisite: The manual adjuster is not used.	Z
3 (lowest)	The position is determined via positioning signal "Y". The manual adjuster is not used and on Z there is no active signal.	Y

Examples

Manual adjuster	Forced control (Z)	Positioning signal (Y)	Stroke actuator	Rotary actuator
Automatic mode	Not connected	5 V	Actuator's stem travels to position (50%)	Actuator's spindle travels to position (50%)
Automatic mode	G	3 V	Actuator's stem extends	Actuator's spindle turns in clockwise direction
Automatic mode	G0	3 V	Actuator's stem retracts	Actuator's spindle turns in counter-clockwise direction
Operated (30%) and engaged	G	8 V	Actuator's stem retracts manual (to 30%)	Actuator's spindle turns manual in counterclockwise direction (to 30%)

Bold printing = positioning signal currently active

4.10 Detection of valve seat

The actuators feature force-dependent valve seat detection. After calibration, the exact valve stroke is filed in the actuator's memory. When the actuator reaches the respective end of stroke, it does not hit the valve's seat at full speed, but stops for 5 seconds at about 1% before the stored position is reached. If the positioning signal stays at 0% or 100%, the actuator travels to the calculated end position at reduced positioning speed and builds up the required nominal force.

This function extends the actuator's service life since the dynamic forces are reduced when approaching the valve seat and there will be less strain on the gear train.

In addition, the actuator's oscillations in the case of instable control are suppressed.

If no force is built up in the calculated end position (e.g. in the event of temperature effects for instance), the actuator continues to operate at a reduced positioning speed until the nominal positioning force is restored. This ensures that the valve always fully closes.

After a power failure, valve seat identification is not active – the actuators define their stroke position on power restoration to be at 50%. From now on, the actuator follows the positioning signal.

When the valve plug reaches its seat for the first time, the actuator readjusts its stroke model.

Example

The supposed position is 50%, Y = 2 V, the actuator travels 30% of the stored valve stroke in the direction of "Actuator's stem retracted".

If the actuator reaches the seat within this 30% travel, it interprets the position as "Valve fully closed" and shifts the position of the valve's stroke accordingly without changing the extent of travel.

From now on, the actuator follows the changed valve stroke position.


This means: New position 0%, Y = 2 V, actuator travels 20% of the stored valve stroke in the direction "Actuator's stem extended".

4.11 Detection of foreign bodies

The actuator detects when the valve is clogged and adjusts its operational behavior accordingly to prevent damage to itself or the valve.

If the actuator hits an obstacle within the calibrated stroke and is not able to overcome it with its nominal positioning force, it stores the position at which the obstacle was hit. Depending on the direction of travel, as ...

- "Lower limit of valve clogging", if the clogging was detected when traveling in the direction of "Actuator's stem retracting".
- "Upper limit of valve clogging", if the clogging was detected when traveling in the direction of "Actuator's stem extending".










Now, the status LED blinks green and the actuator only follows the positioning signal between the positions "Actuator's stem retracted" and "Upper limit of valve clogging" or "Actuator's stem extended" and "Lower limit of valve clogging".

After detection of clogging, 3 attempts are made to overcome clogging by traveling about 15% in the opposite direction and then trying again to overcome the position of clogging. If the attempts made are unsuccessful, the actuator continues to follow the positioning signal within the restricted range only and the LED continues to blink green (refer to "Indicators" on page 61).

4.12 Forced control Z

SA..61.. only

Forced control is affected by changeover of acting direction. It uses the following operating modes:

	Z-mode			
	No function	Fully open	Fully closed	Overriding positioning signal "Y" by 0...1000 Ω
Connections	 	 	 	 
Transmission	Equal-percentage or linear characteristic		Equal-percentage or linear characteristic	
	Contact "Z" not connected, valve follows positioning signal "Y"	Contact "Z" is connected directly to "G", positioning signal "Y" has no impact	Contact "Z" is connected directly to "G0", positioning signal "Y" has no impact	Contact "Z" is connected to "M" via resistor "R", starting point at 50 Ω, end point at 900 Ω, positioning signal "Y" has no impact

Note

The operating modes "Z" shown are based on factory setting "direct acting" and a "push to open" valve.

4.13 Technical and mechanical design

4.13.1 Transmission of power


Function principle

Incoming positioning signals are translated to positioning commands for the motor.


A gear train transmits the motor's positioning steps to the output stage (valve coupling). Attached to the gear train are the electrical and mechanical accessory items and the manual adjuster.

In the case of the rotary actuators, the adjustment to the required torque is made in the output stage. With the stroke actuators, the translation from rotary to stroke movement takes place in the output stage.



SAL..



SAX.., SAV..




4.13.2 Coupling


SAX.., SAV..	SAL..
 <p>The stem coupling (1) and neck coupling (2) ensures full backward compatibility with all types of Siemens large-stroke valves produced since 1975.</p>	 <p>Mounting sets are available for use with butterfly and slipper valves.</p>

4.13.3 Manual adjuster


Automatic

	<p>When the motor drives the manual adjuster turns. Thus in automatic mode, the manual adjuster is used for indication of travel. If the manual adjuster is held firm in this mode, there is no transmission of power to the gear train.</p>
--	--


Manual operation

	<p>When pushing the manual adjuster down (1), it engages and the actuator can be manually operated.</p> <p>Stroke actuator: When turning the manual adjuster in clockwise / counterclockwise direction (2), the actuator's stem retracts / extends.</p> <p>Rotary actuator: The actuator spindle turns in the same direction.</p> <p>An overload protection prevents damage to the manual adjuster</p>
---	--


Fixing the position

	<p>Upon actuation and locking the slide switch, the manual adjuster remains engaged.</p> <p>When in this mode, do not turn the manual adjuster.</p>
---	---

Disengaging the fixing

	<p>When resetting the slide switch, the manual adjuster returns to automatic mode.</p> <p>->The modulating SA..61.. will automatically start a Zero Position Synchronisation</p>
---	---

4.13.4 Indicators



A	Indication of travel	
B	Scale	Position indication
C	Indicator	
D	LED Status indication	

4040J32

Operational status indication



In Automatic mode, the manual adjuster serves for the indication of travel. See "Automatic" (page 60).

Position indication

Position indication is on 2 opposite sides. When turning the manual adjuster, the indicator moves in the same direction.

The scale indicates the stroke. When reaching the stops, the valve is either fully open or fully closed.

Status indication (LED)

Housing cover fitted	Housing cover removed
 4040J34	 4040J33

When the housing cover is fitted, the LED can be viewed through a light conductor.


When the housing cover is removed, the LED can be viewed through a hole.

The status indication informs about the operational state of the actuator.

LED	Indication	Operating state	Remarks, troubleshooting
Green	On	Automatic mode	Normal operation
	Blinking	Calibration (page 42).	Wait until calibration is finished (then green or red light)
		In manual mode	Manual adjuster in MAN position
		Detection of foreign bodies (page 57)	Check valve / actuator
Red	On	Calibration error	Start calibration again (page 42)
	Blinking	Clogged valve	Check valve
Dark	Dark	No power or electronics faulty	Check operating voltage


4.13.5 Electrical accessories

Auxiliary switch ASC10.51



4040U07

The auxiliary switch ASC10.51 switches on or off when a certain position is reached. The switching point can be set between 0...100%.



Application example:


When using an auxiliary switch, position feedback can trigger an automatic stop of the circulating pump in the end position "Fully closed".

Potentiometer ASZ7.5/..



4040U08


Potentiometer ASZ7.5/.. (1000 Ω , 200 Ω , 135 Ω) delivers an ohmic value to the controller giving the exact position of the actuator (continuous position feedback). A slip clutch prevents damage to the potentiometer in the mechanical end positions. This is also used for accurate balancing of the potentiometer in the fully closed position.



Flow characteristic

The end values of the potentiometers refer to the maximum stroke / maximum angular rotation of the actuators. For this reason, the resulting values in operation deviate, depending on the type of valve used in combination with the actuator. The potentiometer's starting point can be very accurately adjusted during installation (refer page 34).

	ASZ7.5/135	ASZ7.5/200	ASZ7.5/1000
	104 Ohm at nominal stroke/nominal angular rotation	154 Ohm at nominal stroke/nominal angular rotation	770 Ohm at nominal stroke/nominal angular rotation
	$R = 0 + 1.04 \text{ Ohm} \times \text{nominal stroke/nominal angular rotation (\%)}$	$R = 0 + 1.54 \text{ Ohm} \times \text{nominal stroke/nominal angular rotation (\%)}$	$R = 0 + 7.7 \text{ Ohm} \times \text{nominal stroke/nominal angular rotation (\%)}$
SAX..	$R = 0 + 5.2 \text{ Ohm} \times \text{stroke (mm)}$	$R = 0 + 7.71 \text{ Ohm} \times \text{stroke (mm)}$	$R = 0 + 38.5 \text{ Ohm} \times \text{stroke (mm)}$
SAV..	$R = 0 + 2.6 \text{ Ohm} \times \text{stroke (mm)}$	$R = 0 + 3.5 \text{ Ohm} \times \text{stroke (mm)}$	$R = 0 + 19.3 \text{ Ohm} \times \text{stroke (mm)}$
SAL..	$R = 0 + 1.15 \text{ Ohm} \times \text{rotary angle (\textdegree)}$	$R = 0 + 1.71 \text{ Ohm} \times \text{rotary angle (\textdegree)}$	$R = 0 + 8.55 \text{ Ohm} \times \text{rotary angle (\textdegree)}$




Function module**AZX61.1**

4040U09

Function module AZX61.1 offers the following choices for changing control:


- Changeover of acting direction (page 51)
- Sequence control (page 49)

Stem heating element**ASZ6.6**

4040U10


Stem heating element ASZ6.6 prevents the formation of ice on the stem when medium temperatures drop below 0 °C. It is suited for universal use with valves having a stem diameter of 10 or 14 mm.

- The stem heating element heats up to 120 °C.**
- This is a PTC element, which means it shows up with a low resistance at power up – inrush current may reach 13 A at low temperatures / high voltage level**

4.13.6 Mechanical accessories**Weather shield****ASK39.1**

4040U11

Weather shield ASK39.1 protects the actuator when installed outdoors. This does not lead to a change of IP class (IP54).

Mounting sets**ASK3..N**

4040U15

Mounting sets ASK31N, ASK33N and ASK35N enable the actuators to be fitted to slipper valves VBF21.., DN65...150 and butterfly valves VKF41.. and VKF45 (page 25-32).

5 Technical data

		SAY..	SAX..	SAV..	SAL..
Power supply	Operating voltage				
	SA..31..	AC 230 V ± 15 %			
	SA..61..	AC 24 V ± 20 % / DC 24 V + 20 % / -15 % (SELV)			
	SA..81..	AC 24 V ± 20 % / DC 24 V + 20 % / -15 % (SELV)			
	Frequenz	45...65Hz			
	External supply line protection (EU)		<ul style="list-style-type: none"> • 6 A...10 A slow • Circuit breaker max. 13 A Characteristic B, C, D according to EN 60898 • Power source with current limitation of max. 10 A 		
	Power consumption at 50 Hz				
	SAX31.00 Stem retracts / extends	3.5 VA / 2 W			
	SAX31.03 Stem retracts / extends	6 VA / 3.5 W			
	SAX61.03.. Stem retracts / extends	8 VA / 3.75 W			
	Holding state	3.5 VA / 1.5 W	-	-	-
	SAX81.00.. Stem retracts / extends	3.5 VA / 2.25 W			
	SAX81.03.. Stem retracts / extends	5 VA / 3.75 W			
	SAV31.00.. Stem retracts / extends		6.5 VA / 4 W		
	SAV61.00.. Stem retracts / extends		9.5 VA / 4.5 W		
	SAV81.00.. Stem retracts / extends		7 VA / 4.5 W		
	SAL31.00T10 Rotary actuator turns			3.5 VA / 2 W	
	SAL31.00T20 Rotary actuator turns			4.5 VA / 2.75 W	
	SAL31.00T40 Rotary actuator turns			7 VA / 4 W	
	SAL31.03T10 Rotary actuator turns			5.5 VA / 3.25 W	
	SAL61.00T10 Rotary actuator turns			5 VA / 2.5 W	
	Holding state			3.5 VA / 1.5 W	
	SAL61.00T20 Rotary actuator turns			6 VA / 2.75 W	
	Holding state			3.5 VA / 1.5 W	
	SAL61.00T40 Rotary actuator turns			9 VA / 4 W	
	Holding state			3.5 VA / 1.5 W	
	SAL61.03T10 Rotary actuator turns			7.5 VA / 3.5 W	
	Holding state			3.5 VA / 1.5 W	
	SAL81.00T10 Rotary actuator turns			3 VA / 2 W	
	SAL81.00T20 Rotary actuator turns			4 VA / 2.75 W	
	SAL81.00T40 Rotary actuator turns			6 VA / 3.75 W	
	SAL81.03T10 Rotary actuator turns			5 VA / 3.5 W	
	SAY31P03 Stem retracts / extends	6 VA / 3.5 W			
	SAY61P03 Stem retracts / extends	8 VA / 3.75 W			
	Holding state	3.5 VA / 1.5 W			
	SAY61.03U Stem retracts / extends	8 VA / 3.75 W			
	Holding state	3.5 VA / 1.5 W			
	SAY81P03 Stem retracts / extends	5 VA / 3.75 W			
	SAY81.03U Stem retracts / extends	5 VA / 3.75 W			

		SAY..	SAX..	SAV..	SAL..
Function data	Positioning times with specified nominal stroke / nominal angular rotation SAX..00, SAV.., SAL..00 SAY..03, SAX..03, SAL..03 Positioning force Torque SAL..T10 SAL..T20 ⁴⁾ SAL..T40 ⁴⁾ Nominal stroke Angular rotation	120 s 30 s 200 N - - 15 mm -	120 s 30 s 800 N - - 20 mm -	120 s - 1600 N - - 40 mm -	120 s 30 s 10 Nm running 20 Nm running 40 Nm running - 90°
Signal inputs	Positioning signal "Y" SA..31.., SA..81.. SA..31.. Voltage SA..81.. Voltage SA..61.. (DC 0...10 V) Current draw Input impedance SA..61.. (DC 4...20 mA) Current draw Input impedance	3-position AC 230 V ± 15 % AC 24 V ± 20 % / DC 24 V + 20 % / -15% ≤ 0,1 mA ≥ 100 kΩ DC 4...20 mA ± 1 % ≤ 500 Ω			
Parallel operation	SA..61..	≤ 10 (depending on controller output)			
Forced control	Positioning signal "Z" SA..61.. R = 0...1000 Ω Z connected to G Z connected to G0 Voltage Current draw	R= 0...1000 Ω, G, G0 Stroke / rotation proportional to R Max. stroke 100% ¹⁾ Min. stroke 0% ¹⁾ Max. AC 24 V ± 20 % Max. DC 24 V + 20 % / -15% ≤ 0,1 mA			90° ¹⁾ 0° ¹⁾
Position feedback	Position feedback U SA..61.. Load impedance Load	DC 0...10 V ± 1 % >10 kΩ res. Max. 1 mA			
Connecting cable	Wire cross-sectional areas Cable entries SA.. SA..U	0.13...1.5 mm ² , AWG 24...16 ²⁾	EU:	2 entries Ø 20.5 mm (for M20) 1 entry Ø 25.5 mm (for M25)	
			US:	3 entries Ø 21.5 mm for ½" tube connection	
Degree of protection	Housing from vertical to horizontal	IP54 as per EN 60529 ³⁾			
	Insulation class Actuators SA..31.. AC 230 V Actuators SA..61.. AC / DC 24 V Actuators SA..81.. AC / DC 24 V	As per EN 60730 II III III			
Environmental conditions	Operation Climatic conditions Mounting location Temperature General Humidity (noncondensing)	IEC 60721-3-3 Class 3K5 Indoors (weather-protected) -5...55 °C 5...95 % r.h.			-15...55 °C
	Transport Climatic conditions Temperature Humidity	IEC 60721-3-2 Class 2K3 -25...70 °C <95 % r.h.			
	Storage Climatic conditions Temperature Humidity	IEC 60721-3-1 Class 1K3 -15...55 °C 5...95 % r.h.			
	Max. media temperatur when mounted on valve	120 °C	130 °C	130 °C ⁵⁾	120 °C

¹⁾ Observe acting direction of DIL switches

²⁾ AWG = American wire gauge

³⁾ Also with weather shield ASK39.1

⁴⁾ SAL.T20 / T40 have a minimum holding torque of 14 Nm

⁵⁾ Up to 150 °C with horizontal mounting position

		SAY..	SAX..	SAV..	SAL..
Directives and Standards	Product standard	EN60730-x			
	Electromagnetic compatibility (Application)		For residential, commercial and industrial environments		
	EU Conformity (CE)	A5W00000333 ¹⁾	CE1T4501x1 ¹⁾ CE1T4501x2 ¹⁾	CE1T4503xx ¹⁾	CE1T4502X1 ¹⁾ CE1T4502X2 ¹⁾
	RCM Conformity AC 230 V	A5W00000334 ¹⁾	CE1T4515X4 ¹⁾	CM1T4503_C1 ¹⁾	-
UL, cUL	AC 230 V AC/DC 24 V	-	UL 873 http://ul.com/database		
Environmental compatibility		The product environmental declarations contain data on environmentally compatible product designs and assessments (RoHS compliance, materials composition, packaging, environmental benefit, disposal):	7173310559Ben ¹⁾	7173310559Ben ¹⁾	7173310522A ¹⁾
Dimensions		See "Dimensions" (page 70)			
Weight	Excl. packaging	See "Dimensions" (page 70)			
Accessories ²⁾	Potentiometer ASZ7.5/135	0...135 Ω ± 5 %			
	Voltage Current rating	DC 10 V (SELV) < 4 mA			
	Potentiometer ASZ7.5/200	0...200 Ω ± 5 %			
	Voltage Current rating	DC 10 V (SELV) < 4 mA			
	Potentiometer ASZ7.5/1000	0...1000 Ω ± 5 %			
	Voltage Current rating	DC 10 V (SELV) < 4 mA			
	Auxiliary switch ASC10.51	AC 24...230 V, 6 (2) A, floating			
	Switching capacity External supply line protection US installation, UL & cUL	See section power supply AC 24 V class 2, 5 A general purpose			
Stem heating element ASZ6.6		AC / DC 24 V			
	Power supply	40 VA / 30 W			
	Power consumption at 50 Hz	Max. 13 A			
Function module AZX61.1 for SA..61..	Inrush current (cold)				
	Switching capacity	AC 24...230 V, 6 (2) A, floating			
	External supply line protection US installation, UL & cUL	See section power supply AC 24 V class 2, 5 A general purpose			

¹⁾ The documents can be downloaded from <http://siemens.com/bt/download>.


²⁾ UL recognized component



6 Connection diagrams and dimensions


6.1 Internal diagrams

SA..31..




Accessories	
A	and / or B
1x ASC10.51	AC 24 V..230 V / 6 (2) A
1x ASC10.51	AC 24 V..230 V / 6 (2) A
or 1 x ASZ7.5/..	SELV/PELV 0...1000 Ω 0...200 Ω 0...135 Ω P1 P2 P3 100% 0%

SA..61..



Accessories	
A	and / or B
1x ASC10.51	AC 24 V..230 V / 6 (2) A
1x ASC10.51	AC 24 V..230 V / 6 (2) A

SA..81..



Accessories	
A	and / or B
1x ASC10.51	AC 24 V..230 V / 6 (2) A
1x ASC10.51	AC 24 V..230 V / 6 (2) A
or 1 x ASZ7.5/..	SELV/PELV 0...1000 Ω 0...200 Ω 0...135 Ω P1 P2 P3 100% 0%

6.2 Connection terminals

6.2.1 Actuators

SA..31..

AC 230 V, 3-position

- | | |
|----|--|
| N | System neutral (SN) |
| Y1 | Positioning signal (actuator's stem extends / actuator's spindle turns clockwise) |
| Y2 | Positioning signal (actuator's stem retracts / actuator's spindle turns counter-clockwise) |

SA..61..

AC/DC 24 V, DC 0...10 V / 4...20 mA / 0...1000 Ω

- | | |
|----|--|
| G0 | System neutral (SN) |
| G | System potential (SP) |
| Y | Positioning signal for DC 0...10 V / 4...20 mA |
| M | Measuring neutral |
| U | Position feedback DC 0...10 V - (reference potential is M measuring neutral) |
| Z | Positioning signal forced control AC/DC ≤ 24 V, 0...1000 Ω |

SA..81..


AC/DC 24 V, 3-position

- | | |
|----|--|
| G | System potential (SP) |
| Y1 | Positioning signal (actuator's stem extends / actuator's spindle turns clockwise) |
| Y2 | Positioning signal (actuator's stem retracts / actuator's spindle turns counter-clockwise) |

6.2.2 Electrical accessories

Auxiliary switch

ASC10.51





4040U07

Adjustable switching points, AC 24...230 V

- | | |
|---|-----------------------|
| 1 | System potential (SP) |
| 2 | Closing Contact |
| 3 | Opening Contact |

Switching state allways related to extending actuator stem or clockwise turning actuator's spindle turns



Potentiometer

ASZ7.5/..



4040U08


Adjustment of zero point, DC 10 V

- | | |
|---|-------------------|
| 1 | Measuring neutral |
| 2 | 0...x Ω |
| 3 | x...0 Ω |

$$x = 135 \Omega, 200 \Omega; 1000 \Omega$$

Stem heating element

ASZ6.6




4040U10

AC 24 V / 30 W / 40 VA / inrush current max. 13A


- | | |
|---|-------------------------------|
| 1 | System neutral (SN) (red) |
| 2 | System potential (SP) (black) |

6.3 Connection diagrams


SA..31..



SA..61..




SA..81..



6.4 Dimensions

6.4.1 Stroke actuators

Dimensions in mm



4040N01_02

- | | |
|----------------|----------------|
| 1 SAX./SAV..: | M25 |
| SAX..U/SAV..U: | ½" (Ø 21.5 mm) |
| 2 SAX./SAV..: | M20 |
| SAX..U/SAV..U: | ½" (Ø 21.5 mm) |


Type	A	B	C	C1	C2	D	E	►	►►	kg
SAX.. (U¹)	242	124	150	68	82	80	100	100	200	1.780
Mit ASK39.1	+25	154	300	200	100	-	-	-	-	2.010
SAV.. (U¹)	265	124	150	68	82	80	100	100	200	1.920
Mit ASK39.1	+25	154	300	200	100	-	-	-	-	2.150
SAY.. (U¹)	242	124	150	68	82	80	100	100	200	1.780

¹⁾ SAX..U: 1.850 kg

²⁾ SAY..U: 1.850 kg

6.4.2 Rotary actuators


Dimensions in mm



- 1 SAL..: M25
2 SAL..: M20

Typ	A	B	C	C1	C2	D	E	F	G	H	►	►►	kg		
													SAL..T10	SAL..T20	SAL..T40
SAL..	160	124	150	68	82	82	88	42	50	70	100	200	1.475	1.600	1.625
With ASK39.1	+25	154	300	200	100	-	-	-	-	-	-	-	1.710	1.835	1.860

With mounting set
ASK3..N



Type	A1	D1	E1	E2
SAL.. with ASK3..N	188	88	80	44
With ASK39.1	+25	-	-	-

7 Revision numbers

Product no.	Valid from rev. no.	Product no.	Valid from rev. no.
SAX31.00	..H	SAL31.00T10	..E
SAX31.03	..H	SAL31.00T20	..D
SAX31P03	..H	SAL31.00T40	..B
SAX81.00	..H	SAL31.03T10	..E
SAX81.03	..H	SAL61.00T10	..E
SAX81.03U	..H	SAL61.00T20	..D
SAX81P03	..H	SAL81.00T40	..B
SAX61.03	..H	SAL61.03T10	..E
SAX61.03U	..H	SAL81.00T10	..E
SAX61P03	..H	SAL81.00T20	..D
		SAL81.00T40	..B
SAV31.00	..B	SAL81.03T10	..E
SAV61.00	..B		
SAV61.00U	..B	SAY31P03	..A
SAV61P00	..B	SAY61P03	..A
SAV81.00	..B	SAY81P03	..A
SAV81.00U	..B		
SAV81P00	..B		

8 Glossary

8.1 Symbols



Caution, general danger – read the notes!




Caution, hot surface – read the notes!



Condition as supplied to customer



Crosstip screwdriver (Pozidriv)



Slotted screwdriver



Screw wrench



Allen key

8.2 Terms

DIL switches

A DIL switch shows the switching choices in the form of a place value system (dual in line) in relation to basis 2 (on and off).

DN

Nominal size: Characteristic for matching parts of the piping system.

Forced control

Forced control serves for overriding automatic mode and is implemented in the structure.

HEX switches

A HEX switch shows the switching choices in the form of a place value system (hexadecimal system) in relation to basis 16 (0...9 and A...F).

kPa

Unit of pressure: 100 kPa = 1 bar = 10 mWS.

k_{vs}

Nominal flow rate: Nominal flow rate of cold water (5...30 °C) through the fully open valve (H₁₀₀) at a differential pressure of 100 kPa (1 bar).

LED

Light emitting diode.

PN

PN class: Characteristic relating to the combination of mechanical und dimensional properties of a component in the piping system.

Position feedback

Signal used to acquire the position, fed back via an input.

Spring return facility

Refer "fail safe function".

Δp_{max} / Δp_{maxV}

Maximum permissible differential pressure across the valve's control path, valid for the entire actuating range of the motorized valve (V = diverting mode).

Δp_s

Maximum permissible differential pressure at which the motorized valve will close securely against the pressure (close off pressure).

slotted screwdriver

Index

3-position control	45	DN	12, 14, 16
A/D conversion	45, 48	Document use	7
About this documentation.....	5	Electrical accessories	62
Accessories	17, 66	Electrical planners	7
Electrical accessories	17	Engineering.....	8
Mechanical accessories.....	17	Environmental compatibility	66
Acting direction	51, 53	Environmental conditions.....	65
Angular rotation	10	Equipment combinations	12
Auxiliary switch ASC10.51	17, 33, 36, 41, 43, 62,	2-port valves	14
66, 67, 68		3-port valves	12
Before you start	6	combi valves	16
Brushless DC motor.....	45, 48	slipper and butterfly valves	16
Cable entries	65	Extra functions	9, 10
Cable glands.....	8, 40	Flow characteristic.....	52, 53, 62
cable lengths	21	Equal-percentage.....	52, 53
Calibration	42, 48, 56	Linear	52, 53
Calibration slot.....	33, 48	Flow characteristic selection	52
Changeover of acting direction.....	51	Force.....	12
Changeover of characteristic.....	48	Forced control	9, 10, 48, 58, 65
Characteristics function.....	48	Formulas for wire lengths	22
Commissioning	42	Function check	42
Connecting cable	65	Function data	65
Connection diagrams	67, 69	Function module AZX61.1	17, 33, 35, 48, 49, 63
Connection terminals	33, 68	Function principle	59
3-position	68	Functions	45
Actuators.....	68	Gear train.....	45, 48
Auxiliary switch ASC10.51	68	Glossary.....	73
Electrical accessories	68	Handling.....	23
Modulating	68	HEX switches	49
Potentiometer ASZ7.5.....	68	Housing cover	8
Stem heating element ASZ6.6	68	HVAC plants.....	7
Contents	3	Identification of seat	45, 48
Control.....	45	Indicators	61
Control functions.....	45	LED	61
Control functoins	48	Operational status indication	61
Control of direction.....	45	Position indication	61
Copyright.....	7	Status indication.....	61
Coupling	8, 60	Indoor use	23
Cross-sectional area of wire	22	Installation.....	8, 23, 40
cross-sectional areas	21	Interior view	33
Degree of protection	65	Internal diagrams.....	67
Delivery	11	Kennlinienumschaltung	9
Detection of foreign bodies	48, 57	k_{vs}	12, 14, 16
Detection of valve seat.....	57	L/P-diagram	22
Deviations.....	46	LED.....	9, 10, 33, 48, 61
DIL switches	33, 48, 49, 51	Maintenance	44
Dimensions.....	66, 70	Manual adjuster.....	8, 9, 10, 45, 48, 60
Rotary actuators	71	Automatic.....	60
Stroke actuators	70	Disengaging the fixing	60
Direct acting	51, 53	Fixing the coupling	60
Directives	66	Manual operation	60
Disposal	44	Manual adjustment	45, 48

Mechanical accessories	63
Modulating control.....	48
Montagesatz ASK3..N	16
Montagesatz ASK31N	27
Montagesatz ASK35N	17
Motor control.....	45, 48
Mounting.....	23
Accessories	33
Auxiliary switch ASC10.51	36
Fitting actuators to butterfly valves	25, 30, 31
Fitting actuators to seat valves	23
Fitting actuators to slipper valves	27
Function module AZX61.1	35
Mounting positions	23
Potentiometer ASZ7.5	34
Stem heating element ASZ6.6	39
Weather shield ASK39.1	39
Mounting set ASK3..N	63, 71
Mounting set ASK31N	17
Mounting set ASK33N	17, 25
Mounting set ASK35N	31
Navigation	5
Operating voltage	22, 64
Operataing voltage	9, 10
Ordering	11
Outdoor use	23
Parallel operation	65
Parallel operation of actuators	20
Permissible voltage drop	22
Permissible wire length	22
Plug-in space A	33, 34, 36
Plug-in space B	33, 35, 37
PN	12, 14, 16
Position control	48
Position feedback	9, 10, 52, 65
Position indication	8
Positioning force	9, 10, 12, 14, 18
Positioning signal	9, 10, 48
Positioning signal (Z)	65
Positioning signal selection	52
Positioning time	9, 10, 18
Positioning times stroke model	46
Potentiometer ASZ7.5.....	17, 33, 34, 41, 44, 62, 66, 67, 68
Power consumption	22
Power supply	48, 64
Power transmission	8
Product description	8
Product replacements	
Electrical accessories	19
Rotary actuators SQL.. to SAL.....	18
Stroke actuators SQX.. to SAX.....	18
Product replacements	18
Quality assurance	7
Quick access	5
Reference documents	6
Request to the reader	7
Reverse acting	51, 53
Revision history	6
Revision numbers	72
Scope of this document	7
Selecting the acting direction	51
Sequence control	49
Setting elements	33
Signal adaptation	49
Signal error	21
Signal inputs	65
Signal priorities	56
Sizing	20
Spare parts	20
Spring return time	9, 10
Standards	66
Status indication	8
Stem heating element ASZ6.6	17, 39, 63, 66, 68
Stroke	9, 10
Symbols	73
Technical	59
Technical data	64
Terms	73
Torque	10, 16, 18
Trademarks	6
Transmission of power	59
Type summary	9
Rotary actuators	10
Stroke actuators	9
Use	9
User interface	8
Valve neck coupling	8
Valve stem coupling	8
Voltage drop	21
Volumetric flow	51, 52
Warranty	22
Weather shield ASK39.1	17, 39, 63
Weight	66
Wiring	40
Actuator	40
Auxiliary switch ASC10.51	41, 43
Potentiometer ASZ7.5	41
Preparation of wire endings	40
Yoke	8
Δp_{\max}	12, 14, 16
Δp_s	14, 16

Issued by

Siemens Switzerland Ltd
Building Technologies Division
International Headquarters
Gubelstrasse 22

6301 Zug
Switzerland

Tel. +41 41-724 24 24

www.siemens.com/sbt

© Siemens Switzerland Ltd, 2010
Technical specifications and availability subject to change without notice