

RISLONE TECHNICAL BULLETIN	
Tech Bulletin #: TB-100QR-3	Page 1 of 1
Date 1 <sup>st</sup> Issued: October 8, 2007	Date Revised: June 01, 2018
Rislone Engine Treatment	Part #: 100QR

## **ENGINE TREATMENT**

Rislone<sup>®</sup> Engine Treatment is high quality penetrating lubrication oil, combined with protective engine additives and special cleaning agents. Its multi-grade formula allows the oil to flow freely and provides protection over a broader temperature range. Sludge and other harmful deposits within engines can alter tolerances, stick rings, cause noisy valves & lifters, and plug oil passages and screens. The unique Rislone formula is designed to penetrate into valve seats, bearing surfaces, piston rings and ring grooves, where sludge and varnish is likely to form. These deposits are gradually removed and held in suspension until they are trapped in the filter or removed with the next oil change. Regular use of Rislone Engine Treatment, with oil and filter changes at the proper intervals, will keep such deposits to a minimum. A cleaner engine is a better lubricated engine with less friction & wear.

- REDUCES FRICTION & WEAR
- QUIETS NOISY LIFTERS AND VALVES
- REMOVES & PREVENTS SLUDGE

Rislone works with all petroleum-based motor oils including conventional, high mileage and synthetic formulas.

## DIRECTIONS (Automotive Applications)

- When Adding To Existing Engine Oil Remove engine dipstick and check oil level. If oil is low, remove oil cap and install entire contents of bottle. Do NOT overfill. If needed top off with manufacturers recommended engine oil. Reinstall dipstick and oil cap. Drive/idle engine for 10-15 minutes then recheck engine oil level.
  - When Changing Oil If using when changing oil, replace one quart of your motor oil with Rislone Engine Treatment. Then refill with manufacturer's recommended oil to proper level. Drive vehicle and recheck oil level.

For best protection, use Rislone Engine Treatment at every oil change.

Part Number: 100QR UPC Item: 0 78615 10032 3 UPC Case: 6 00 78615 10032 5 Bottle Size: 32 fl. oz. (946ml) Bottle Dimensions: 4.3 x 2.5 x 8.9 Bottle Cube: 96 Case Pack: 6 bottles per case Case Size: 8.8 x 7.6 x 9.4 Case Cube: 629 Case Weight: 12.2 pounds TI 25 HI 5 Total 125 Pallet: Pallet Height: 51 inches

## DOSAGE

In passenger car and light truck engines, use one bottle for a 4 to 6 quart system. Example: If using when changing oil and you have a 5 quart crankcase capacity, use 4 quarts of oil and 1 quart of Rislone Engine Treatment.

For larger systems, stationary engines and diesel trucks, use at 20% of crankcase capacity.

For severely dirty engines, use two quarts of Rislone Engine Treatment and change the oil after 100 miles of driving.

