

Automatische Aerosol Dispenser Gebruiksaanwijzing

1. Controleer of de schakelaar op 'OFF' staat, en plaats twee AA batterijen. Gebruik bij voorkeur Alkaline batterijen voor ultiem resultaat.
2. De tekening laat u zien hoe de batterijen op de juiste manier geplaatst dienen te worden (fig.1).
3. Kies de spray intervallen. Het is mogelijk om uit 3 verschillende intervallen te kiezen (fig.2)
 - 7.5 sprayt elke 7,5 min.
 - 15 sprayt elke 15 min.
 - 30 sprayt elke 30 min.
4. Licht sensor knop
 - 24H. Bij de 24-h modus werkt de dispenser dag en nacht.
 - NIGHT. Bij de nacht modus werkt de dispenser wanneer er geen lichtbron in de buurt is.
 - DAY. Bij de dag modus werkt de dispenser bij de aanwezigheid van lichtbronnen.

5. Zet de dispenser aan, door de schakelaar op 'ON' te zetten (fig.1).

LET OP: de dispenser sprayt direct.
Vermijd het sprayen in uw richting.

6. Wanneer het LED licht 5 seconden groen knippert, wil dat zeggen dat de dispenser goed functioneert.
7. Een rood knipperlicht geeft aan dat het aantal sprays over de 3000 is, en daarmee kan het dus zijn dat het spuitbusje leeg is. Controleer in dit geval de spuitbus. Bij het verwisselen van spuitbusjes, moet u de dispenser eerst uitzetten door de schakelaar op 'OFF' te zetten. Hierna kunt u de dispenser weer aanzetten. Het rood knipperende lichtje zou nu uit moeten gaan.
8. Licht Sensor LED – Wanneer de rode LED knippert, heeft de dispenser meer dan 3000 sprays uitgevoerd. Dit betekent dat de spuitbus vervangen dient te worden. Zet de dispenser uit, hiermee wordt de dispenser gereset. Vervang de spuitbus door de instructies in figuur 1 te volgen. Zet hierna de dispenser weer aan.




fig. 1




fig. 2

Automatic Aerosol Dispenser Operation Instruction

1. Confirm the power switch is in the state of 'OFF', and load two AA batteries. Suggested is to use two alkaline batteries to make it more effective.
2. The figure shows how to put the can in the correct way (fig.1).
3. Choose the spray intervals. It is possible to choose 3 different intervals (fig.2).
 - 7.5 sets up spray interval in each 7,5 min.
 - 15 sets up spray interval in each 15 min.
 - 30 sets up spray interval in each 30 min.
4. Photocell switch
 - 24H. Under the 24-h mode, it will activate in a whole day round.
 - NIGHT. Under the night mode, it will activate during night, when there is no light source.
 - DAY. Under the day mode, it will activate during day when there are light sources.
5. Switch the dispenser ON (fig.1).
ATTENTION: the dispenser will spray immediately. Avoid to direct the jet towards you.
6. A for 5 seconds continuously flashing green LED light indicates that the dispenser is in good condition.
7. A red flash indicates the spray time is over 3000 times, and one aerosol refill might be used up. Then what you have to do is to check the aerosol refill. Replacing the refill, you should turn off the dispenser and then back on, for clearing the spraying record. By then, the red alarm flash will stop.
8. Photocell LED – If the red LED blinks, the dispenser has performed more than 3000 sprays and the can needs to be replaced. Switch off the dispenser, in this way the counter will be reset. Replace the aerosol refill by following the instructions in fig.1. Switch on the dispenser.




fig. 1




fig. 2