


# Micro-controlled Vacuum Pump System



- 1 **Power Supply Status**  
Power supply low Lo  
Power supply in working range Vin  
Power supply to high Hi
- 2 **Voltage indicating system**
- 3 **Operating Mode** MANUAL MANUAL  
Operating Mode AUTO AUTO
- 4 **Warning !** Slow stop! Check the system!
- 5 **VacuumStatus**  
Vacuum pressure to low Lo  
Vacuum pressure in operating mode OK
- 6 **Operating Range Vacuum**  
upper operating range   
lower operating range

7 **Negative Vacuum Pressure in kpa**

8 **Automatic Button**

8.1 **Mode Adjustment**  
Hold green Button for 3 seconds

12 Change into Mode Menu

13 Select with blue Button

Return with green Button

9 **Manual Pump Button**

10 **Air supply**

11 **XLR Plug**

