


Ultimaker Original+


Spare-Parts



Version 1.2
28/05/18

Spare Parts Ultimaker Original+

Injection Moulding Set



1030 Injection Moulding Set

Spare Parts Ultimaker Original+

Belts



1085 Timing Belt B100 MXL



1086 Timing Belt B300 MXL

Spare Parts Ultimaker Original+

Frame



1673 Front plate including Parts



1674 Back plate including Parts




1675 Left plate including Parts



1676 Right plate including Parts




1677 Top plate including Parts



1678 Bottom plate including Parts

Spare Parts Ultimaker Original+


Frame



1679 Parts plate UM+

Spare Parts Ultimaker Original+

Hot end



1049 Aluminium Heater Block



1053 Hot end Isolator Tube



1054 Nozzle



1067 Peek Isolator



1069 Tube Coupling Collet



1071 Clamp Clip

Spare Parts Ultimaker Original+

Knurled drive bolt



1031 Feeder Bolt Clip



1133 Feeder Knurled Bolt



1134 Cap Nut M8



1136 Washer M8



1137 Nut M8

Spare Parts Ultimaker Original+

Nuts & Bolts



1202 ISO 7380 M3x10



1203 ISO 7380 M3x12



1204 ISO 7380 M3x16



1206 ISO 7380 M3x20



1207 ISO 7380 M3x25



1208 ISO 7380 M3x30

Spare Parts Ultimaker Original+

Nuts & Bolts



1209 Nut M3



1211 Set Screw M4x4



1214 ISO 7040 Nut M3 prev. torque A2

Spare Parts Ultimaker Original+

Pulleys



1084 Timing Pulley 5 mm shaft



1088 Timing Pulley 8 mm shaft

Spare Parts Ultimaker Original+

Bearings



1021 Ball Bearing 688-2RS




1056 Sintered Bushing



1065 Linear Bearing LM6LUU



1142 Ball Bearing 693ZZ



1170 Square Flanged Linear Bearing LMK12LUU

Spare Parts Ultimaker Original+

Axles



1011 Y-Linear Shaft



1012 X-Linear Shaft



1028 Z-Linear Shaft



1046 Print Head Shaft X/Y



1159 Z-Motor with Trapezoidal Lead Screw

Spare Parts Ultimaker Original+

Fans



1501 Print Head Fancap Metal



1512 Print Head Fan 24 VDC

Spare Parts Ultimaker Original+

Limit switch



1023 Limit Switch Black Long Wire



1025 Limit Switch Blue Wire




1026 Limit Switch Red Wire

Spare Parts Ultimaker Original+

Heated bed



1154 PrintTable Glass



1155 PrintTable Heated Bed



1183 Heated Bed Cable



1243 Heated Bed Cable Clip



1256 Build Platform Glass Retainer Back



1257 Knurled Nut Platform

Spare Parts Ultimaker Original+

Heated bed



1818 Print Table Base Plate

Spare Parts Ultimaker Original+

Electronics



1315 Jumper



1546 Main Board v2.1.4.

Spare Parts Ultimaker Original+

Cables



1017 Feeder Motor



1082 X/Y Motor



1241 Motor Spacer

Spare Parts Ultimaker Original+

Bowden tube



1069 Tube Coupling Collet



1071 Clamp Clip



1266 Bowden tube

Spare Parts Ultimaker Original+

UltiController




1099 Flatcable 10 wire



1129 Knob



1139 Spacer 15mm (white 16mm)



1146 Ultipanel Rev. 1.1

1250 SD Card 4GB



1522 Ulticontroller Window

Spare Parts Ultimaker Original+

Power Supply Unit



1238 Power Adapter 24-220W



1805 Power Cable EU Type C13 CE



1806 Power Cable UK Type C13 CE



1807 Power Cable AU Type C13 CE



1808 Power Cable US Type C13 CE

Spare Parts Ultimaker Original+

Additional




1010 Velcro Parts




1016 Feeder Quick Fit Coupling



1097 Spiral Sleeve



1131 Cable Duct Front



1132 Cable Duct Back



1143 Feeder Spring D2110

Spare Parts Ultimaker Original+

Additional



1144 USB Cable



1185 PT100 B Sensor



1227 Hex Key Screwdriver 2.0



1400 Hex Key Wrench 1.5



1513 Heater Cartridge 18V 40W