

Programma Massa

Onderhoudsadvies

HOUTSOORT	Hergebruikt Teakhout
HERKOMST	Azië
KLEUR (MOGELIJKHEID)	Hergebruikt Teakhout
OVERIGE MATERIALEN	Metaal
AFWERKING	Lichte White Wash

ALGEMENE TIPS EN ADVIES

Hout werkt: het zet uit en krimpt. De mate waarin dat gebeurt, is afhankelijk van de luchtvochtigheid en temperatuur van de ruimte waarin het meubel staat. De ideale luchtvochtigheid ligt tussen de 55% en 65%. De ideale temperatuur is 20°C. Wijk de situatie hier teveel van af of schommelt deze teveel, dan kan het hout gaan scheuren of kromtrekken. Plaats een meubel daarom dan ook niet dicht bij een warmtebron of airco installatie. Vermijd (direct) zonlicht: Kleuren worden hierdoor sneller dof en de lak of olie waarmee het meubel behandeld is, slijt sneller af waardoor de kans groter is op schade door normaal dagelijks gebruik. Gebruik daarbij ten alle tijden onderzetters en indien er geknoeid wordt, neem dit direct op met een schone doek. Plaats geen hete potten en/of pannen op meubelen.

PERIODIEK ONDERHOUDS- / REINIGINGSADVIES

Dagelijks onderhoud: afdoen met een licht vochtige doek en daarna met een droge doek nawrijven. Vermijd ten alle tijden bijtende en ammonia houdende middelen.

Periodiek onderhoud: 2 a 3 maal per jaar het meubel reinigen met Woodclean en behandelen met Mat Polish (beide producten zijn van Oranje B.V.)

Collection Massa

Maintenance advice

TYPE OF WOOD	Recycled Teak
ORIGIN	Asia
COLOR (OPTIONS)	Recycled Teak
OTHER MATERIALS	Metal
FINISHING	Light White Wash

GENERAL TIPS AND ADVICE

Wood shrinks and expands due to external influences like humidity and temperature. A humidity of 55% to 65% and a constant room temperature of 20°C are the ideal conditions. Large differences in humidity and temperature can cause the wood to crack. If you have a room and/or rooms with varying levels of humidity, we advice to use a humidifier to help stabilize the general level of humidity throughout the whole year. It is important not to place your furniture directly next to a heating source or airconditioning. In addition to this, avoid placing furniture in (direct) sunlight. Colors will fade sooner and lacquer and/or varnishes will wear off sooner which increases the likelihood of damages by normal daily use. Always use coasters and if you spill something, make sure to wipe this off as soon as possible. Also don't place any hot items on the furniture.

PERIODIC MAINTENANCE / CLEANING ADVICE

Daily maintenance: A damp cloth and mild dish soap are usually all you need to clean your furniture. After cleaning, rinse with a soap free and slightly damp cloth. Then dry the surface with a dry towel. Avoid aggressive and ammonia containing substances at all times when cleaning.

Periodic maintenance: Clean 2 or 3 times per year with Woodclean and treat it with Mat Polish for protection (both products are from Oranje B.V.).