

## USER MANUAL WIRELESS SCENE SWITCH


The Eria wireless scene switch is a battery-powered dimmer for ZigBee Light link and 3.0 certified lights: it controls your preferred lighting setting. ψ ON/OFF

SCENE 1

SCENE 2


SCENE 3

U+1 Long press. Color loop




1+2	Long press To fouch link with bulbs.	
2+3	Long press Connect to the gateway.	
ტ+3	Long press Reset the bulb.	
1+3	Long press Reset to factory settings.	
2.To use without a control st- switch on the ZigBee lamp you want to control.		

Important note: Can be used without an Eria HUB but offers more options in combination with an Eria HUB



ation, which I





COLOR LAMP

Connect with the ERIA hub

1 A.Download the Adurosmart App from the Apple App Store or from
Google Play or go to http://adurosmart.com/adurosmart-app/

Android














0

On the top right corner press on the "+" symbol then press on "Add device".

0





Smart Si





To reset the remote:
press and hold the
1 button (symbol) +3 button (symbol) on the remote simultaneously for
10 seconds
a successful reset will be confirmed by
a green flash from the LED indicator,
falled reset will be indicated by
a red flash.



The Netherlands: +31 523687532 Support@Adurosmart.eu

