




# USER MANUAL

## DTC ERASER FOR Truck

**EURO 5** **EURO 6**



 [www.canbusemulator.com/en](http://www.canbusemulator.com/en)

 +90 530 937 46 36

 erenakarsubasi

## Installation DTC Eraser For Truck



- 1-The ignition is switched on (but the truck will not working)
  - 2-DTC Eraser plug into the OBD socket.
  - 3-Wait 30 seconds (while the device is in the socket)
  - 4-The ignition is switched Off
  - 5-DTC Eraser plug get out the OBD socket.
  - 6-Wait 30 seconds.
  - 7-You can run the truck.
- All faults will be cleared. If the error is still there, repeat the process.