

Titel

Table of contents

- 1. Hardware
 - 1.1. LED Status Display
 - 1.2. Hardware Revision
 - 1.2.1. Hardware Revision 0
 - 1.2.2. Hardware Revision 1
 - 1.2.3. Hardware Revision 2.X
 - 1.2.3.1. Upgrading from REV_2 to REV2.5
 - 1.2.3.2. Downgrade from REV_2.5 to REV_2
 - 1.3. Watchdog
 - 1.4. Reset Button
 - 1.5. Conformity
 - 1.5.1. Hardware Revision 1
 - 1.5.2. Hardware Revision 2
 - 1.6. Bluetooth module
 - 1.6.1. Hardware Revision 0 und 1
 - 1.6.2. Hardware Revision 2
 - 1.7. Type label
 - 1.7.1. Hardware Revision 1
 - 1.7.2. Hardware Revision 2
 - 1.8. Firmware Version
 - 1.9. Software Librarys
- 2. Areas of application
 - 2.1. Gateway to an existing lighting control system (Netcomposer)
 - 2.2. Gateway to an existing lighting control system (Helvar)
 - 2.3. Gateway to a system using UDP or TCP (ASCII based commands)
 - 2.4. Bridge between individual Casambi networks
 - 2.5. Coupling to an existing evaluation system / visualization
 - 2.6. ArtNet gateway
 - 2.7. BacNet/IP gateway
 - 2.8. MQTT
 - 2.9. Example implementations



Lithernet - Casambi Gateway v4.35

User Manual
Revision: 10.12.2023