

USE AND SAFETY

CLEANING

Follow the instructions below to avoid damaging or discoloring the product exterior.

- A** Wipe with a soft, dry cloth.
- B** Do not use insecticides or other volatile substances.
- C** Do not place rubber/vinyl on the product's enclosure for extended periods of time.
- D** Do not use solvents or other chemicals. Do not clean the product with a chemically treated cleaning cloth.

STORAGE CONDITIONS

- A** Do not expose the product to high temperatures, high humidity or direct sunlight when it is being used, transported or stored.
- B** Do not leave the product in a car with the windows closed, particularly in hot weather.
- C** Do not expose the device to dust, smoke or steam.

WARNING

Use of headsets or headphones

Using a headset or headphones (not included) at high volume can cause permanent hearing damage. Set the volume to a safe level. While progressively louder sounds may sound normal over time, they can still harm your hearing. If you hear muffled sounds or ringing in your ears or feel any discomfort in your ears, stop listening and have your hearing checked. The louder the volume, the faster your hearing can be damaged.

Handling lithium-ion batteries

Do not handle damaged or leaking lithium-ion batteries. If the internal battery fluid leaks, stop using the product immediately and contact technical support for assistance. If you get battery fluid on your clothing, on your skin or in your eyes, rinse immediately with clean water and consult your doctor. The battery fluid can cause blindness.



USE AND SAFETY

WARNING

Radiowaves

Radio waves can affect electronic equipment or medical devices (e.g. pacemakers). This can cause malfunctions and possible injury. If you use a pacemaker or other medical device, consult your doctor or the manufacturer of your medical device before using the wireless network function (Bluetooth® and wireless LAN). Do not use the wireless network function in the following locations: Places where wireless network use is prohibited, such as in hospitals. Comply with the regulations of the medical facility when using the console there. Environments near fire alarms, automatic doors and other automated equipment.

Magnets

This product contains magnets that may affect pacemakers, defibrillators, programmable shunt valves and other medical devices. Do not place this product near such medical devices or persons using these medical devices. Consult your doctor before using this product if you use such medical devices.

PRECAUTIONARY MEASURES

Safety

This product has been designed with the utmost concern for safety. However, any electrical device, if used improperly, can cause fire, electric shock or personal injury. Follow these guidelines to avoid accidents.

Observe all warnings, cautions, and instructions. If there is any information in this manual that is not clear to you, please contact the appropriate MNR customer service. You will find the e-mail address in the warranty booklet.

- A** Stop use and immediately disconnect all cables if the product behaves abnormally, produces unusual noises or odors, or becomes too hot to touch.
- B** Do not play when you are tired or in need of sleep.

Using the vibration function of the wireless controller

- A** If the wireless controller is placed on a flat surface, the vibration of the wireless controller during gameplay may cause the controller to fall. This may cause injury or malfunction.
- B** Do not use the vibration or trigger effect function if you have a condition or injury to the bones, joints, or muscles of your hands or arms. If you have a condition or injury, do not play games that use these controller functions unless you have disabled the functions. To enable or disable the features, select Settings > Accessories from the console home screen.



USE AND SAFETY

PRECAUTIONARY MEASURES

Injuries to small children

Keep this product out of the reach of small children. Small children may swallow small parts or wrap the cables around themselves. This may cause accidents, injury or malfunction.

Volume level

- A** To protect your hearing, do the following: Avoid using your headset or headphones at high volume.
- B** Zet het volume niet hoger vanwege een lawaaierige omgeving.
- C** Zet het volume lager als u mensen vlakbij niet goed kunt verstaan.

Pause

- A** Avoid prolonged use of the console. Take a 15 minute break for every hour you play.
- B** Speel niet wanneer u moe bent of slaap nodig hebt.
- C** Stop using the console immediately if you begin to feel tired or if you experience discomfort or pain in your hands or arms while using the wireless controller. Consult a doctor if you continue to feel unwell.

PRECAUTIONARY MEASURES

D If you suffer from any of the following health conditions, we recommend that you stop using the console immediately. If symptoms persist, see a doctor.

- 1** Dizziness, nausea, tiredness, or symptoms similar to those of motion sickness
- 2** Pain or discomfort in any part of the body, such as the eyes, ears, hands, or arms

Static shock

When using a headset or headphones in very dry air environments, you may sometimes feel a small (static) shock to your ears. This is due to static electricity that builds up in the body. There is no problem with your headset or headphones.



USE AND SAFETY

PRECAUTIONARY MEASURES

Motion sensor

Note the following points when using the wireless controller's motion sensor function. If the controller hits a person or object, it may result in injury or damage.

- A** Make sure you have enough room to move around before using the motion sensor feature.
- B** Hold the wireless controller securely to prevent it from slipping out of your hand and causing damage or injury.
- C** If you're using a wireless controller that connects to the console with a USB cable, make sure there's enough room for the cable so that it doesn't hit a person or object.

Light bar

Do not look at the light bar on the controller when it is flashing. If you experience discomfort or pain anywhere on your body after slight movements or stimulation, stop using the controller immediately.

Placing and handling

- A** Do not place the product on surfaces that are unstable, tilted, or subject to vibration.
- B** Do not place the product on the floor or where it can be tripped over.

PRECAUTIONARY MEASURES

Placing and handling

- C** Do not let liquids or small objects fall into the device.
- D** Do not touch the device with wet hands.
- E** Do not touch the product during a thunderstorm.
- F** Do not drop or subject the product to physical shock.
- G** Do not step on the product or place any objects on it.
- H** Do not touch the terminals and do not insert any foreign objects into the product.
- I** If there is dust or dirt on the connector, wipe it with a dry cloth before connecting.
- J** The device must not be dismantled or modified.
- K** The product and its parts are made of metal and plastic. When disposing of the product, follow local regulations for the correct way to dispose of these materials.



USE AND SAFETY

BATTERY

Warning about the use of the built-in battery

- 1 Dit product bevat een oplaadbare lithium-ion batterij.
- 2 Before using this product, read all instructions for using and charging the battery. You must follow these instructions.
- 3 Take extra care when handling the battery. Improper use may result in fire and burns.
- 4 Never attempt to open, flatten, heat or set fire to the battery.
- 5 Do not charge the battery for a long time when the product is not in use.
- 6 Always dispose of used batteries in accordance with local laws or regulations.

Battery life and operating time

- A** The battery has a limited lifespan. As the battery is used frequently and with age, the operating time gradually decreases. Battery life also depends on how it is stored and used, the environment in which it is kept, and other factors.
- B** Charge the controller in a room with a temperature between 10 °C and 30 °C. Charging may be less effective at other temperatures.

BATTERY

Battery life and operating time

- C** Battery life may vary depending on usage and environmental conditions.

When the controller is not being used

If you do not use the controller for an extended period of time, we recommend that you fully charge the battery at least once a year to keep it working.

TECHNICAL DATA

Design and specifications are subject to change without notice. Depending on the software version used, the console may operate differently than described in this manual.

Input Current Voltage	5 V = 1 500 mA
Battery type	Built-in rechargeable lithium-ion battery
Voltage	3,65 V m
Battery capacity	1 560 mAh
Operating temperature	5 °C to 35 °C
Weight	Approximately 320 grams
Country of production	Production China. Assembly Nederland.

