



# MNR CONTROLLER

Instruction Manual



 /modsandrepairs

 /modsenreparaties



MODS<sup>AND</sup>  
REPAIRS



## **INFINITY CONTROLLER**


Your "INFINITY" controller is equipped with an ergonomically rubberized back for optimal comfort, and 4 "remappable" buttons. The possibilities are truly infinite.



## INFINITE POSSIBILITIES

Do you want to give your "MNR INFINITY" controller a facelift? You can! MNR has a wide range of faceplates (fronts) for your controller.

The entire range can be found on our site <https://www.modsandrepairs.com/brands/mods-and-repairs/>. Or scan the QR code below.



# INFINITY FEATURES

# 1

## A UNIQUE DESIGN

The "MNR INFINITY" controller is equipped with an MNR designed front. Transport yourself to the universe and enter "The Void". Completely empty of space and time, you step into infinite with this design.

# 2

## ERGONOMIC BACK WITH GRIP

Each "MNR INFINITY" controller has an ergonomically designed back with rubber surfaces for optimal comfort. The texture on the rubber surfaces gives you extra grip on the controller and therefore your performance in-game.

# 3

## 4 ADDITIONAL REMAPPABLE BUTTONS

The 4 extra buttons on the back can be reassigned (programmable). This gives the player unlimited possibilities in creating your own style of play.



## BEGIN YOUR JOURNEY

To enjoy your “MNR INFINITY” controller, connect the controller to the console via the USB-C cable before using it for the first time. Then press the “MNR” (PS) button to connect.

Important: After the controller is connected for the first time, the controller can be used wirelessly with the console from now on. The controller is now paired via “Bluetooth” by default.



Touchpad	1	MNR (PS) button	6
Create button	2	Mute (microphone) button	7
Option button	3	Bumpers (L1 + R1)	8
Action button	4	Headphone jack (3.5mm)	9
D-Pad	5		



## FOLLOW US

Follow us on social media to stay up to date with the latest news, discount promotions, new controllers and much more.



/modsandrepairs



/modsenreparaties



Remap button	1	Reset pinhole	6
K3 button	2	Triggers (L2 + R2)	7
K4 button	3	USB-C connection	8
K1 button	4	Rubberized grip	9
K2 button	5	Indication LED	10



## NEED HELP?

Are you still not sure after reading this manual? Then we will help you further! Visit our website for all your questions or video help with setting up your “INFINITY” controller.  
Scan the QR code below.



# INFINITY SETUP

## PROGRAMMABLE BUTTONS SETUP

**Important:** Refer to the “INFINITY LAYOUT” section for the location of the buttons listed below.

- 1** Connect your controller to your console via a USB-cable.
- 2** Press the MNR(PS) button in order to connect to your console.
- 3** Press and hold the remap button until the red LED turns on. You are now in pairing mode.
- 4** Choose one of the programmable buttons on the back of your controller and the button you want to assign it to.
- 5** Press and hold both buttons simultaneously until the red LED starts flashing. (the LED always flashes three times.)
- 6** Once you are satisfied with your setup, you can exit pairing mode by pressing the remap button until the red LED turns off.

