



# MNR CONTROLLER

Instruction Manual



 /modsandrepairs

 /modsenreparaties



**MODS**<sub>AND</sub>  
**REPAIRS**



## **IMMORTAL CONTROLLER**

Your "IMMORTAL" controller is the total package. Equipped with a custom designed front, "ZEUS" mechanical keys and 4 "remappable" buttons. With this controller you will become immortal.



## INFINITE POSSIBILITIES

Do you want to give your "MNR IMMORTAL" controller a facelift? You can!

MNR has a wide range of faceplates (fronts) for your controller.

The entire range can be found on our site <https://www.modsandrepairs.com/brands/mods-and-repairs/>. Or scan the QR code below.



# IMMORTAL FEATURES

# 1

## ZEUS MECHANICAL KEYS

Be lightning fast with the mechanical buttons. Due to the shortened pressure distances you are between 40% and 60% faster than your opponent.

# 2

## ERGONOMIC BACK WITH GRIP

Each "MNR INFINITY" controller has an ergonomically designed back with rubber surfaces for optimal comfort. The texture on the rubber surfaces gives you extra grip on the controller and therefore your performance in-game.

# 3

## 4 ADDITIONAL REMAPPABLE BUTTONS

The 4 extra buttons on the back can be reassigned (programmable). This gives the player unlimited possibilities in creating your own style of play.



## BEGIN YOUR JOURNEY

To enjoy your “MNR INFINITY” controller, connect the controller to the console via the USB-C cable before using it for the first time. Then press the “MNR” (PS) button to connect.

Important: After the controller is connected for the first time, the controller can be used wirelessly with the console from now on. The controller is now paired via “Bluetooth” by default.



Touchpad	1	MNR (PS) button	6
Create button	2	Mute (microphone) button	7
Option button	3	Bumpers (L1 + R1)	8
Action buttons	4	Headphone jack (3.5mm)	9
D-Pad	5		



## FOLLOW US

Follow us on social media to stay up to date with the latest news, discount promotions, new controllers and much more.



/modsandrepairs



/modsenreparaties



Remap button	1	Reset pinhole	6
K3 button	2	Triggers (L2 + R2)	7
K4 button	3	USB-C connection	8
K1 button	4	Rubberized grip	9
K2 button	5	Indication LED	10



## NEED HELP?

Are you still not sure after reading this manual? Then we will help you further! Visit our website for all your questions or video help with setting up your “IMMORTAL” controller. Scan the QR code below.



# IMMORTAL SETUP

## PROGRAMMABLE BUTTONS SETUP

**Important:** Refer to the “IMMORTAL LAYOUT” section for the location of the buttons listed below.

- 1** Connect your controller to your console via a USB-cable.
- 2** Press the MNR(PS) button in order to connect to your console.
- 3** Press and hold the remap button until the red LED turns on. You are now in pairing mode.
- 4** Choose one of the programmable buttons on the back of your controller and the button you want to assign it to.
- 5** Press and hold both buttons simultaneously until the red LED starts flashing. (the LED always flashes three times.)
- 6** Once you are satisfied with your setup, you can exit pairing mode by pressing the remap button until the red LED turns off.

