



Manual 5 to 16 meter
Xmasstarlight, excl pole

Important



Laat de boom zakken bij windkracht 6 of hoger
De transformator mag niet worden blootgesteld aan vocht



Lower the tree when wind force is 6 or higher
Always keep the transformer away from moisture



Senken Sie den Baum bei Windstärke 6 oder höher.
Halten Sie den Transformator stets von Feuchtigkeit fern



Abaissez l'arbre lorsque la force du vent est de 6 ou plus
Gardez toujours le transformateur à l'abri de l'humidité



Sänk trädet när vindstyrkan är 6 eller högre
Håll alltid transformatorn borta från fukt



Sænk træet, når vindstyrken er 6 eller højere
Hold altid transformeren væk fra fugt



Senk treet når vindstyrken er 6 eller høyere
Hold alltid transformatoren unna fuktighet



Opuść drzewo, gdy siła wiatru wynosi 6 lub więcej
Zawsze trzymaj transformator z dala od wilgoci

RoHS
compliant



TRANSFORMER



LIGHTSET

IP
44



CE



For more information
and explanations,
scan the QR code or email
service@xmasstarlight.com

® XMAS Starlight® is a registered trademark of Elmersindustries BV
XMAS Starlight B.V. Ploeggang 12, 8431NG Oosterwolde, The Netherlands



XMAS
STARLIGHT
ORIGINAL DUTCH COMPANY

XMAS TREE MANUAL 5 to 16 meter

Xmasstarlight.com
Ploeggang 12
8431NG Oosterwolde
The Netherlands

Manual 5 to 16 meter Xmasstarlight, excl pole

1



Tree1 piece




Peg
8 pieces





Plug 1 piece



Measure belt 1 piece




2





click

Repeat until the tree reaches
the top of the pole.



click

3



4

