


## Battery (re)placement guide for Euromex magnifiers



1. Remove batteries from plastic



4. Stack batteries into compartment, make sure that positive charge (text) is facing upwards



5. Place electrode on top of batteries



2. Unscrew lid with enclosed tool or coin to access battery compartment



6. Return lid and screw tight until you feel little resistance



3. Carefully lift electrode and wiring from compartment (use paperclip/tweezers)



7. Switch LED on to confirm batteries are placed correctly