

## DAF NGD STONEGUARD MOUNTING GUIDE



THE STONEGUARD COMES WITH 5 FIXED MOUNTING POINTS



INSTALL THE BRACKETS DELIVERED WITH THE STONEGUARD  
IN THE FOLLOWING WAY.



BRACKET POSITION 2 AND 4 (INSIDE VIEW)



**BRACKET POSITION 2 AND 4 ( OUTSIDE VIEW )**



**BRACKET POSITION 3 ( MIDDLE BRACKET )**



**BRACKET POSITION 3 (MIDDLE BRACKET INSIDE VIEW) FIX WITH A NUT AND BOLT AND POP RIVET AS SHOWN.**



BRACKET POSITION 1 AND 5.



BRACKET POSITION 1 AND 5 INSIDE VIEW.



**FIRST TEST FIT THE STONEGUARD BEFORE PAINTING. PAINTED RETURNS WILL NOT BE ACCEPTED. THE STONEGUARD IS MOUNTED ON 5 FIXING POINTS AND CAN BE REMOVED TO OPEN THE GRILLE OR FOR PERIODIC TESTING PURPOSE.**

**ALL SENSORS REMAIN IN FUNCTION. A CUT OUT IS REQUIRED FOR THE CORNER EYE CAMERA (SPECIFY WITH YOUR ORDER)**

**THE MOUNTING DIFFICULTY RATING FOR THIS PRODUCT IS EXPERT!**

**THIS STONEGUARD IS FOR LHD VEHICLES ONLY.**

