

Sazou Jewels – Gebruiksaanwijzing Ernest Horloge Myron



STOPWATCH.

JUST PRESS BUTTON **B** ONCE, THE STOPWATCH FUNCTION WILL APPEAR, THEN USE THE **C** BUTTON TO ACTIVATE OR STOP THE STOPWATCH. THEN USE THE **D** BUTTON TO RESET THE STOPWATCH COUNT

ALARM

PRESS THE **B** BUTTON TWICE, THE ALARM TIME FLASHES. USE THE **C** BUTTON TO SET THE ALARM TIME. THEN PRESS THE **D** BUTTON TO FLASH THE WAKE UP MINUTES, AND USE THE SAME BUTTON TO ADJUST. THEN USE THE **B** BUTTON TO COMPLETE THE SETTING.

TIME

PRESS BUTTON **B** THREE (3X) TIMES CONSECUTIVELY TO FLASH THE TIME DISPLAY.
THEN USE BUTTON **C** AND **D** TO SET THE HOUR, MINUTE AND SECOND