V2

Assembly Instructions

PARTS

Frame **A**	Handlebar **C**	Saddle **D**
x1	x1	x1

Small package contents :

| Front foot **E**	Screw and Washer **B1** & **B2**	Rear foot **F**
FRONT AVANT		BACK ARRIERE
x1	x2 Screwed on each feet	x1
Pair of PEDAL & CRANK *Pedals already fixed on cranks* **2 PAIRS**	ALLEN KEYS	

Feet Assembly, E & F on Frame A

1	2
Unscrew B1 and insert E	**Screw B1**
A, B1, E	FRONT / AVANT

3	4
Unscrew B2 and Insert F	**Screw B2**
B2, F	BACK / ARRIERE

5	6
Insert RIGHT & LEFT pedal crank sets through axis hole	Lock **PEDALS SET**

Screw

FINALIZED ASSEMBLY :

Handlebar assembly, C on the frame A

7	8
Remove screws from the gallows fixed on the frame A	Place handlebar C between the 2 parts of the gallows & replace screws
Remove Screws x2 to open	
A	

Adjust the saddle D

9	10

MAINTENANCE ADVICES

*We thank you for purchasing one of our **AquaNess devices.***
We wish you lots of pleasure by using it.

aquabiking or aquajogging.

*Hereby you will find some advices to use and keep your **AquaNess** in the best conditions.*

IMPORTANT => before using the *AquaNess* , control the PH of the water ! <=

*The **pH**, or potential hydrogen, means the concentration in water of ions of hydrogen. The percentage of pH exists between 0 and 14 ; the water of the pool have to be neutral or slightly basic.*

The water of your pool should have the best rate valid of pH 7,4

ATTENTION => The guarantee can't apply if the unbalanced pH is the reason of possible changes on the painting on the aluminum frame or on stainless steel bolting <=

- After using your **AquaNess** in the pool, please **rince it** with fresh water, and **wipe it** (*don't forget underside of the saddle*)
- Do not use water treatment such as chemical treatment, when the bike is in the water or nearby.
- Pay attention to avoid any shock; don't let the device falling down.
- Shock impacts on the painting are not covered by the guarantee.
- When you do not use your bike or aqua treadmill, please store your **AquaNess** in a dry or well ventilated room.

Any breach on these maintenance tips will cancel the warranty.

2 years warranty on any kind of manufacturing trouble(Frame, handlebar, crank set …)
6 months warranty on any wear parts (saddle, handlebar, belts…)

Please read carefully :

- The bike must be only used in a completely stable swimming pool
- The water lever never has to exceed the height of shoulders
- It is forbidden to modify the device and to use it for another purpose than pedaling in the water-
- The children minors have to use the device only under the supervision and the responsibility of their parents.