

TWIN WIRELESS BUDS

USER GUIDE



Model: Q830
SKU: NT-14-830
EAN: 8719273148303

A UNIQ Surround Product
Innsbruckweg 46
3047AH Rotterdam, Netherlands

+31 10 229 89 03
info@uniqaccessory.com

PRODUCT INSTRUCTION & PICTURE

Name: UNIQBUDSQ830
Bluetooth version: 4.2
Charge voltage: DC 5V
Working temperature: -20~50 C
Charging time: about 1.5 hours
Talking time: about 3 hours
Music time: over 2 hours
Supported devices type: can be used with devices (e.g. phones or laptops)
which support HSP/A2DP/AVRCP and so on for music function and call function.

Charge base introduction
Input current: 5V/500MA
Output current: 5V/200MA
Battery capacity: >450MA



FUNCTIONS INSTRUCTION

POWER ON:

Long press power-on button for 2 seconds to get blue light flash 3 times and voice prompt 'power-on'. The earphones reconnect to the paired devices nearby.

GET INTO PAIR STAGE (RECONNECTING):

In power-off state, long press 'power-on' button for 2 seconds and see the red and blue light flash alternately and hear the voice prompt "waiting for pairing". At that time the earphones get into the pairing state.

CLEAR THE PAIRED INFORMATION:

Long press 'power-on' button for 8 seconds to get blue light flash 2 times and voice prompt 'beep'. After beep, it has cleared the paired information.

PAIRING:

Turn on the phone's Bluetooth option to search 'UNIQBUDSQ830' and click on it to pair. Seconds later, the LED light turns blue and flashes slowly and it shows 'UNIQBUDSQ830' connected to the device.

POWER OFF:

Long press 'power-on' button for 3 seconds to get voice prompt 'power off' and red light is on for 2 seconds.

1. The right and left earphones have been paired and connected before shipping from factory. Turn on both earphones simultaneously for the first time use. About 3 seconds later the two earphones connect successfully and the main earphone will get into the pairing state. Then use the device to search and connect the main earphone. After that you will only

need to turn on the two earphones and they can connect the phone automatically.
2. To choose the main earphone again, you need to double click one earphone as the main earphone (left channel) after the twins earphones get into the pairing state. With the twins earphones connected successfully, the main earphone gets into the pair state automatically, and then use the device to search and connect the main earphone.

CHOOSE MAIN EARPHONE (PAIRING STAGE):

Double click the 'power-on' button, get voice prompt "waiting for team pairing"

CALL FUNCTION: (MAIN EARPHONES)

1. Last call redial: in connected mode, double-click the power-on button to redial the last number with the 'beep' voice prompt.
2. Answer/Hang Up: Short press 'power-on' button to answer/hang up a phone call.

3. Reject a phone call: Double click 'Power-on' button to reject the call simultaneously there will be a 'beep' voice prompt.
4. Voice dialing (to open Siri) Long press 'power-on' button for 1 second and release after hearing the 'beep' prompt.

MUSIC FUNCTION:

Turn on the phone player, click the 'power-on' button of the main earphone to control play and pause, during the music is playing.

NEXT SONG:


Click the vice earphone to get next song.

AUTO POWER OFF:

Unpairs automatically over 5 minutes if not used. Also if the voltage is less than 3.0V, it will power off.

INDICATOR LIGHTS

Power on: Blue LED light flashes 3 times to get into power on stage.
Power off: Red LED light on for 2 seconds and goes power off.
Pairing mode: Red and blue LED lights flash alternately.
Connected and standby state: Blue LED light flashes once every 10 seconds.
Calling state: Blue LED light flashes once every 10 seconds.
Charging: Red light on.
Charging Complete: Blue light on.



UNIQBUDSQ830

PRODUCT WARRANTY CARD

1. Warranty is valid for six months after purchase. If the failure is caused by technical issues and under normal usage, we will repair or replace the product free of charge.
2. In the following circumstances, the company will refuse to provide warranty service:
a. The product has been wrongly operated, inadvertent used or because of natural and man-made disasters such as accident led to the damage of parts.
b. The product is not bought and doesn't carry our name on it.
c. Product parts have been converted, altered or removed.
d. The product is not in accordance with the original factory to provide the installation instructions.
3. The warranty card to provide free services do not include products accessories, and other decorative projects.
4. The company will not be responsible for any loss, damage to equipment and cause direct or indirect losses.
5. The content of the warranty card is changed, without prior notice.

ATTENTION

Please keep away from the magnet when using bluetooth headset, electrical appliances and near the speaker.
Try to avoid placing the bluetooth headset in extreme temperatures.
Avoid exposing bluetooth headset in the humid environments.

COMMON PROBLEMS AND THEIR SOLUTIONS

| Problem | Cause of problem | Solution |
|--------------------------------------------|--------------------------------------------------------------------------|-----------------------------------------------------------|
| Automatically shut down | Lack of battery | 1.5 hours to recharge headphones |
| After pairing silent | Pairing is not correct | Pair/match again |
| You can call, but red bright light appears | Battery shortage appears red light hint | Please charge immediately |
| Charge no order | The charger has no voltage output | Check the charger plug and if power supply is switched on |
| The headphones have echo | Volume is too high or too noisy environment | Adjust the volume or change place |
| Talk with noise | Environmental disturbance caused or headset distance too far with device | In a place or the headset and equipment distance between |
| The two sides low voice | Headset is not correct | Adjust position of the headphones |
| Can't listen to music | Mobile phone does not support | In exchange for support stereo bluetooth phones |