Operation

Operation

Start Stand-alone mode:

By depressing start once the "+ and -" buttons can be used to set the tanning time. Pressing for a second time will start the unit.

Coin mode:

The unit can be started automatically by the external timer or the coin automat. The start button can be used only when the unit has to be restarted from "pause".



Α

Stand-alone mode:


Pressing stop once will cause the unit to "pause". The lights will go out but the ventilation will continue to run.


Pressing stop twice will initiate a mandatory after-cooling phase of 3 minutes. The unit cannot be started during these 3 minutes.

Coin mode:

Pressing stop once will cause the unit to "pause". The lights will go out but the ventilation will continue to run.

The unit will not respond to pressing stop several times. The external timer or coin automat will switch the unit off. Switching off will initiate a mandatory after-cooling phase of 3 minutes. The unit cannot be started during these 3 minutes.





General:

The unit is generally set for use without external timer or coin automat (stand-alone mode). When the unit has to operate in combination with an external timer or a coin automat (coin mode), the internal time should be set to 0 minutes as per procedure below.



depress continuously for 10 seconds

after 10 seconds depress the "-" button and contin ue to press until the display indicates "00"

press once and the unit will bleep in response. Note: The maximum tanning session is restricted to 30 minutes.

