



Seal Check II

Setup, Use, and Care Guide

Copyright 2012, Gates Underwater Products, Inc.

Last document revision: December 14, 2012

This manual is available in 8.5 x 11 size and full color at

<http://www.gateshousings.com/documentation.html>

Gates Underwater Products, Inc.

13685 Stowe Drive
Poway, California 92064 USA

Phone: 800.875.1052 toll-free in the U.S.

858.391.0052 outside the U.S.

Fax: 858.391.0053

Web: <http://gateshousings.com/>

Table of Contents

1:	Introducing Seal Check II	4
	Features	4
	Warranty Disclaimer	4
	Unpacking Seal Check II.....	5
	Optional Parts	5
2:	Using Seal Check II.....	7
	Setup and Preparation.....	7
	Test	8
	Pre-Dive Final Check	9
	Post Dive	10
3:	Troubleshooting.....	11
	No Vacuum	11
	Rapid loss of vacuum.....	12
	Slow loss of vacuum.....	13
	What to do if you find a leak.....	14
4:	Maintaining Seal Check II	15
5:	Self Installation Kit	16
6:	Customer Support	18

1: Introducing Seal Check II

Congratulations on owning a new Gates product: Seal Check II. You've selected a product that will provide years of value and reliable service. We designed this test product specifically to enhance the reliability of your Gates underwater imaging system and protect your investment.

Please read through this entire guide to learn about Seal Check II so you can get the most out of this valuable tool. In this section, we'll introduce you to the features of Seal Check II so you can get started.

Features

Seal Check II has several key features:

- **Integrity Verification.** As the name implies, Seal Check II provides a means of testing the seal integrity of your Gates housing *before* entering the water.
- **Portable.** A small Pelican 1150 case accompanies you to all corners of the globe.
- **Convenient and easy to use.** Seal Check II is straightforward & quickly draws a vacuum on even the largest Gates housings, revealing housing integrity in a few short minutes.

Warranty Disclaimer

Seal Check II is a tool that, like any tool, requires knowledge and understanding to be effective. When used properly Seal Check II virtually eliminates the possibility of water intrusion to your housing.

Your responsibility is to learn the proper setup, use and care of Seal Check II. Because we can only provide you with the information necessary to do so, Gates does not warrant the contents of your housing (e.g. your camera and lenses) under any circumstance. We warrant Seal Check II as a testing tool only for a period of 1 year. The body fitting installed on a Gates housing is warranted for 2 years.

Gates does not warranty the contents of your housing (eg. Your camera and lenses). Therefore the appropriate insurance should be maintained by the user.


If you have any questions about the setup, use and care of Seal Check II, contact Gates directly. Details are in section 6.

Unpacking Seal Check II


After you remove Seal Check II from its shipping container, carefully inspect it for missing parts or damage that may have occurred during shipment. If you discover any discrepancies, contact Gates or your dealer immediately for assistance.

Seal Check II comes with the following standard parts:

- ☐ Body Fitting and Plug installed in your housing
- ☐ Pelican 1150 Case with integrated Seal Check II vacuum system
- ☐ Quick Test and Troubleshooting Guides
- ☐ This Setup, Use and Care Guide
- ☐



Body Fitting & Plug on housing



Optional Parts

Your housing may also come with an optional self install kit:

- ☐ Body Fitting and Plug
- ☐ # 'D' size drill
- ☐ 1/16-27 NPT Tap
- ☐ Q-Tip applicators (2)
- ☐ Two part urethane adhesive
- ☐ Adhesive mixing stick

For the self installation you will also require:

- ☐ Rubbing alcohol or other non-residue solvent
- ☐ Torque wrench with 7/16" head

Refer to section 5 for installation instructions



2: Using Seal Check II

Seal Check II is straightforward to use, but we recommend you take time to become familiar with the system. This will help ensure operation will go smoothly at your dive location.

Setup and Preparation

- Remove the stem plug from the body fitting on the housing. Do so by pulling back on the sleeve (much like your BC inflator hose) then remove the plug.
- ▶ **NOTE: Use care to align the stem & fitting when coupling and uncoupling.**
- Insert the test stem into the body fitting. The test stem is on the end of the 24" hose in the Seal Check II kit.

Remove stem plug



Insert Test Fitting





Test

- ☐ Turn on the gauge. The unit will read ~0 Millibars.
- ☐ Rotate the 3-way valve so the lever points toward “PUMP.”
- ☐ Turn on the vacuum pump.
- ☐ Watch the gauge until it reaches approximately 200 Millibars. At this time turn off the pump switch and rotate the 3-way valve lever to the center “CHECK” position.
- ☐ Wait for system to settle. The Gauge takes time to ‘settle’. During this time the gauge will typically drop between 2 and 3 Millibars. It may take up to 60 seconds to do so.
- ☐ Monitor the gauge. Wait ~ 10 minutes. A 3 or less drop in Millibars indicates a passing condition.

If you are unable to draw a vacuum on the housing or if you see a steady and continuous drop in vacuum reading, this indicates a fail condition. Consult the troubleshooting section of this guide for more details.

Pre-Dive Final Check

- Confirm a Test Pass when the gauge reads a consistent, stable reading. If the gauge reading drops consistently and steadily, refer to the troubleshooting section.
 - Remove the test stem from the body fitting.
 - Insert the stem plug. Pull on the plug to verify it is inserted and locked in position for water entry.
- ▶ **WARNING: THE STEM PLUG MUST BE INSERTED AND LOCKED PRIOR TO WATER ENTRY. FAILURE TO DO SO MAY RESULT IN A WET CAMERA.**
- ▶ **NOTE:** It is unnecessary to remove the vacuum from the system prior to diving. It is, in fact, beneficial to maintaining a seal prior to water entry.



Post Dive

Upon return from the dive, it is necessary to release the vacuum on the housing.

- ▶ **CAUTION:** Do not attempt to open the housing prior to releasing the vacuum. The small amount of vacuum (or more appropriately, the external pressure) exerted will prevent opening without the use of tools or other damaging measures.

- ☐ Remove the stem plug.
- ☐ Insert the test fitting.
- ☐ Release the vacuum. Rotate the 3-way valve to “VENT” position. This will open the housing to ambient air and release the vacuum. It may take up to 60 seconds to do so.


- ▶ **NOTE:** When releasing the vacuum the gauge may read zero before the vacuum is fully released. The vacuum is fully released when you can open the housing normally.

- ☐ Remove the test fitting and re-insert the stem plug.
- ☐ Open the housing and perform your usual post-dive procedures.

Remove stem plug



Insert Test Fitting



3: Troubleshooting

This section is a guide to finding a leak when Seal Check II determines one is present. There are three types of leaks addressed here:

- ☐ No vacuum i.e. a vacuum cannot be drawn on the housing.
- ☐ Rapid loss of vacuum; and
- ☐ Slow loss of vacuum.

No Vacuum

In this condition, no vacuum can be pulled on the housing. The vacuum gauge continues to read zero despite an operating vacuum pump. This indicates a complete compromise of a seal, or a missing seal. In most cases the cause will be evident, so look for the obvious.

- ☐ First check that the 3-way valve **is in the “PUMP” position.**
- ☐ Examine the main seal for an even line around the mating front and rear shells. An easy check is to run a slip of paper around the seal. It should not pass the o-ring. Look closely at the latches that they are tight and secure. (Refer to the photo in the next section.)
- ☐ If this is the first use of the housing from storage or travel check for damage. Abusive handling, inspectors and excessive vibration can inflict harm.
- ☐ Check the glands (the bolt-shaped component at the base of each control. Refer to the photo in the next section). Try to loosen with your fingers. They should be tight. If one has loosened, gently tighten with a 5/8 wrench.
- ☐ Check for setup errors like a missing o-ring or misaligned port.
- ☐ If the housing has been in use and now leaks, focus on any changes or service performed on the housing.
- ☐ Lastly, examine Seal Check II for detached or broken hoses.
- ☐ At any point, you can re-test the housing for leaks to eliminate possibilities. This logical approach will rapidly narrow and help ID the cause.


Rapid loss of vacuum

In this condition, a vacuum can be drawn on the housing, but drops rapidly reaching zero within a few minutes. This indicates the o-rings are compromised by damage, foreign matter or poor mating of components. Finding this type of leak will require a little more investigation but it should also be evident once identified.

- Examine the main seal for an even line around the mating front and rear shells. Look for obvious gaps. An easy check is to run a slip of paper around the seal. It should not pass the o-ring. Look closely at the latches that they are tight and secure.
- Check the main seal and port o-rings. These are most commonly susceptible to damage by handling. Inspect them carefully for nicks or cuts. Gently stretch them between your fingers to highlight any cracks or cuts.

Ensure the o-ring is free of foreign matter (dirt, hair, etc) that can compromise the seal. Clean and lubricate the o-ring as needed, and re-install. (NOTE: DO NOT LUBRICATE THE ORANGE O-RINGS.)

- If the housing has been in use and now leaks check for changes or service performed on the housing.
- If this is the first use of the housing from storage or travel check for damage. **Abusive handling, inspections and excessive vibration can inflict harm.**
- Check the glands (the bolt-shaped component at the base of each control). Try to loosen with your fingers. They should be tight. If one has loosened, gently tighten with a 5/8 wrench.
- Examine all windows. A proper seal is indicated by a solid black line (which is the o-ring) around the perimeter. Also look for cracks. A flashlight may be necessary to illuminate more subtle cracks or damage.
- Lastly, examine Seal Check II **for cracked or broken hoses.**



At any point, you can re-test the housing for leaks to eliminate possibilities. This logical approach will rapidly narrow and help ID the cause. If necessary you can also take the housing in the water WITHOUT a camera and look inside the port or windows to see where water is entering.

Slow loss of vacuum

In this condition, a vacuum can be drawn on the housing but drops slowly and consistently over time. The vacuum reading may or may not reach zero depending on the specific type of leak.

This type of leak indicates the o-rings are attempting to seal but one or more are compromised by a more subtle form of damage, foreign matter or poor mating of components. Finding this type of leak is more difficult and time consuming. Leaks of this nature are best identified by close examination and frequent re-test to eliminate possibilities. Taking this logical approach will be most efficient.

- ▶ **NOTE:** A false leak indication may occur if your housing is experiencing a significant temperature change. For example, if you move the housing from a cool, air-conditioned room to a warm tropical exterior, the gauge may indicate a slow loss of vacuum. This may be a false leak indication. It will be necessary to wait until the housing reaches ambient temperature before an accurate reading of the gauge can be made.

- Examine the main seal for an even line around the mating front and rear shells. An easy check is to run a slip of paper around the seal. It should not pass the o-ring. Look closely at the latches that they are tight and secure. (Refer to the photo in the previous section)

- Check the main seal and port o-rings. These are most commonly susceptible to damage by handling. Inspect them carefully for nicks or cuts. Gently stretch them between your fingers to highlight any cracks or cuts.

Ensure the o-ring is free of foreign matter (dirt, hair, etc) that can compromise the seal. Clean and lubricate the o-ring as needed, and re-install. (NOTE: DO NOT LUBRICATE THE ORANGE O-RING.)

- If the housing has been in use and now leaks check for changes or service performed on the housing.



- If this is the first use of the housing from storage or travel check for damage. **Abusive handling, inspections and excessive vibration can inflict harm.**
- Examine all windows. A proper seal is indicated by a solid black line (which is the o-ring) around the perimeter. Also look for cracks. A flashlight may be necessary to illuminate more subtle cracks or damage.
- Check the glands (the bolt-shaped component at the base of each control. Refer to the photo in the previous section.). Try to loosen with your fingers. They should be tight. If one has loosened, gently tighten with a 5/8 wrench.
- Look closely at the surface where the main o-ring mates. Examine this surface for nicks, dings and scratches that could compromise the seal. Do the same for the port mating surface. This surface is the inner diameter of the port bore opening, immediately forward of the bayonet tabs.
- Examine all controls. The stainless steel shafts should be free of nicks and scratches. A scratch of sufficient depth to compromise a seal can be felt with your fingernail.
- Lastly, examine Seal Check II **for cracked or broken hoses.**
- At any point, you can re-test the housing for leaks to eliminate possibilities. This logical approach will rapidly narrow and help ID the cause.
- If necessary, you can also take the housing in the water WITHOUT a camera and look inside the port or windows to see where water is entering.

What to do if you find a leak

Fortunately, nearly all leaks identified by Seal Check II are readily remedied on the spot. O-rings, generally the cause of water intrusion, are easily replaced. Ports can be seated and housing shells mated more carefully. Glands can be tightened. It is very likely you will be ‘up and running’ quickly having identified the leak.

If circumstance requires parts or other support from Gates to fix a problem, please contact us immediately. We stand ready to assist and help you to get the underwater images you want.

Should you be in a remote location and must perform repairs to your Gates housing on the spot, our technical support team may be able to guide you through some unconventional but effective field repairs. Again, contact us directly with the information in section 6. .


4: Maintaining Seal Check II

Seal Check II requires virtually no maintenance. Follow these simple guidelines to keep Seal Check II operating at full efficiency.

- **Store Seal Check II** in the Pelican case with lid closed when not in use. Be sure the system is not wet.
- **Be Careful** not to “kink” or pinch the air hose.
- **Foreign contaminants.** Keep Seal Check II free from dirt, sand and other foreign matter. Avoid anything that might foul the vacuum pump or other components in the system.
- **Replace vacuum pump batteries** when necessary. You can expect more than 50 cycles of vacuum tests on the 8 AA cells required for the vacuum pump. Replace them when the pump exhibits obvious signs of slowing down when drawing a vacuum on the housing. Remove the battery cover to change batteries.
- **Lightly lubricate the stem plug** every 20th use. This will in turn lubricate the o-ring inside the body fitting. Use a light silicone lubricant and apply sparingly.
- **Long term storage.** When not in use for more than 30 days at a time, remove all batteries.



Seal Check II requires 8 AA batteries. Remove cover for access



Lightly lubricate the stem of the stem plug

5: Self Installation Kit

This section outlines the steps necessary to install the test body fitting on an underwater housing.


It is highly recommended the installation be performed by an experienced machinist.

- Identify the location where the test body fitting will be installed. The wall must be a minimum 0.2" / 5mm thick.

If possible, pick a location that can protect the test body fitting. For example, installing next to a port or handle grip might protect it from impact.

The location should also be flat (not curved) to facilitate drilling and tapping perpendicular to the surface.

- Drill a hole using the 'D' size drill.
- Tap the hole with the 1/16-27 tap. Note that the tap is marked with white indicating the tap depth. Use care to tap up to, but not beyond this marker.



Body fitting & stem plug installed next to the port on a Gates housing.

Urethane adhesive with mixing stick and applicators.



D drill and 1/16-27 NPTF tap -- Note the white marker on the tap.

Body fitting with plug, wire retainer and warning tag

- Clean the threads of both the test body fitting and the tapped hole with rubbing alcohol or other non-residue solvent cleaner.
 - Mix the two part urethane adhesive thoroughly with the mixing stick per the instructions on the label.
 - Apply the urethane adhesive. Using the stick end of the Q-tip apply a light coat to the threads on the housing, and a similar light coat to the threads of the fitting
 - Insert the test body fitting in the tapped hole and tighten with a torque wrench to 55 In-lbs / 5.6 N-m. A properly installed fitting will have 1-2 threads visible at the base of the fitting.
 - Remove excess urethane adhesive inside the housing where the fitting extends through with rubbing alcohol.
 - Do not remove the urethane adhesive from the exterior at the base of the fitting. Allow it to 'fillet' at the base.
 - Allow the urethane adhesive to dry **for 24 hours**.
 - Insert the stem plug into the fitting and loop the retainer wire **around the base of the fitting as shown in the photo**.
 - Test the system as outlined in the previous sections.
- **NOTE:** Gates provides no warranty on the self installation of Seal Check II fittings or any part of any housing or contents (e.g. a camera). The installation is your responsibility. If you have any questions about the installation contact Gates at the information provided in section 6.

1-2 threads are visible at the base of the body fitting when properly installed.

Allow urethane adhesive to form a fillet at the base of the threads.

When dry, loop the stem retainer wire around the base of the fitting and insert the stem into the fitting.



6: Customer Support

Should you have any questions about Seal Check II and its operation, please contact Gates at the numbers below.

Email: Customer.srvc@GatesHousings.com

Web: www.GatesHousings.com

Phone: 858.391.0052

Fax: 858.391.0053